


Key combination		Function	Key combination		Function		
Fn + Z		Pre Track	Fn + Enter	Win_Right	→	Arrow Left	
Fn + X		Play/Pause		Menu		Arrow Down	
Fn + C		Next Track		Ctrl_Right		←	Arrow Right
Fn + V		Volume Decrease		Shift_Right		Arrow Up	
Fn + B		Volume Increase	Note	Shift_Right Keycap lower right corner LED will bright			
Fn + N		Mute					

Dip Switch Functions

Default	Port 1	Port 2	Port 1	Port 2	Port 1	Port 2
	ON	OFF	OFF	ON	ON	ON

Default	Port 3	Default	Port 4
	ON		ON

Default		
Port 5	ON	
Port 6	OFF	
Port 5	OFF	
Port 6	ON	
Port 5	ON	
Port 6	ON	



Feature

1. USB Interface
2. HID Device
3. Plug & Play
4. Firmware upgradable over USB
5. QWERTY Layout
6. About 60% as wide as of the standard 104-Key keyboard
7. Uses mechanical switches
8. N-key rollover
9. 6 Port dip switch for customer define
10. Multi-Lingual Layout
11. Laser-engraved Keycaps

Package Contents

1. Keyboard
2. Replacement keycap
3. Cable
4. Keycap puller

Key combination	Function	Key combination	Function
Fn + ` (~)	Esc	Fn + 0	F10
Fn + 1	F1	Fn + -	F11
Fn + 2	F2	Fn + =	F12
Fn + 3	F3	Fn + Backspace	Delete
Fn + 4	F4	Fn + Tab	Caps Lock
Fn + 5	F5	Fn + W	Arrow Up
Fn + 6	F6	Fn + R	Backspace
Fn + 7	F7	Fn + T	Home
Fn + 8	F8	Fn + Y	Page Up
Fn + 9	F9	Fn + U	Print Screen

Key combination	Function	Key combination	Function
Fn + I	Scroll Lock	Fn + H	Page Down
Fn + O	Pause	Fn + K	Insert
Fn + P	Arrow Up	Fn + L	Arrow Left
Fn + A	Arrow Left	Fn + ;	Arrow Down
Fn + S	Arrow Down	Fn + ' (")	Arrow Right
Fn + D	Arrow Right	Fn + /	Menu
Fn + F	Delete		
Fn + G	End		
Fn + J	~ (Shift + `)		
	Only in US / EU Version		