




MOTOROLA

BRAVO

Numeric Display Portable Programmer



MOTOROLA'S BRAVO Numeric Display Portable Programmer lets you program and reprogram all codes, addresses and options on **BRAVO** Numeric Display pagers. Just remove the battery door and battery from the pager, put the pager in the Programmer, and select your options. You can program or reprogram BRAVO Numeric Display pagers anywhere in minutes!

- Easy to carry — compact and lightweight (1.46 lbs. with batteries).
- Simple to operate — menu driven.
- No attachments necessary.
- Uses 6 'AA' alkaline batteries or an AC adapter (both included).
- Four operating modes:
 - Read Mode tells you what programming exists in the pager.
 - Program Mode lets you program First Code and/or Second Code and all options in the pager.
 - Sequential Mode increments codes for programming a group of pagers in sequence.
 - Options Mode lets you change only options in the pager.
- Portable Programmer lets you:
 - Program First Code and/or Second Code.
 - Select active addresses.
 - Program Group Call or Mail Drop.
 - Add Priority Override on the First and/or Second Code.
 - Select alert options for MEM-O-LERT operation.
 - Program any code plug option.
- To order, use model number NLN3163A (formerly N1388A)



Support Services

Wherever Motorola sells, our product is backed by service. In the U.S., we have 900 authorized or company-owned centers. In addition, our products are serviced throughout the world by a wide network of company or authorized independent distributor service organizations.



MOTOROLA

1301 E. Algonquin Rd., Schaumburg, Illinois 60196
(312) 397-1000

Motorola, Inc. is an Equal
Employment Opportunity/
Affirmative Action Employer.



Motorola, and BRAVO are trademarks
of Motorola, Inc. © 1986 by Motorola, Inc.
□ Printed in U.S.A. (8707) S.P.