

# **VAXlab Master Index**

Order Number: AV-KN98C-TE

**February 1990**

The *VAXlab Master Index* contains index entries from all of the documents in the VAXlab Version 1.4 documentation set.

**Revision/Update Information:** This is a revised document.

**Software Version:** VAXlab Software Library Version 1.4

**digital equipment corporation  
maynard, massachusetts**

---

**First Printing, December 1987**  
**Revised, August 1988**  
**Revised, February 1990**

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1987, 1988, 1990

All Rights Reserved.  
Printed in U.S.A.

The Reader's Comments form on the last page of this document requests the user's critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DEC	LN03R	VAXlab
DECnet	MicroVAX	VAXstation
DRB32	Q-bus	VMS
LN03	VAX	VT
LN03 PLUS	VAXcluster	

**digital**™

This document was prepared with VAX DOCUMENT, Version 1.2.

---

## Introduction to the VAXlab Master Index

The *VAXlab Master Index* is a compilation of the indexes to the individual books in the VAXlab Version 1.4 documentation set.

Each keyword or subentry in the master index is followed by an abbreviated book title and the chapter and page reference to the topic in that book. For example, an entry in the master index might be:

Asynchronous I/O, *LIO*, 1-3

This entry indicates that you can find information about "Asynchronous I/O" on page 1-3 of the *Guide to the VAXlab Laboratory I/O Routines*.

Table 1 provides a list of abbreviations used in the *VAXlab Master Index* to identify the VAXlab documents.

**Table 1: Abbreviations Used in the Master Index**

Abbreviation	VAXlab Document
GETSTART	<i>Getting Started with VAXlab</i>
IDAT	<i>Guide to the VAXlab Interactive Data Acquisition Tool</i>
INSTALL	<i>VAXlab Installation Guide</i>
LGP	<i>Guide to the VAXlab Laboratory Graphics Package</i>
LIO	<i>Guide to the VAXlab Laboratory I/O Routines</i>
LSP	<i>Guide to the VAXlab Laboratory Signal-Processing Routines</i>



# Index

## A

### A/D channels

- adding • *LIO*, 4-19
- specifying • *LIO*, 4-13, 4-15
- specifying gains • *LIO*, 4-17

### A/D converters

- ADF01 • *LIO*, 2-27 to 2-38
- ADQ32 • *LIO*, 2-38 to 2-44
- ADV11-D • *LIO*, 2-44 to 2-49
- AXV11-C • *LIO*, 2-49 to 2-54
- IAV11-A • *LIO*, 2-90 to 2-95
- IAV11-AA • *LIO*, 2-90
- Preston • *LIO*, 2-61 to 2-67

### A/D Samples and Channel Gains screen • *IDAT*, 2-12

### A/D Samples and Channels screen • *IDAT*, 2-10

### AAF01 • *LIO*, 2-12 to 2-22

- alternate-buffer DMA • *LIO*, 1-25
- AST routines • *LIO*, 4-104
- asynchronous output • *LIO*, 4-24
- attaching • *LIO*, 2-13
- buffered data path • *LIO*, 4-92
- clearing large buffer overflow • *LIO*, 4-61
- continuous DMA • *LIO*, 1-21
- Control Table Address (CTA) register • *LIO*, 4-74
- Control Word Registers • *LIO*, 4-87
- direct data path • *LIO*, 4-92
- event ASTs • *LIO*, 4-121
- external clock enable bit • *LIO*, 4-114
- function bits • *LIO*, 4-148
- memory transfer bit • *LIO*, 4-112
- outputting a voltage value • *LIO*, 4-21

### AAF01 (Cont.)

- parameters valid for • *LIO*, 2-14
  - Programmable Clock Register • *LIO*, 4-196
  - read-only bits status • *LIO*, 4-212
  - resetting • *LIO*, 4-214
  - sequence break enable bit • *LIO*, 4-115
  - setting channel • *LIO*, 4-50
  - setting Command Output (COU) bit • *LIO*, 4-63
  - setting up • *LIO*, 2-14
  - single-buffer DMA • *LIO*, 1-20
  - stopping continuous DMA • *LIO*, 4-45
  - synchronous output • *LIO*, 4-239
  - timeout • *LIO*, 4-245
- ### AAV11-D • *LIO*, 2-22 to 2-27
- AST routines • *LIO*, 4-22
  - asynchronous output • *LIO*, 4-24
  - attaching • *LIO*, 2-22
  - buffer forwarding • *LIO*, 4-143
  - continuous DMA • *LIO*, 1-21, 4-70
  - D/A channels • *LIO*, 4-89, 4-179
  - device event flag • *LIO*, 4-97
  - KWV11-C clock rate • *IDAT*, 2-20
  - parameters valid for • *LIO*, 2-23
  - selecting A/D channels for output to the D/A • *IDAT*, 2-28, 2-33
  - setting up • *LIO*, 2-23
  - single-buffer DMA • *LIO*, 1-20, 4-223
  - starting continuous DMA • *LIO*, 4-230
  - stopping continuous DMA • *LIO*, 4-235
  - synchronous output • *LIO*, 4-239
  - timeout • *LIO*, 4-245
  - trigger modes • *IDAT*, 2-38; *LIO*, 4-253
- ### Accepting default values • *IDAT*, 1-10
- ### Accessing the spline calculation • *LGP*, 4-126

Ada program development • *GETSTART*, 3-4  
   checking routine call status • *GETSTART*, 3-11  
   declaring and dimensioning arrays •  
     *GETSTART*, 3-7  
   declaring data types and variables •  
     *GETSTART*, 3-6  
   declaring external routines • *GETSTART*, 3-9  
   defaulting routine call arguments • *GETSTART*,  
     3-10  
   including symbolic definition files • *GETSTART*,  
     3-4  
 Adding a node to DECnet • *GETSTART*, 2-27  
 Adding a user account • *GETSTART*, 2-8  
 ADF01 • *LIO*, 2-27 to 2-38  
   alternate-buffer DMA • *LIO*, 1-25  
   AST routines • *LIO*, 4-104  
   asynchronous input • *LIO*, 4-24  
   buffered data path • *LIO*, 4-92  
   clearing large buffer overflow • *LIO*, 4-61  
   clearing sequence timer enable bit • *LIO*,  
     4-234  
   continuous DMA • *LIO*, 1-21  
   Control Table Address (CTA) register • *LIO*,  
     4-74  
   control table transfer bit • *LIO*, 4-112  
   converting voltage • *LIO*, 4-277  
   DAC Data Register • *LIO*, 4-277  
   direct data path • *LIO*, 4-92  
   event ASTs • *LIO*, 4-121  
   external clock enable bit • *LIO*, 4-114  
   function bits • *LIO*, 4-148  
   output voltage • *LIO*, 4-32  
   parameters valid for • *LIO*, 2-29  
   Programmable Clock Register • *LIO*, 4-196  
   resetting • *LIO*, 4-214  
   sequence break enable bit • *LIO*, 4-115  
   sequence timer • *LIO*, 4-228  
   setting channel • *LIO*, 4-50  
   setting up • *LIO*, 2-29  
   single-buffer DMA • *LIO*, 1-20  
   stopping continuous DMA • *LIO*, 4-45  
   synchronous input • *LIO*, 4-239  
   timeout • *LIO*, 4-245  
 ADQ32 • *LIO*, 2-38 to 2-44  
   A/D channel gains • *LIO*, 4-17  
   A/D channels • *LIO*, 4-13, 4-176  
   A/D channels and channel gains • *IDAT*, 2-10

#### ADQ32 (Cont.)

  AST routines • *LIO*, 4-22  
   asynchronous input • *LIO*, 4-24  
   attaching • *LIO*, 2-40  
   buffer forwarding • *LIO*, 4-143  
   buffer size • *LIO*, 4-37  
   buffer specification • *LIO*, A-6  
   channel specification • *LIO*, A-5  
   clock logic • *LIO*, A-9  
   clock modes • *LIO*, A-10 to A-43  
     summary of • *LIO*, A-1  
   clock overrun errors • *LIO*, A-8  
   clock rate and divider • *LIO*, 4-55  
   device event flag • *LIO*, 4-97  
   diagnostic inputs • *LIO*, 4-99  
   differential input • *LIO*, 4-15  
   double-buffer DMA • *LIO*, 1-27  
   double buffer transfers • *LIO*, A-7  
   enabling double-buffer DMA • *LIO*, 4-95  
   external frequency input • *LIO*, 2-39  
   external gate/trigger input • *LIO*, 2-39  
   external gating • *LIO*, 4-153  
   FIFO buffers • *LIO*, 1-16  
   gain specification • *LIO*, A-6  
   number of samples • *IDAT*, 2-10  
   parameters valid for • *LIO*, 2-41  
   setting up • *LIO*, 2-40  
   single-buffer DMA • *LIO*, 1-20, 4-223  
   single buffer transfers • *LIO*, A-6  
   single-ended input • *LIO*, 4-15  
   starting data acquisition • *LIO*, A-8  
   sweep clock rate • *IDAT*, 2-37; *LIO*, 4-237  
   synchronous input • *LIO*, 4-239  
   trigger modes • *IDAT*, 2-13; *LIO*, 4-253  
 ADV11-D • *LIO*, 2-44 to 2-49  
   A/D channel gains • *LIO*, 4-17  
   A/D channels • *IDAT*, 2-18, 2-27; *LIO*, 4-13,  
     4-176  
   AST routines • *LIO*, 4-22  
   asynchronous input • *LIO*, 4-24  
   attaching • *LIO*, 2-44  
   buffer forwarding • *LIO*, 4-143  
   channel gains • *IDAT*, 2-12, 3-8  
   continuous DMA • *LIO*, 1-21, 4-70  
   device event flag • *LIO*, 4-97  
   KWV11-C clock rate • *IDAT*, 2-20, 3-9  
   number of samples • *IDAT*, 2-12, 3-8  
   parameters valid for • *LIO*, 2-45

## ADV11-D (Cont.)

- setting up • *LIO*, 2-45
- single-buffer DMA • *LIO*, 1-20, 4-223
- starting continuous DMA • *LIO*, 4-230
- stopping continuous DMA • *LIO*, 4-235
- synchronous input • *LIO*, 4-239
- timeout • *LIO*, 4-245
- trigger modes • *IDAT*, 2-38, 3-9; *LIO*, 4-253
- Allocating a device • *GETSTART*, 2-38
- Alternate-buffer DMA • *LIO*, 1-25
- AMF01 • *LIO*, 2-27
- AMF01 option
  - clearing sequence timer enable bit • *LIO*, 4-234
  - sequence timer • *LIO*, 4-228
- Analog devices
  - AAV11-D • *IDAT*, 1-2
  - ADQ32 • *IDAT*, 1-2
  - ADV11-D • *IDAT*, 1-2
  - AXV11-C • *IDAT*, 1-2
  - Preston/DRB32 • *IDAT*, 1-2
  - Preston/DRQ3B • *IDAT*, 1-2
  - Preston/DRV11-WA • *IDAT*, 1-2
- Analog I/O devices • *LIO*, 2-12 to 2-67
  - AAF01 • *LIO*, 2-12 to 2-22
  - AAV11-D • *LIO*, 2-22 to 2-37
  - ADF01 • *LIO*, 2-27 to 2-38
  - ADQ32 • *LIO*, 2-38 to 2-44
  - ADV11-D • *LIO*, 2-44 to 2-49
  - AMF01 • *LIO*, 2-27
  - ASF01 • *LIO*, 2-12, 2-28
  - AXV11-C • *LIO*, 2-49 to 2-54
  - DRQ11-C • *LIO*, 2-54 to 2-61
  - IAV11-A • *LIO*, 2-90 to 2-95
  - IAV11-AA • *LIO*, 2-90
  - IAV11-B • *LIO*, 2-95 to 2-98
  - Preston • *LIO*, 2-61 to 2-67
- Analog-to-digital converters
  - See A/D converters
- Analog-to-digital data translation • *LSP*, 6-38
- Array
  - three-dimensional • *LGP*, 4-80, 4-121, 4-134
  - two-dimensional • *LGP*, 4-59, 4-115
- ASF01 • *LIO*, 2-12, 2-28
- Assigning logical names • *LGP*, 1-9
  - example of • *LGP*, 1-11
  - for foreign device support • *LGP*, 1-12

## Assigning logical names (Cont.)

- GKS\$CONID • *IDAT*, 1-4, 4-4
- GKS\$WSTYPE • *IDAT*, 1-4, 4-4
- Associated documents • *INSTALL*, viii
- AST routines • *LIO*, 1-11 to 1-13, 4-81
  - buffer completion • *LIO*, 2-127
  - declaring global variables • *GETSTART*, 3-24
  - event ASTs • *LIO*, 1-13, 2-127, 4-121 to 4-124
  - restrictions for use • *LIO*, 1-13
  - setting up to receive buffers • *LIO*, 4-104
- Asynchronous I/O • *LIO*, 1-3
  - application uses • *LIO*, 1-4
  - buffer-handling mechanisms • *LIO*, 1-8 to 1-13
  - device queue • *LIO*, 1-3
  - LIO\$DEQUEUE routine • *LIO*, 1-4
  - LIO\$ENQUEUE routine • *LIO*, 1-4
  - LIO\$K\_ASYNC parameter • *LIO*, 4-24
  - user queue • *LIO*, 1-3
  - using disk files • *LIO*, 2-149
  - using serial line devices • *LIO*, 2-144
  - using the DRB32 • *LIO*, 2-71
  - using the DRB32W • *LIO*, 2-77
  - using the DRQ11-C • *LIO*, 2-59
  - using the DRQ3B • *LIO*, 2-81
  - using the DRV11-WA • *LIO*, 2-89
- Asynchronous input
  - using the ADF01 • *LIO*, 2-35
  - using the ADQ32 • *LIO*, 2-43
  - using the ADV11-D • *LIO*, 2-47
  - using the AXV11-C • *LIO*, 2-53
  - using the IAV11-A • *LIO*, 2-94
  - using the IDV11-A • *LIO*, 2-101
  - using the Preston • *LIO*, 2-66
- Asynchronous output
  - using the AAF01 • *LIO*, 2-19
  - using the AAV11-D • *LIO*, 2-26
  - using the IAV11-B • *LIO*, 2-98
  - using the IDV11-B • *LIO*, 2-103
- Asynchronous System Traps (ASTs) • *LIO*, 1-11 to 1-13
- Attaching I/O devices
  - AAF01 • *LIO*, 2-13
  - AAV11-D • *LIO*, 2-22
  - ADQ32 • *LIO*, 2-40
  - ADV11-D • *LIO*, 2-44
  - AXV11-C • *LIO*, 2-49

## Attaching I/O devices (Cont.)

- disk files • *LIO*, 2-147
  - DRB32 • *LIO*, 2-68
  - DRB32W • *LIO*, 2-74
  - DRQ11-C • *LIO*, 2-55
  - DRQ3B • *LIO*, 2-78
  - DRV11-J • *LIO*, 2-83
  - DRV11-WA • *LIO*, 2-87
  - IAV11-A • *LIO*, 2-91
  - IAV11-AA • *LIO*, 2-91
  - IAV11-B • *LIO*, 2-96
  - IAV11-C • *LIO*, 2-91
  - IAV11-CA • *LIO*, 2-91
  - IDV11-A • *LIO*, 2-99
  - IDV11-B • *LIO*, 2-101
  - IDV11-D • *LIO*, 2-104
  - IEQ11 • *LIO*, 2-119
  - IEZ11 • *LIO*, 2-119
  - IOtech Micro488A • *LIO*, 2-120
  - KWV11-C • *LIO*, 2-2
  - memory queue • *LIO*, 2-151
  - Preston • *LIO*, 2-62
  - real-time plotting • *LIO*, 2-162
  - serial line • *LIO*, 2-140
  - Simpact RTC01 • *LIO*, 2-2
  - using connect-to-interrupt I/O • *LIO*, 3-7
  - using polled I/O • *LIO*, 3-7
  - using QIOs • *LIO*, 3-7
- Attribute list
- See Plotting attribute list
- Attribute table definition files • *LGP*, 1-13, 2-1
- Audience
- of document • *LGP*, ix
  - of guide • *INSTALL*, vii
- Audience of manual • *LIO*, xix
- Authorize Utility • *INSTALL*, 5-5
- Autocorrelation function • *LSP*, 6-11
- definition • *LSP*, 2-7
  - mathematical equation • *LSP*, 2-7
  - references • *LSP*, 2-8
- AUTOGEN procedure • *INSTALL*, 5-4
- Autoscaling • *IDAT*, 2-16
- algorithm
    - used in a linear plot • *LGP*, 4-108
    - used in a logarithmic plot • *LGP*, 4-111
  - LGP\_AUTOSCALE.FOR* sample program • *LGP*, 6-2
- Autoscaling Option screen • *IDAT*, 2-16

- Auxiliary command • *LIO*, 4-26
- Axes Labels screen • *IDAT*, 2-15
- Axis coordinates • *IDAT*, 2-39, 2-40
- Axis system • *LGP*, 4-59
- AXV11-C • *LIO*, 2-49 to 2-54
  - A/D channel gains • *LIO*, 4-17
  - A/D channels • *LIO*, 4-13, 4-176
  - A/D channels and channel gains • *IDAT*, 2-10
  - AST routines • *LIO*, 4-22
  - asynchronous input • *LIO*, 4-24
  - attaching • *LIO*, 2-49
  - buffer forwarding • *LIO*, 4-143
  - connecting the CTI driver • *LIO*, B-1
  - connect-to-interrupt I/O • *LIO*, B-1 to B-5
  - CTI buffer and event flag • *LIO*, 4-75
  - CTI handler overhead • *LIO*, 4-78
  - D/A channels • *IDAT*, 2-29; *LIO*, 4-89, 4-179
  - device event flag • *LIO*, 4-97
  - KWV11-C clock rate • *IDAT*, 2-20, 3-11
  - number of samples • *IDAT*, 2-10
  - parameters valid for • *LIO*, 2-50
  - reconnecting the QIO driver • *LIO*, B-5
  - reloading the QIO driver • *LIO*, B-5
  - selecting A/D channels for output to the D/A • *IDAT*, 2-28, 2-33
  - setting up • *LIO*, 2-50
  - synchronous input • *LIO*, 4-239
  - timeout • *LIO*, 4-245
  - trigger modes • *IDAT*, 2-38, 3-11; *LIO*, 4-253

---

## B

---

- Backup
- system disk • *INSTALL*, 4-2, 4-5
- Backup Utility • *GETSTART*, 2-43
- BASIC program development • *GETSTART*, 3-21
- checking routine call status • *GETSTART*, 3-28
  - declaring and dimensioning arrays • *GETSTART*, 3-24
  - declaring data types and variables • *GETSTART*, 3-23
  - declaring external routines • *GETSTART*, 3-25
  - defaulting routine call arguments • *GETSTART*, 3-26
  - including symbolic definition files • *GETSTART*, 3-22
  - using COMMON statements • *GETSTART*, 3-24



- Batch queue • *INSTALL*, 5-3
- Batch queues
  - deleting • *GETSTART*, 2-22
  - restarting • *GETSTART*, 2-21
  - setting up • *GETSTART*, 2-19
  - showing status • *GETSTART*, 2-24
  - stopping • *GETSTART*, 2-22
- Baud rate
  - setting • *LIO*, 4-29
- Beginning an IDAT session • *IDAT*, 1-6
- Bit mask • *LGP*, 1-12
- Bit precision • *IDAT*, 2-17
- Bit Precision Specification screen • *IDAT*, 2-17
- Bivariate Gaussian curves
  - LGP\_CONTOUR.FOR sample program • *LGP*, 6-2
  - LGP\_PLOT\_3D.FOR sample program • *LGP*, 6-5
  - LGP\_PLOT\_CONTOUR.FOR sample program • *LGP*, 6-4
  - LGP\_SHADE\_CONTOUR.FOR sample program • *LGP*, 6-5
- Board
  - See Device
- Break condition • *LIO*, 4-36
- Buffer dequeuing • *LIO*, 1-9
- Buffer forwarding • *LIO*, 1-10, 4-143
- Buffer-handling mechanisms
  - AST routines • *LIO*, 1-11 to 1-13
  - buffer forwarding • *LIO*, 1-10
  - dequeuing • *LIO*, 1-9
- Buffers
  - allocating dynamically • *LIO*, 2-153
  - page-aligning • *LIO*, 4-185
- Buffer size
  - setting • *LIO*, 4-37
- Buffer source
  - specifying • *LIO*, 4-39
- Burst rate
  - specifying for Preston • *LIO*, 4-43

---

## C

---

- Calls
  - summary of • *LGP*, 4-1
- CARRIER signal • *LIO*, 4-173
- CGM metafile • *LGP*, 2-10
- Changing account passwords • *GETSTART*, 2-14
- Changing plotting logical names • *LGP*, 4-5
- Channel Selection screen • *IDAT*, 2-18
- Character output • *LGP*, 1-19
- Checking routine call status • *LIO*, 5-2
  - in Ada programs • *GETSTART*, 3-11
  - in BASIC programs • *GETSTART*, 3-28
  - in C programs • *GETSTART*, 3-40
  - in FORTRAN programs • *GETSTART*, 3-52
  - in PASCAL programs • *GETSTART*, 3-64
- Clearing screens
  - plotting screen • *LGP*, 4-146
  - screen • *LGP*, 4-29
  - workstation window • *LGP*, 4-29
- Clock
  - ADQ32 • *LIO*, 2-38
  - divider
    - specifying • *LIO*, 4-55, 4-58
    - specifying for the Preston • *LIO*, 4-53
  - IDV11-D • *LIO*, 2-104
  - KWV11-C • *LIO*, 2-1
  - rate
    - specifying • *LIO*, 4-55
  - setting up function • *LIO*, 4-145
  - Simpact RTC01 • *LIO*, 2-1
  - source
    - specifying • *LIO*, 4-58
- Clock Function Selection screen • *IDAT*, 2-19
- Clock Rate Selection screen • *IDAT*, 2-20
- Clock Source Selection screen • *IDAT*, 2-21
- Clock Trigger Selection screen • *IDAT*, 2-22
- Closing open workstations • *LGP*, 4-146
- Cluster operations • *INSTALL*, 1-4
- Command Output (COUT) bit • *LIO*, 4-63
- Compiling program source code • *GETSTART*, 3-2
- Components
  - of LGP • *LGP*, 1-1
- Condition values
  - LGP • *LGP*, 5-1

## Condition values (Cont.)

- LSP • *LSP*, 7-3
- Configuring DECnet • *GETSTART*, 2-25
- Connect-to-interrupt (CTI) I/O
  - handler overhead • *LIO*, 4-78
  - setting up • *LIO*, 4-75
- Connect-to-interrupt I/O • *LIO*, 1-7
- Contact bounce elimination • *LIO*, 4-34
- Continuous DMA • *LIO*, 1-21 to 1-25, 4-70
  - stopping • *LIO*, 4-45
- Contour plotting • *LGP*, 4-8, 4-16, 4-24
- Control keys • *IDAT*, 1-16
- Control Table Address (CTA) register
  - loading • *LIO*, 4-74
- Conventions
  - documentation • *LIO*, xxiii; *INSTALL*, ix
  - of document • *LGP*, xii
- Coordinates • *LGP*, 1-16
- Copying data
  - using the memory queue • *LIO*, 2-157
- Correlation function • *LSP*, 6-11
  - definition • *LSP*, 2-7
  - mathematical equation • *LSP*, 2-7
  - references • *LSP*, 2-8
- Counting external events
  - using the IDV11-D • *LIO*, 2-105
  - using the Simpact RTC01 • *LIO*, 2-9
- Count register
  - reading • *LIO*, 4-72
- COUT bit • *LIO*, 4-63
- C program development • *GETSTART*, 3-33
  - checking routine call status • *GETSTART*, 3-40
  - declaring and dimensioning arrays • *GETSTART*, 3-37
  - declaring data types and variables • *GETSTART*, 3-35
  - declaring external routines • *GETSTART*, 3-38
  - defaulting routine call arguments • *GETSTART*, 3-38
  - including symbolic definition files • *GETSTART*, 3-34
- Creating
  - axis system • *LGP*, 4-59
  - hardcopy plots • *LGP*, 4-100
  - linear coordinate system • *LGP*, 4-68
  - logarithmic axis system • *LGP*, 4-68
  - multiple plots • *LGP*, 3-1 to 3-8
    - example of • *LGP*, 3-4

- Creating program source code • *GETSTART*, 3-1
- CTA register
  - loading • *LIO*, 4-74
- CTS signal • *LIO*, 4-173

---

## D

---

- D/A converters
  - AAF01 • *LIO*, 2-12 to 2-22
  - AAV11-D • *LIO*, 2-22 to 2-27
  - AXV11-C • *LIO*, 2-49 to 2-54
  - IAV11-B • *LIO*, 2-95 to 2-98
- DAC Data Register • *LIO*, 4-32
- Data analysis
  - power spectrum • *IDAT*, 1-3, 3-27
  - selecting power spectrum option • *IDAT*, 2-6
- Data Analysis Menu • *IDAT*, 2-6
- Data bits
  - establishing • *LIO*, 4-33
- Data devices
  - producing a multiple channel plot • *IDAT*, 3-42
  - producing a single channel plot • *IDAT*, 3-48
  - selecting input devices • *IDAT*, 2-3
  - using a disk file for input • *IDAT*, 3-12
  - using a disk file for output • *IDAT*, 3-35
  - using an RS/1 file for output • *IDAT*, 3-46
  - using the AAV11-D for output • *IDAT*, 3-29
  - using the ADQ32 for input • *IDAT*, 3-2
  - using the ADV11-D for input • *IDAT*, 3-6
  - using the AXV11-C for input • *IDAT*, 3-9
  - using the AXV11-C for output • *IDAT*, 3-32
  - using the DRB32 for input • *IDAT*, 3-13
  - using the DRB32 for output • *IDAT*, 3-36
  - using the DRQ3B for input • *IDAT*, 3-15
  - using the DRQ3B for output • *IDAT*, 3-37
  - using the DRV11-J for input • *IDAT*, 3-17
  - using the DRV11-J for output • *IDAT*, 3-38
  - using the DRV11-WA for input • *IDAT*, 3-20
  - using the DRV11-WA for output • *IDAT*, 3-40
  - using the Preston for input • *IDAT*, 3-24
- Data entry screens
  - conventions for use • *IDAT*, 1-8
  - generic screen layout • *IDAT*, 1-11
- Data format translation • *LSP*, 1-3
  - analog-to-digital • *IDAT*, 1-3
  - digital-to-analog • *IDAT*, 1-3

- Data Length Specification screen • *IDAT*, 2-23
- Data output
  - selecting output destinations • *IDAT*, 2-7
- Data plotting • *IDAT*, 1-4
  - assigning logical names • *IDAT*, 1-4, 4-4
- Data set • *LGP*, 4-59
- Data translation
  - analog-to-digital • *LSP*, 6-38
  - digital-to-analog • *LSP*, 6-41
- DDR
  - See DAC Data Register
- Deallocating a device • *GETSTART*, 2-40
- Deallocating devices • *LIO*, 3-13
- Debugging programs • *GETSTART*, 3-3
- DEC GKS
  - See GKS
- Declaring and dimensioning arrays
  - in Ada programs • *GETSTART*, 3-7
  - in BASIC programs • *GETSTART*, 3-24
  - in C programs • *GETSTART*, 3-37
  - in FORTRAN programs • *GETSTART*, 3-48
  - in PASCAL programs • *GETSTART*, 3-61
- Declaring data types and variables
  - in Ada programs • *GETSTART*, 3-6
  - in BASIC programs • *GETSTART*, 3-23
  - in C programs • *GETSTART*, 3-35
  - in FORTRAN programs • *GETSTART*, 3-47
  - in PASCAL programs • *GETSTART*, 3-59
- Declaring external routines
  - in Ada programs • *GETSTART*, 3-9
  - in BASIC programs • *GETSTART*, 3-25
  - in C programs • *GETSTART*, 3-38
  - in FORTRAN programs • *GETSTART*, 3-50
  - in PASCAL programs • *GETSTART*, 3-62
- DECnet management tasks
  - adding a node to DECnet • *GETSTART*, 2-27
  - configuring DECnet • *GETSTART*, 2-25
  - listing DECnet nodes • *GETSTART*, 2-31
  - removing a node from DECnet • *GETSTART*, 2-29
  - turning DECnet on or off • *GETSTART*, 2-30
- DECwindows
  - using LGP with • *LGP*, 1-8, 4-7
- DECwindows workstation types • *LGP*, 1-7, 1-8, 4-7
- Default axis lengths • *LGP*, 1-7

- Defaulting routine call arguments
  - in Ada programs • *GETSTART*, 3-10
  - in BASIC programs • *GETSTART*, 3-26
  - in C programs • *GETSTART*, 3-38
  - in FORTRAN programs • *GETSTART*, 3-50
  - in PASCAL programs • *GETSTART*, 3-62
- Defining logical names • *LGP*, 1-9
  - example of • *LGP*, 1-11
  - for foreign device support • *LGP*, 1-12
- Deleting a batch queue • *GETSTART*, 2-22
- Deleting a print queue • *GETSTART*, 2-17
- Deleting a user account • *GETSTART*, 2-11
- Dequeuing buffers
  - from the free queue • *LIO*, 3-12
  - from the user queue • *LIO*, 3-12
- Detaching devices • *LIO*, 3-13
- Device
  - DRQ11-C • *INSTALL*, 4-7
  - European • *INSTALL*, 4-7, 4-9
  - IEQ11 • *INSTALL*, 4-7
  - IXV11 • *INSTALL*, 4-7, 4-9
- Device capabilities • *LGP*, 1-14
- Device driver
  - DRQ11-C • *INSTALL*, 5-6
  - IEQ11 • *INSTALL*, 4-7, 5-6
  - IXV11 • *INSTALL*, 5-6
- Device management tasks
  - allocating a device • *GETSTART*, 2-38
  - deallocating a device • *GETSTART*, 2-40
  - dismounting a device • *GETSTART*, 2-36
  - initializing a device • *GETSTART*, 2-34
  - mounting a device • *GETSTART*, 2-32
  - showing device status • *GETSTART*, 2-41
- Device queue • *LIO*, 1-3
- Devices
  - analog I/O • *LIO*, 2-12 to 2-67
  - creating multiple plots on • *LGP*, 3-4 to 3-8
  - digital I/O • *LIO*, 2-67 to 2-104
  - supported • *LGP*, 1-6 to 1-8
- Device specifications
  - listing of • *LIO*, 3-4
- Device symbols • *INSTALL*, 5-6
- Digital devices
  - DRB32 • *IDAT*, 1-2
  - DRQ3B • *IDAT*, 1-2
  - DRV11-J • *IDAT*, 1-2
  - DRV11-WA • *IDAT*, 1-2
- Digital filtering

## Digital filtering (Cont.)

- definition • *LSP*, 3-1
- LSP\$APPLY\_WINDOW\_TABLE* routine • *LSP*, 6-5
- LSP\$BUILD\_WINDOW\_TABLE* routine • *LSP*, 6-8
- LSP\$SPECTRAL\_WINDOWS* routine • *LSP*, 6-62
- nonrecursive filtering • *LSP*, 3-3
- polynomials • *LSP*, 3-1
- references • *LSP*, 3-13
- spectral window filtering • *LSP*, 4-2

## Digital I/O devices • *LIO*, 2-67 to 2-104

- DRB32* • *LIO*, 2-67 to 2-74
- DRB32W* • *LIO*, 2-74 to 2-77
- DRQ3B* • *LIO*, 2-78 to 2-82
- DRV11-J* • *LIO*, 2-83 to 2-86
- DRV11-WA* • *LIO*, 2-86 to 2-89
- IDV11-A* • *LIO*, 2-98 to 2-101
- IDV11-B* • *LIO*, 2-101 to 2-104
- IDV11-C* • *LIO*, 2-101

## Digital input devices

- IDV11-A* • *LIO*, 2-98 to 2-101

## Digital output devices

- IDV11-B* • *LIO*, 2-101 to 2-104
- IDV11-C* • *LIO*, 2-101

## Digital-to-analog converters

- See *D/A* converters

## Digital-to-analog data translation • *LSP*, 6-41

## Direct memory access • *LIO*, 1-19 to 1-28

- alternate-buffer DMA • *LIO*, 1-25
- continuous • *LIO*, 1-21
- continuous DMA • *LIO*, 4-70
  - starting • *LIO*, 4-230
  - stopping • *LIO*, 4-235
- double-buffer DMA • *LIO*, 1-26
  - enabling • *LIO*, 4-95
- page-aligning buffers • *LIO*, 1-24
- single-buffer DMA • *LIO*, 1-19, 4-223
- with QIOs • *LIO*, 1-6
- word-aligning buffers • *LIO*, 1-19

## Discrete Fourier transform

- definition • *LSP*, 2-3
- mathematical equation • *LSP*, 2-3

## Disk file device • *LIO*, 2-146 to 2-150

- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24

## Disk file device (Cont.)

- attaching • *LIO*, 2-147
- buffer forwarding • *LIO*, 4-143
- device event flag • *LIO*, 4-97
- extending output file size • *LIO*, 4-133
- file name • *LIO*, 4-180
- I/O direction • *LIO*, 4-101
- opening • *LIO*, 4-182
- output file size • *LIO*, 4-138
- parameters valid for • *LIO*, 2-147
- remaining blocks in an output file • *LIO*, 4-136
- repositioning block pointer • *LIO*, 4-135
- setting up • *LIO*, 2-147
- synchronous I/O • *LIO*, 4-239

## Disk files

- file names • *IDAT*, 2-24

## Dismounting a device • *GETSTART*, 2-36

## Displaying a list of user accounts • *GETSTART*, 2-10

## Displaying data

- using the memory queue • *LIO*, 2-157

## DMA

- See Direct memory access

## Document

- audience • *LGP*, ix
- structure • *LGP*, ix

## Documentation conventions • *INSTALL*, ix

## Document conventions • *LGP*, xii

## Documents

- associated • *LGP*, x; *INSTALL*, viii
- associated hardware • *LIO*, xxii
- associated software • *LIO*, xxi
- associated VAXlab • *LIO*, xxi
- structure • *INSTALL*, vii

## Double-buffer DMA • *LIO*, 1-26 to 1-28

- pointer sequence • *LIO*, 1-26

## **DOWNARROW** key • *IDAT*, 1-8

## *DRB32* • *LIO*, 2-67 to 2-74

- AST routines • *LIO*, 4-22, 4-81
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-68
- buffer forwarding • *LIO*, 4-143
- buffer locking • *LIO*, 4-166
- data length • *IDAT*, 3-15
- data transfers without DMA • *LIO*, 4-91
- device event flag • *LIO*, 4-97
- function bits • *LIO*, 4-148
- I/O direction • *LIO*, 4-101

## DRB32 (Cont.)

- locking buffers • *LIO*, 4-166
- loopback mode • *LIO*, 4-168
- parallel data path width • *LIO*, 4-94
- parameters valid for • *LIO*, 2-68
- parity • *LIO*, 4-193
- setting up • *LIO*, 2-68
- synchronous I/O • *LIO*, 4-239
- timeout • *LIO*, 4-245
- unlock buffers • *LIO*, 4-266

## DRB32W • *LIO*, 2-74 to 2-77

- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-74
- buffer forwarding • *LIO*, 4-143
- device event flag • *LIO*, 4-97
- I/O direction • *LIO*, 4-101
- parameters valid for • *LIO*, 2-75
- setting up • *LIO*, 2-75
- synchronous I/O • *LIO*, 4-239
- timeout • *LIO*, 4-245

## DRQ11-C • *LIO*, 2-54 to 2-61

- alternate-buffer DMA • *LIO*, 1-25
- AST routines • *LIO*, 4-104
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-55
- buffered data path • *LIO*, 4-92
- clearing large buffer overflow • *LIO*, 4-61
- continuous DMA • *LIO*, 1-21
- direct data path • *LIO*, 4-92
- event ASTs • *LIO*, 4-121
- function bits • *LIO*, 4-148
- parameters valid for • *LIO*, 2-55
- resetting DMA interface • *LIO*, 4-215
- returning hardware register contents • *LIO*, 4-106
- returning status information • *LIO*, 4-233
- setting up • *LIO*, 2-55
- single-buffer DMA • *LIO*, 1-20
- stopping continuous DMA • *LIO*, 4-45
- synchronous I/O • *LIO*, 4-239
- timeout • *LIO*, 4-245

## DRQ11-C device driver • *INSTALL*, 5-6

## DRQ3B • *LIO*, 2-78 to 2-82

- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-78
- buffer forwarding • *LIO*, 4-143

## DRQ3B (Cont.)

- buffer size • *LIO*, 4-37
- data length • *IDAT*, 2-23, 3-16
- device event flag • *LIO*, 4-97
- double-buffer DMA • *LIO*, 1-27
- FIFO buffers • *LIO*, 1-16
- function bits • *LIO*, 4-148
- handshaking • *LIO*, 1-17
- parameters valid for • *LIO*, 2-79
- setting up • *LIO*, 2-79
- stopping continuous DMA • *LIO*, 4-235
- synchronous I/O • *LIO*, 4-239

## DRV11-J • *LIO*, 2-83 to 2-86

- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-83
- buffer forwarding • *LIO*, 4-143
- data length • *IDAT*, 2-23, 3-19
- device event flag • *LIO*, 4-97
- disabling handshaking • *IDAT*, 2-25, 3-19
- enabling handshaking • *IDAT*, 2-25, 3-19
- event ASTs • *LIO*, 4-121
- external event flags • *LIO*, 4-125
- handshaking • *LIO*, 1-18, 4-156
- I/O direction • *LIO*, 4-101
- output • *IDAT*, 3-38
- parameters valid for • *LIO*, 2-84
- polarity • *LIO*, 4-202
- port specification • *IDAT*, 2-31, 3-19, 3-40
- setting up • *LIO*, 2-84
- synchronous I/O • *LIO*, 4-239
- timeout • *LIO*, 4-245

## DRV11-WA • *LIO*, 2-86 to 2-89

- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-87
- buffer forwarding • *LIO*, 4-143
- data length • *IDAT*, 2-23
- device event flag • *LIO*, 4-97
- handshaking • *LIO*, 1-18
- I/O direction • *LIO*, 4-101
- output • *IDAT*, 3-40
- parameters valid for • *LIO*, 2-87
- setting up • *LIO*, 2-87
- synchronous I/O • *LIO*, 4-239
- timeout • *LIO*, 4-245

## DSR/DTR • *LIO*, 4-139

- DSR signal • *LIO*, 4-173

DTR signal • *LIO*, 4-173

---

## E

---

### Editing files

startup command files • *INSTALL*, 5-2

### EK device

See *IEZ11*

end-or-identify (EOI) line • *LIO*, 4-116

Enqueueing buffers • *LIO*, 3-15

Entering a DCL command from *MANAGER* •

*GETSTART*, 2-14

Entering data on data entry screens • *IDAT*, 1-10

Entering new parameter values • *IDAT*, 1-10

Environment files • *GETSTART*, 3-58

### EOI

using to terminate write requests • *LIO*, 2-139

EOI line • *LIO*, 4-116

### Error code

symbolic status definition files • *LGP*, 1-13

Error handling • *LIO*, 5-1

#### parity

for serial line devices • *LIO*, 4-120

symbolic status definition files

list of • *LIO*, 5-2

Error messages • *LGP*, 5-4 to 5-18; *LIO*, 5-6 to 5-27

checking routine call status • *LGP*, 5-2; *LSP*, 7-2

explanation and user action • *LSP*, 7-3

*LSP* • *LSP*, 7-1

overview of • *LGP*, 5-1

symbolic status definition files • *LSP*, 7-2

Error recovery • *IDAT*, 1-14

European installation

See *Installation*

Event ASTs • *LIO*, 4-121 to 4-124

Event flag

setting on external event • *LIO*, 4-125

Event timing

setting source frequency • *LIO*, 4-58

Example programs

See *Online sample programs*

*LIO* • *INSTALL*, 4-8

Executing *IDAT* • *IDAT*, 1-6

Executing programs • *GETSTART*, 3-3

Executing *VSL* routines • *IDAT*, 2-35, 2-36

Exit conditions • *LGP*, 1-20

Exiting *IDAT* • *IDAT*, 1-16

using the **CTRL/Y** • *IDAT*, 1-16

using the **EXIT** option • *IDAT*, 1-16

Exiting *LGP* • *LGP*, 1-20

External gating

setting up • *LIO*, 4-153

---

## F

---

### Fast Fourier transform

in two dimensions • *LSP*, 2-5

mathematical equation • *LSP*, 2-3

of real-valued data • *LSP*, 6-20

reduced-symmetric storage • *LSP*, 2-5

references • *LSP*, 2-8

FIFOs • *LIO*, 1-16

### File devices

input • *IDAT*, 1-2

output • *IDAT*, 1-2

File names • *IDAT*, 2-24

File Name Specification screen • *IDAT*, 2-24

First-in/first-out buffers • *LIO*, 1-16

### Flowchart

installation decision • *INSTALL*, 1-1

### Flow control

for serial line device • *LIO*, 4-139, 4-141

FNCT0 bit • *LIO*, 4-215

Foreign device support • *LGP*, 1-12

### Format

of *LGP* routines • *LGP*, 4-4

FORTTRAN program development • *GETSTART*, 3-45

checking routine call status • *GETSTART*, 3-52

declaring and dimensioning arrays •

*GETSTART*, 3-48

declaring data types and variables •

*GETSTART*, 3-47

declaring external routines • *GETSTART*, 3-50

defaulting routine call arguments • *GETSTART*, 3-50

including symbolic definition files • *GETSTART*, 3-46

Forward Fourier transform

definition • *LSP*, 2-1

of complex-valued data • *LSP*, 6-14

Forward Fourier transform (Cont.)  
of complex-valued data in two dimensions •  
*LSP*, 6-17

## FOUT

See Frequency Output (FOUT)  
Frequency Output (FOUT) • *LIO*, 4-46  
Function bits  
setting • *LIO*, 4-148

---

## G

GBLPAGES • *INSTALL*, 4-3  
GBLSECTIONS • *INSTALL*, 4-3  
Generating output frequencies  
using the IDV11-D • *LIO*, 2-113  
Generating output pulses  
using the IDV11-D • *LIO*, 2-112  
Getting plotting status information • *LGP*, 4-55  
Gibbs Phenomenon • *LSP*, 3-6  
GKS  
installing • *INSTALL*, 4-2  
logical names • *INSTALL*, 5-3  
GKS\$CONID • *INSTALL*, 5-3  
GKS\$WSTYPE • *INSTALL*, 5-3  
operating states • *LGP*, 1-18  
using with LGP • *LGP*, 1-15  
warning message • *INSTALL*, 4-11  
GKS\$CONID • *IDAT*, 1-4, 4-4; *LGP*, 1-9 to  
1-11, 4-6  
GKS\$WSTYPE • *IDAT*, 1-4, 4-4; *LGP*, 1-9, 4-6  
GKS operating states • *LGP*, 1-18  
Graph  
setting up • *LGP*, 4-115  
Graphics  
overview • *LGP*, 1-1  
Graphics devices  
See Devices  
Graphics terminal types  
supported • *INSTALL*, 4-8  
Graph titles • *IDAT*, 2-15, 2-16

---

## H

Handshake Enable/Disable screen • *IDAT*, 2-25  
Handshaking • *IDAT*, 2-25; *LIO*, 1-16 to 1-18  
Hardcopy output • *LGP*, 4-100  
Hierarchy of operations • *LGP*, 1-4  
Histogram  
LGP\_ERASE.C sample program • *LGP*, 6-2  
LGP\_GKS.FOR sample program • *LGP*, 6-3  
LGP\_INFO.FOR sample program • *LGP*, 6-3  
LGP\_PLOT\_HIST.FOR sample program • *LGP*,  
6-4  
HP7550 plotter • *LGP*, 4-57  
plotting capabilities • *LGP*, 1-14

---

## I

I/O devices  
See Devices  
I/O interfaces  
asynchronous • *LIO*, 1-3  
device-specific • *LIO*, 1-14 to 1-28  
DMA • *LIO*, 1-19  
FIFOs • *LIO*, 1-16  
handshaking • *LIO*, 1-16  
summary of devices • *LIO*, 1-5  
synchronous • *LIO*, 1-2  
I/O operations  
connect-to-interrupt • *LIO*, 1-7  
interrupt-driven I/O • *LIO*, 1-7  
memory-mapped I/O • *LIO*, 1-7  
polled I/O • *LIO*, 1-7  
QIOs to a device driver • *LIO*, 1-6  
I/O routines  
LIO\$ATTACH • *LIO*, 3-3 to 3-7  
LIO\$DEQUEUE • *LIO*, 3-8 to 3-12  
LIO\$DETACH • *LIO*, 3-13 to 3-14  
LIO\$ENQUEUE • *LIO*, 3-15 to 3-23  
LIO\$READ • *LIO*, 3-24 to 3-28  
LIO\$SET\_I • *LIO*, 3-29 to 3-30  
LIO\$SET\_R • *LIO*, 3-31 to 3-32  
LIO\$SET\_S • *LIO*, 3-33 to 3-34  
LIO\$SHOW • *LIO*, 3-35 to 3-36  
LIO\$WRITE • *LIO*, 3-37 to 3-40  
I/O types  
listing of • *LIO*, 3-4

IAV11-A • *LIO*, 2-90 to 2-95  
 A/D channels • *LIO*, 4-176  
 AST routines • *LIO*, 4-22  
 asynchronous input • *LIO*, 4-24  
 attaching • *LIO*, 2-91  
 buffer forwarding • *LIO*, 4-143  
 device event flag • *LIO*, 4-97  
 parameters valid for • *LIO*, 2-92  
 setting up • *LIO*, 2-92  
 synchronous input • *LIO*, 4-239

IAV11-AA • *LIO*, 2-90  
 A/D channels • *LIO*, 4-176  
 AST routines • *LIO*, 4-22  
 asynchronous input • *LIO*, 4-24  
 attaching • *LIO*, 2-91  
 buffer forwarding • *LIO*, 4-143  
 device event flag • *LIO*, 4-97  
 synchronous input • *LIO*, 4-239

IAV11-B • *LIO*, 2-95 to 2-98  
 AST routines • *LIO*, 4-22  
 asynchronous output • *LIO*, 4-24  
 attaching • *LIO*, 2-96  
 buffer forwarding • *LIO*, 4-143  
 device event flag • *LIO*, 4-97  
 parameters valid for • *LIO*, 2-96  
 setting up • *LIO*, 2-96  
 synchronous output • *LIO*, 4-239

IAV11-C • *LIO*, 2-91  
 A/D channels • *LIO*, 4-176  
 AST routines • *LIO*, 4-22  
 asynchronous input • *LIO*, 4-24  
 attaching • *LIO*, 2-91  
 buffer forwarding • *LIO*, 4-143  
 device event flag • *LIO*, 4-97  
 synchronous input • *LIO*, 4-239

IAV11-CA • *LIO*, 2-91  
 A/D channels • *LIO*, 4-176  
 AST routines • *LIO*, 4-22  
 asynchronous input • *LIO*, 4-24  
 attaching • *LIO*, 2-91  
 buffer forwarding • *LIO*, 4-143  
 device event flag • *LIO*, 4-97  
 synchronous input • *LIO*, 4-239

IDAT • *INSTALL*, 5-3  
 A/D Samples and Channel Gains screen •  
*IDAT*, 2-12

## IDAT (Cont.)

A/D Samples and Channels screen • *IDAT*,  
 2-10  
 accepting default values • *IDAT*, 1-10  
 assigning logical names • *IDAT*, 1-4  
 Autoscaling Option screen • *IDAT*, 2-16  
 Axes Labels screen • *IDAT*, 2-15  
 beginning a session • *IDAT*, 1-6  
 Bit Precision Specification screen • *IDAT*,  
 2-17  
 Channel Selection screen • *IDAT*, 2-18  
 Clock Function Selection screen • *IDAT*, 2-19  
 Clock Rate Selection screen • *IDAT*, 2-20  
 Clock Source Selection screen • *IDAT*, 2-21  
 Clock Trigger Selection screen • *IDAT*, 2-22  
 data analysis • *IDAT*, 1-3  
 Data Analysis Menu • *IDAT*, 2-6  
 data devices • *IDAT*, 1-2  
 data format translation • *IDAT*, 1-3  
 Data Length Specification screen • *IDAT*, 2-23  
 data plotting • *IDAT*, 1-4  
 entering data on screen forms • *IDAT*, 1-10  
 entering new parameter values • *IDAT*, 1-10  
 executing • *IDAT*, 1-6  
 File Name Specification screen • *IDAT*, 2-24  
 Handshake Enable/Disable screen • *IDAT*,  
 2-25  
 Input Channel Selection screen • *IDAT*, 2-27  
 Input Source Menu • *IDAT*, 2-3  
 internal buffer • *IDAT*, 1-6  
 Main Menu • *IDAT*, 2-2  
 Multiple Input Channel Selection screen •  
*IDAT*, 2-28  
 Output Channel Selection screen • *IDAT*, 2-29  
 Output Destination Menu • *IDAT*, 2-7  
 Point Size Specification screen • *IDAT*, 2-30  
 Port Specification screen • *IDAT*, 2-31  
 Preston Trigger Mode Selection screen • *IDAT*,  
 2-32  
 running • *IDAT*, 1-6  
 running the executable image • *IDAT*, 1-6  
 screen forms interface • *IDAT*, 1-7  
 selecting options from menus • *IDAT*, 1-8  
 Single Input Channel Selection screen • *IDAT*,  
 2-33  
 Sweep Clock Rate Selection screen • *IDAT*,  
 2-37  
 Trigger Mode Selection screen • *IDAT*, 2-38



## IDAT (Cont.)

- using the **DOWNARROW** key • *IDAT*, 1-8
- using the **UPARROW** key • *IDAT*, 1-8
- X-Axis Coordinates screen • *IDAT*, 2-39
- Y-Axis Coordinates screen • *IDAT*, 2-40

## IDAT data analysis

- performing a power spectrum • *IDAT*, 3-27

## IDAT data devices

- producing a multiple channel plot • *IDAT*, 3-42
- producing a single channel plot • *IDAT*, 3-48
- using a disk file for input • *IDAT*, 3-12
- using a disk file for output • *IDAT*, 3-35
- using an RS/1 file for output • *IDAT*, 3-46
- using DRB32 for input • *IDAT*, 3-13
- using the AAV11-D for output • *IDAT*, 3-29
- using the ADQ32 for input • *IDAT*, 3-2
- using the ADV11-D for input • *IDAT*, 3-6
- using the AXV11-C for input • *IDAT*, 3-9
- using the AXV11-C for output • *IDAT*, 3-32
- using the DRB32 for output • *IDAT*, 3-36
- using the DRQ3B for input • *IDAT*, 3-15
- using the DRQ3B for output • *IDAT*, 3-37
- using the DRV11-J for input • *IDAT*, 3-17
- using the DRV11-J for output • *IDAT*, 3-38
- using the DRV11-WA for input • *IDAT*, 3-20
- using the DRV11-WA for output • *IDAT*, 3-40
- using the Preston for input • *IDAT*, 3-24

## IDAT pass • *IDAT*, 1-6

## IDAT session • *IDAT*, 1-6

## IDV11-A • *LIO*, 2-98 to 2-101

- AST routines • *LIO*, 4-22
- asynchronous input • *LIO*, 4-24
- attaching • *LIO*, 2-99
- buffer forwarding • *LIO*, 4-143
- contact bounce elimination response time • *LIO*, 4-34
- device event flag • *LIO*, 4-97
- event ASTs • *LIO*, 4-121
- parameters valid for • *LIO*, 2-99
- polarity • *LIO*, 4-202
- setting up • *LIO*, 2-99
- synchronous input • *LIO*, 4-239
- voltage range • *LIO*, 4-278

## IDV11-B • *LIO*, 2-101 to 2-104

- AST routines • *LIO*, 4-22
- asynchronous output • *LIO*, 4-24
- attaching • *LIO*, 2-101

## IDV11-B (Cont.)

- buffer forwarding • *LIO*, 4-143
- device event flag • *LIO*, 4-97
- parameters valid for • *LIO*, 2-102
- setting up • *LIO*, 2-102
- synchronous output • *LIO*, 4-239

## IDV11-C • *LIO*, 2-101

- AST routines • *LIO*, 4-22
- asynchronous output • *LIO*, 4-24
- buffer forwarding • *LIO*, 4-143
- device event flag • *LIO*, 4-97
- synchronous output • *LIO*, 4-239

## IDV11-D

- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-104
- buffer forwarding • *LIO*, 4-143
- counter channel setup • *LIO*, 4-48
- device event flag • *LIO*, 4-97
- frequency output reference signal • *LIO*, 4-46
- parameters valid for • *LIO*, 2-105
- setting up • *LIO*, 2-105
- starting counter channels • *LIO*, 4-230
- stopping counter channels • *LIO*, 4-235
- synchronous I/O • *LIO*, 4-239

## IDV11-D real-time counter • *LIO*, 2-104 to 2-114

## IEEE-488

- auxiliary commands • *LIO*, 4-26
- bus address
  - setting up • *LIO*, 4-159
- commands • *LIO*, 4-64 to 4-69
- termination characters • *LIO*, 2-139

## IEEE-488 bus

- recognizing events • *LIO*, 4-127

## IEEE-488 bus event

- waiting for • *LIO*, 4-131

## IEEE-488 bus instruments

- parallel polling • *LIO*, 4-188

## IEEE-488 device

- parameters valid for • *LIO*, 2-120

## IEEE-488 devices • *LIO*, 2-114 to 2-139

## IEQ11 • *LIO*, 2-115

- activating controller function • *LIO*, 4-79
- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-119
- auxiliary commands • *LIO*, 4-26
- buffer forwarding • *LIO*, 4-143

## IEQ11 (Cont.)

- configuring for parallel polling • *LIO*, 4-188
- configuring for serial polling • *LIO*, 4-221
- controller-standby state • *LIO*, 4-164
- deactivating controller function • *LIO*, 4-85
- device • *INSTALL*, 4-7
- device event flag • *LIO*, 4-97
- EOI line assertion • *LIO*, 4-116
- event ASTs • *LIO*, 4-121
- IEEE-488 commands • *LIO*, 4-64
- parallel polling • *LIO*, 4-188
- parallel poll status register • *LIO*, 4-191
- passing control • *LIO*, 4-195
- primary address • *LIO*, 4-159
- recognizing IEEE-488 bus events • *LIO*, 4-127
- returning IEEE-488 bus events • *LIO*, 4-131
- returning instrument status • *LIO*, 4-186, 4-219
- secondary address • *LIO*, 4-159
- serial polling • *LIO*, 4-219
- serial poll status byte • *LIO*, 4-226
- service requests • *LIO*, 4-243
- setting up • *LIO*, 2-120
- synchronous I/O • *LIO*, 4-239
- terminating I/O with a service request • *LIO*, 4-243
- termination character • *LIO*, 4-241
- timeout • *LIO*, 4-245
- waiting for IEEE-488 bus events • *LIO*, 4-131

IEQ11 device driver • *INSTALL*, 5-6

IEZ11 • *LIO*, 2-115

- activating controller function • *LIO*, 4-79
- AST routines • *LIO*, 4-22
- asynchronous I/O • *LIO*, 4-24
- attaching • *LIO*, 2-119
- auxiliary commands • *LIO*, 4-26
- buffer forwarding • *LIO*, 4-143
- configuring for parallel polling • *LIO*, 4-188
- configuring for serial polling • *LIO*, 4-221
- deactivating controller function • *LIO*, 4-85
- device event flag • *LIO*, 4-97
- EOI line assertion • *LIO*, 4-116
- event ASTs • *LIO*, 4-121
- IEEE-488 commands • *LIO*, 4-64
- parallel polling • *LIO*, 4-188
- parallel poll status register • *LIO*, 4-191
- passing control • *LIO*, 4-195
- primary address • *LIO*, 4-159

## IEZ11 (Cont.)

- recognizing IEEE-488 bus events • *LIO*, 4-127
- returning IEEE-488 bus events • *LIO*, 4-131
- returning instrument status • *LIO*, 4-186, 4-219
- secondary address • *LIO*, 4-159
- serial polling • *LIO*, 4-219
- serial poll status byte • *LIO*, 4-226
- setting up • *LIO*, 2-120
- synchronous I/O • *LIO*, 4-239
- termination character • *LIO*, 4-241
- timeout • *LIO*, 4-245
- waiting for IEEE-488 bus events • *LIO*, 4-131
- Include file • *LIO*, 6-3
- Include files
  - error handling symbolic status • *LIO*, 5-2
- Including symbolic definition files
  - in Ada programs • *GETSTART*, 3-4
  - in BASIC programs • *GETSTART*, 3-22
  - in C programs • *GETSTART*, 3-34
  - in FORTRAN programs • *GETSTART*, 3-46
  - in PASCAL programs • *GETSTART*, 3-57
- Initializing a device • *GETSTART*, 2-34
- Input Channel Selection screen • *IDAT*, 2-27
- Input Source Menu • *IDAT*, 2-3
- Inputting a value • *LGP*, 4-46
- Installation
  - checklists • *INSTALL*, 1-2
  - European • *INSTALL*, 4-7, 4-9
  - modifying system configuration command file • *INSTALL*, 5-6
  - prerequisites • *INSTALL*, 1-2 to 1-3
  - times • *INSTALL*, 1-4
- Installation paths • *INSTALL*, 1-1
- Installation times • *INSTALL*, 1-4
- Installation Verification Procedure
  - See IVP
- Installing VAXIab
  - from the system tape cartridge • *INSTALL*, 3-1 to 3-4
  - installing the system tape • *INSTALL*, 3-3 to 3-4
  - loading a tape cartridge • *INSTALL*, 3-2
  - new VAXIab system • *INSTALL*, 2-1 to 2-2
  - preinstalled software on hard disk • *INSTALL*, 2-1 to 2-2
- Installing VSL • *INSTALL*, 4-1 to 4-13
  - in Europe • *INSTALL*, 4-7, 4-9

Installing VSL  
 in Europe (Cont.)  
   modifying system configuration command  
   file • *INSTALL*, 5-6  
   prerequisites • *INSTALL*, 4-1  
   sample IVP plot • *INSTALL*, 4-8

Instrument status  
 polling • *LIO*, 4-186

Internal buffer • *IDAT*, 1-6

Interprocess communications  
 using the memory queue • *LIO*, 2-155

Interrupt-driven I/O • *LIO*, 1-7

Interval histogram analysis  
 with floating-point input • *LSP*, 6-45  
 with integer input • *LSP*, 6-49

Inverse Fourier transform  
 definition • *LSP*, 2-2  
 mathematical equation • *LSP*, 2-3  
 of complex-valued data • *LSP*, 6-14  
 of complex-valued data in two dimensions •  
*LSP*, 6-17  
 of real-valued data • *LSP*, 6-20

IOtech Micro488A • *LIO*, 2-115  
 activating controller function • *LIO*, 4-79  
 attaching • *LIO*, 2-120  
 auxiliary commands • *LIO*, 4-26  
 configuring for parallel polling • *LIO*, 4-188  
 configuring for serial polling • *LIO*, 4-221  
 deactivating controller function • *LIO*, 4-85  
 device event flag • *LIO*, 4-97  
 device modes • *LIO*, 2-118  
 DIP switch • *LIO*, 2-118  
 EOI line assertion • *LIO*, 4-116  
 IEEE-488 commands • *LIO*, 4-64  
 parallel polling • *LIO*, 4-188  
 parallel poll status register • *LIO*, 4-191  
 passing control • *LIO*, 4-195  
 primary address • *LIO*, 4-159  
 recognizing IEEE-488 bus events • *LIO*, 4-127  
 returning IEEE-488 bus events • *LIO*, 4-131  
 returning instrument status • *LIO*, 4-186,  
 4-219  
 secondary address • *LIO*, 4-160  
 serial polling • *LIO*, 4-219  
 serial poll status byte • *LIO*, 4-226  
 setting up • *LIO*, 2-120  
 termination character • *LIO*, 4-241  
 timeout • *LIO*, 4-245

IOtech Micro488A (Cont.)  
 waiting for IEEE-488 bus events • *LIO*, 4-131  
 Isolated real-time devices • *LIO*, 2-90 to 2-114  
 IT device  
   See IOtech Micro488A  
 IVP • *INSTALL*, 4-8, 4-12  
   sample plot • *INSTALL*, 4-8, B-1  
 IX device  
   See IEQ11  
 IXV11 • *INSTALL*, 4-9  
 IXV11 device driver • *INSTALL*, 5-6  
 IXV11 devices • *LIO*, 2-90 to 2-114  
 IXV devices  
   See IXV11 devices

---

## K

KWV11-C • *LIO*, 2-1 to 2-11  
 AST routines • *LIO*, 4-22  
 asynchronous I/O • *LIO*, 4-24  
 attaching • *LIO*, 2-2  
 buffer forwarding • *LIO*, 4-143  
 clock function • *IDAT*, 2-19, 3-23; *LIO*, 4-145  
 clock rate • *IDAT*, 2-20  
 clock rate and divider • *LIO*, 4-55  
 clock source • *IDAT*, 2-21, 3-23  
 clock source and divider • *LIO*, 4-58  
 clock trigger • *IDAT*, 2-22, 3-22  
 device event flag • *LIO*, 4-97  
 event ASTs • *LIO*, 4-121  
 external event flags • *LIO*, 4-125  
 parameters valid for • *LIO*, 2-3  
 setting up • *LIO*, 2-3  
 starting the clock • *LIO*, 4-230  
 stopping the clock • *LIO*, 4-235  
 synchronous I/O • *LIO*, 4-239  
 timeout • *LIO*, 4-245  
 trigger modes • *LIO*, 4-253

---

## L

LA100 printer  
 plotting capabilities • *LGP*, 1-14  
 LA12 printer  
 plotting capabilities • *LGP*, 1-14  
 LA210 printer  
 plotting capabilities • *LGP*, 1-14

LA34 printer  
   plotting capabilities • *LGP*, 1–14  
 LA50 printer  
   plotting capabilities • *LGP*, 1–14  
 LA75 printer  
   plotting capabilities • *LGP*, 1–14  
 Labeling axes • *IDAT*, 2–15, 2–16  
 Laboratory I/O  
   overview • *LIO*, 1–1  
 Laboratory signal-processing routines  
   error messages • *LSP*, 7–1  
 Languages supported • *LIO*, 1–1  
 Large buffer overflow (LBO) • *LIO*, 4–61  
 LBO  
   See Large buffer overflow (LBO)  
 LGP  
   components • *LGP*, 1–1  
   exiting • *LGP*, 1–20  
   plotting routine hierarchy • *LGP*, 1–4  
   warning message • *INSTALL*, 4–11  
 LGP\$3D\_SIMPLE • *LGP*, 4–134  
 LGP\$CHANGE\_PLOTTING\_LOGICALS • *LGP*, 4–5  
 LGP\$CONTOUR • *LGP*, 4–8  
 LGP\$CONTOURM • *LGP*, 4–24  
 LGP\$CONTOUR\_SHADE • *LGP*, 4–16  
 LGP\$ERASE • *LGP*, 4–29  
 LGP\$GET\_CHOICE • *LGP*, 4–32  
 LGP\$GET\_LOCATOR • *LGP*, 4–36  
 LGP\$GET\_STRING • *LGP*, 4–39  
 LGP\$GET\_STROKE • *LGP*, 4–43  
 LGP\$GET\_VALUE • *LGP*, 4–46  
 LGP\$HIST • *LGP*, 4–50  
 LGP\$INFO • *LGP*, 4–55  
 LGP\$K\_ANGLE plotting attribute • *LGP*, 1–15, 2–7  
 LGP\$K\_AXISLINE\_THICKNESS plotting attribute •  
   *LGP*, 2–3  
 LGP\$K\_AXISOFFSET\_X plotting attribute • *LGP*,  
   2–4  
 LGP\$K\_AXISOFFSET\_Y plotting attribute • *LGP*,  
   2–5  
 LGP\$K\_BBORDER\_MINOR\_TICKMARK plotting  
   attribute • *LGP*, 2–9  
 LGP\$K\_BBORDER\_SIZE plotting attribute • *LGP*,  
   2–7  
 LGP\$K\_BORDER plotting attribute • *LGP*, 2–8  
 LGP\$K\_DATALINE\_THICKNESS plotting attribute  
   • *LGP*, 2–4  
 LGP\$K\_DECIMALANNOT\_X plotting attribute •  
   *LGP*, 2–2  
 LGP\$K\_DECIMALANNOT\_Y plotting attribute •  
   *LGP*, 2–3  
 LGP\$K\_ERASE\_COND plotting attribute • *LGP*,  
   2–8  
 LGP\$K\_HISTLINE\_THICKNESS plotting attribute •  
   *LGP*, 2–4  
 LGP\$K\_HORGRID\_THICKNESS plotting attribute  
   • *LGP*, 2–3  
 LGP\$K\_LABELFONT\_X plotting attribute • *LGP*,  
   2–5  
 LGP\$K\_LABELFONT\_Y plotting attribute • *LGP*,  
   2–5  
 LGP\$K\_LABELHEIGHT\_X plotting attribute • *LGP*,  
   2–5  
 LGP\$K\_LABELHEIGHT\_Y plotting attribute • *LGP*,  
   2–5  
 LGP\$K\_LBORDER\_MINOR\_TICKMARK plotting  
   attribute • *LGP*, 2–9  
 LGP\$K\_LBORDER\_SIZE plotting attribute • *LGP*,  
   2–7  
 LGP\$K\_META\_TYPE plotting attribute • *LGP*, 2–10  
 LGP\$K\_NUMANNOTFONT\_X plotting attribute •  
   *LGP*, 2–6  
 LGP\$K\_NUMANNOTFONT\_Y plotting attribute •  
   *LGP*, 2–6  
 LGP\$K\_NUMANNOTHEIGHT\_X plotting attribute •  
   *LGP*, 2–6  
 LGP\$K\_NUMANNOTHEIGHT\_Y plotting attribute •  
   *LGP*, 2–6  
 LGP\$K\_NUMLABEL\_X plotting attribute • *LGP*,  
   2–2  
 LGP\$K\_NUMLABEL\_Y plotting attribute • *LGP*,  
   2–2  
 LGP\$K\_NUM\_MINOR\_TICKS plotting attribute •  
   *LGP*, 2–10  
 LGP\$K\_PLACE\_TICKMARK plotting attribute •  
   *LGP*, 2–10  
 LGP\$K\_POINT\_THICKNESS plotting attribute •  
   *LGP*, 2–4  
 LGP\$K\_RBORDER\_MAJOR\_TICKMARK plotting  
   attribute • *LGP*, 2–9  
 LGP\$K\_RBORDER\_MINOR\_TICKMARK plotting  
   attribute • *LGP*, 2–10  
 LGP\$K\_RBORDER\_SIZE plotting attribute • *LGP*,  
   2–7

LGP\$K\_SCREEN DIV plotting attribute • *LGP*, 2-8  
 LGP\$K\_STD\_THICKNESS plotting attribute • *LGP*, 2-4  
 LGP\$K\_TBORDER\_MAJOR\_TICKMARK plotting attribute • *LGP*, 2-8  
 LGP\$K\_TBORDER\_MINOR\_TICKMARK plotting attribute • *LGP*, 2-9  
 LGP\$K\_TBORDER\_SIZE plotting attribute • *LGP*, 2-7  
 LGP\$K\_TITLEFONT plotting attribute • *LGP*, 2-6  
 LGP\$K\_TITLEHEIGHT plotting attribute • *LGP*, 2-5  
 LGP\$K\_VERTGRID\_THICKNESS plotting attribute • *LGP*, 2-3  
 LGP\$MAP\_PEN • *LGP*, 4-57  
 LGP\$PLOT • *LGP*, 4-59  
 LGP\$PLOT C • *LGP*, 4-84  
 LGP\$PLOT M • *LGP*, 4-89  
 LGP\$PLOT\_3D • *LGP*, 4-80  
 LGP\$PLOT\_LOG • *LGP*, 4-68  
 LGP\$PLOT\_METAFILE • *LGP*, 4-78  
 LGP\$POINT • *LGP*, 4-95  
 LGP\$PRINT\_SCREEN • *LGP*, 4-100  
 LGP\$PUT\_TEXT • *LGP*, 4-102  
 LGP\$SCALE • *LGP*, 4-108  
 LGP\$SCALE\_LOG • *LGP*, 4-111  
 LGP\$SET\_3D\_GRAPH • *LGP*, 4-121  
 LGP\$SET\_GRAPH • *LGP*, 4-115  
 LGP\$SPLINE\_QHC • *LGP*, 4-126  
 LGP\$STNDEV • *LGP*, 4-130  
 LGP\$TABLE\_MODIFY • *LGP*, 2-12, 4-141  
 LGP\$TABLE\_READ\_VALUE • *LGP*, 2-11, 4-143  
 LGP\$TABLE\_RESET • *LGP*, 2-13, 4-145  
 LGP\$TERMINATE\_PLOT • *LGP*, 1-20, 4-146  
 LGP\$ \_AXIS\_RESIZED error message • *LGP*, 5-4  
 LGP\$ \_ILL\_ARRAY error message • *LGP*, 5-4  
 LGP\$ \_ILL\_ARRAY\_SIZE error message • *LGP*, 5-4  
 LGP\$ \_ILL\_AT\_LIST error message • *LGP*, 5-4  
 LGP\$ \_ILL\_AT\_VALUE error message • *LGP*, 5-5  
 LGP\$ \_ILL\_COLOR\_ARRAY error message • *LGP*, 5-5  
 LGP\$ \_ILL\_ECHO\_AREA error message • *LGP*, 5-5  
 LGP\$ \_ILL\_FONT error message • *LGP*, 5-5  
 LGP\$ \_ILL\_H\_XLOW error message • *LGP*, 5-6  
 LGP\$ \_ILL\_IGON error message • *LGP*, 5-6  
 LGP\$ \_ILL\_IGRID error message • *LGP*, 5-6  
 LGP\$ \_ILL\_ILINE error message • *LGP*, 5-6

LGP\$ \_ILL\_INPUT\_WS error message • *LGP*, 5-7  
 LGP\$ \_ILL\_ISHADE error message • *LGP*, 5-7  
 LGP\$ \_ILL\_LOG\_DATA error message • *LGP*, 5-7  
 LGP\$ \_ILL\_LOG\_XLOW error message • *LGP*, 5-7  
 LGP\$ \_ILL\_LOG\_YLOW error message • *LGP*, 5-7  
 LGP\$ \_ILL\_METAFLAG error message • *LGP*, 5-8  
 LGP\$ \_ILL\_MODE\_STRING error message • *LGP*, 5-8  
 LGP\$ \_ILL\_NDIV error message • *LGP*, 5-9  
 LGP\$ \_ILL\_N error message • *LGP*, 5-8  
 LGP\$ \_ILL\_NPTS error message • *LGP*, 5-9  
 LGP\$ \_ILL\_NSETS error message • *LGP*, 5-10  
 LGP\$ \_ILL\_NSIZE error message • *LGP*, 5-10  
 LGP\$ \_ILL\_NX error message • *LGP*, 5-10  
 LGP\$ \_ILL\_NY error message • *LGP*, 5-10  
 LGP\$ \_ILL\_N\_START error message • *LGP*, 5-8  
 LGP\$ \_ILL\_N\_STEP error message • *LGP*, 5-9  
 LGP\$ \_ILL\_N\_SUBINT error message • *LGP*, 5-9  
 LGP\$ \_ILL\_PEN\_NUMBER error message • *LGP*, 5-11  
 LGP\$ \_ILL\_PORT error message • *LGP*, 5-11  
 LGP\$ \_ILL\_PORT\_LEN error message • *LGP*, 5-11  
 LGP\$ \_ILL\_PROC\_HIST error message • *LGP*, 5-11  
 LGP\$ \_ILL\_PROC\_PLOT C error message • *LGP*, 5-12  
 LGP\$ \_ILL\_PROC\_PLOT M error message • *LGP*, 5-12  
 LGP\$ \_ILL\_PROC\_POINT error message • *LGP*, 5-12  
 LGP\$ \_ILL\_PROC\_STNDEV error message • *LGP*, 5-12  
 LGP\$ \_ILL\_PUT\_TEXT error message • *LGP*, 5-13  
 LGP\$ \_ILL\_SIZE error message • *LGP*, 5-14  
 LGP\$ \_ILL\_STNDEV error message • *LGP*, 5-14  
 LGP\$ \_ILL\_S\_NPTS error message • *LGP*, 5-13  
 LGP\$ \_ILL\_S\_NSETS error message • *LGP*, 5-13  
 LGP\$ \_ILL\_S\_NSIZE error message • *LGP*, 5-14  
 LGP\$ \_ILL\_TEXT\_PATH error message • *LGP*, 5-14  
 LGP\$ \_ILL\_WKSTN\_SIZE error message • *LGP*, 5-15  
 LGP\$ \_ILL\_WLIST\_SIZE error message • *LGP*, 5-15  
 LGP\$ \_ILL\_WSN error message • *LGP*, 5-15  
 LGP\$ \_ILL\_WSTYPE error message • *LGP*, 5-15  
 LGP\$ \_ILL\_XARRAY error message • *LGP*, 5-16

LGP\$\_ILL\_XDELTA error message • *LGP*, 5–16  
 LGP\$\_ILL\_XLEN error message • *LGP*, 5–16  
 LGP\$\_ILL\_XLOW error message • *LGP*, 5–16  
 LGP\$\_ILL\_YDELTA error message • *LGP*, 5–17  
 LGP\$\_ILL\_YLEN error message • *LGP*, 5–17  
 LGP\$\_ILL\_YLOW error message • *LGP*, 5–17  
 LGP\$\_ILL\_ZMAX error message • *LGP*, 5–17  
 LGP\$\_MAND\_ARG error message • *LGP*, 5–18  
 LGP\$\_SUCCESS error message • *LGP*, 5–18  
 LGP\$\_WKSTN\_SIZE\_UNDEF error message •  
   *LGP*, 5–18  
 LGP\$\_WSN\_IN\_USE error message • *LGP*, 5–18  
 LGP\$\_WSN\_NOT\_IN\_USE error message • *LGP*,  
   5–18  
 LGP\_3D.FOR sample program • *LGP*, 6–6  
 LGP\_ASSIGN\_PEN.FOR sample program • *LGP*,  
   6–2  
 LGP\_AUTOSCALE.FOR sample program • *LGP*,  
   6–2  
 LGP\_CHANGE\_LOGICALS.FOR sample program  
   • *LGP*, 6–2  
 LGP\_CONTOURM.FOR sample program • *LGP*,  
   6–2  
 LGP\_ERASE.C sample program • *LGP*, 6–2  
 LGP\_GET\_ROUTINES.FOR sample program •  
   *LGP*, 6–3  
 LGP\_GKS.FOR sample program • *LGP*, 6–3  
 LGP\_INFO.FOR sample program • *LGP*, 6–3  
 LGP\_LIO.FOR sample program • *LGP*, 6–3  
 LGP\_METAFILE.FOR sample program • *LGP*, 6–3  
 LGP\_MOD\_ATTRIB.FOR sample program • *LGP*,  
   6–4  
 LGP\_PLOT.C.FOR sample program • *LGP*, 6–5  
 LGP\_PLOTM\_SINE.FOR sample program • *LGP*,  
   6–5  
 LGP\_PLOT\_3D.FOR sample program • *LGP*, 6–5  
 LGP\_PLOT\_CONTOUR.FOR sample program •  
   *LGP*, 6–4  
 LGP\_PLOT\_HIST.FOR sample program • *LGP*,  
   6–4  
 LGP\_PLOT\_LOG.C sample program • *LGP*, 6–4  
 LGP\_PLOT\_POINTS.C sample program • *LGP*,  
   6–4  
 LGP\_PLOT\_SINE.FOR sample program • *LGP*,  
   6–4  
 LGP\_SCALE\_LOG.C sample program • *LGP*, 6–5  
 LGP\_SHADE\_CONTOUR.FOR sample program •  
   *LGP*, 6–5  
 LGP\_SIMPLE.C sample program • *LGP*, 6–5  
 LGP\_STNDEV.FOR sample program • *LGP*, 6–6  
 LGP\_WRITE\_TEXT.FOR sample program • *LGP*,  
   6–6  
 LIB\$WAIT • *LGP*, 4–147  
 License  
   loading • *INSTALL*, 5–5  
 License registration  
   for new VAXlab systems • *INSTALL*, 2–2  
   for VAXlab systems • *INSTALL*, 3–4  
 Linear coordinate system • *LGP*, 4–68  
 Linking object files • *GETSTART*, 3–2  
 LIO\$ATTACH • *LIO*, 3–3 to 3–7  
   device specifications • *LIO*, 3–4  
   I/O types • *LIO*, 3–4  
 LIO\$DEQUEUE • *LIO*, 3–8 to 3–12  
   device-specific argument values • *LIO*, 3–11  
 LIO\$DETACH • *LIO*, 3–13 to 3–14  
 LIO\$ENQUEUE • *LIO*, 3–15 to 3–23  
   device-specific argument values • *LIO*, 3–18  
 LIO\$EXAMPLES • *LIO*, 6–1  
 LIO\$K\_AAF\_DOUBLE.C sample program • *LIO*,  
   6–5  
 LIO\$K\_ACK\_NAK\_TERMINATOR • *LIO*, 4–12  
 LIO\$K\_ADD\_AD\_CHAN • *LIO*, 4–19 to 4–20  
 LIO\$K\_ADF\_DOUBLE.C sample program • *LIO*,  
   6–8  
 LIO\$K\_ADF\_SINGLE.C sample program • *LIO*,  
   6–10  
 LIO\$K\_AD\_CHAN • *LIO*, 4–13 to 4–14  
 LIO\$K\_AD\_CLOCK • *LIO*, 4–255  
 LIO\$K\_AD\_DIFFERENTIAL • *LIO*, 4–15 to 4–16  
 LIO\$K\_AD\_GAIN • *LIO*, 4–17 to 4–18  
 LIO\$K\_ANALOG • *LIO*, 4–217  
 LIO\$K\_ANA\_OUT • *LIO*, 4–21  
 LIO\$K\_AST\_RTN • *LIO*, 4–22 to 4–23  
 LIO\$K\_ASYNCH • *LIO*, 4–24 to 4–25  
 LIO\$K\_AUX\_COMMAND • *LIO*, 4–26 to 4–28  
 LIO\$K\_BAUD\_RATE • *LIO*, 4–29 to 4–31  
 LIO\$K\_BIN\_DDR • *LIO*, 4–32  
 LIO\$K\_BITS\_PER\_CHAR • *LIO*, 4–33  
 LIO\$K\_BOTH • *LIO*, 4–141  
 LIO\$K\_BOUNCE • *LIO*, 4–34 to 4–35  
 LIO\$K\_BREAK • *LIO*, 4–36  
 LIO\$K\_BUFF\_SIZE • *LIO*, 4–37 to 4–38

LIO\$K\_BUFF\_SOURCE • LIO, 4-39 to 4-40  
 LIO\$K\_BUFPATH • LIO, 4-92  
 LIO\$K\_BURST • LIO, 4-255  
 LIO\$K\_BURST\_DIV • LIO, 4-41 to 4-42  
 LIO\$K\_BURST\_RATE • LIO, 4-43 to 4-44  
 LIO\$K\_CANCEL • LIO, 4-45  
 LIO\$K\_CC\_FOUT • LIO, 4-46 to 4-47  
 LIO\$K\_CC\_SETUP • LIO, 4-48 to 4-49  
 LIO\$K\_CHANNEL • LIO, 4-50  
 LIO\$K\_CLK\_BASE • LIO, 4-51 to 4-52  
 LIO\$K\_CLK\_BURST • LIO, 4-254, 4-258  
 LIO\$K\_CLK\_DIV • LIO, 4-53 to 4-54  
 LIO\$K\_CLK\_POINT • LIO, 4-254, 4-259  
 LIO\$K\_CLK\_RATE • LIO, 4-55 to 4-57  
 LIO\$K\_CLK\_SRC • LIO, 4-58 to 4-60  
 LIO\$K\_CLK\_SWEEP • LIO, 4-254, 4-257  
 LIO\$K\_CLR\_LBO • LIO, 4-61 to 4-62  
 LIO\$K\_COB • LIO, 4-63  
 LIO\$K\_COMMAND • LIO, 4-64 to 4-69  
 LIO\$K\_CONT • LIO, 4-70 to 4-71  
 LIO\$K\_COUNTER • LIO, 4-72 to 4-73  
 LIO\$K\_CTA • LIO, 4-74  
 LIO\$K\_CTI\_BUF • LIO, 4-75 to 4-77  
 LIO\$K\_CTI\_OVERHD • LIO, 4-78  
 LIO\$K\_CTRL\_ACTIVE • LIO, 4-79 to 4-80  
 LIO\$K\_CTRL\_AST • LIO, 4-81  
 LIO\$K\_CTRL\_HANDLING • LIO, 4-83 to 4-84  
 LIO\$K\_CTRL\_STANDBY • LIO, 4-85  
 LIO\$K\_CURRENT\_CHANNEL • LIO, 4-86  
 LIO\$K\_CWT • LIO, 4-87 to 4-88  
 LIO\$K\_DATA • LIO, 4-91  
 LIO\$K\_DATA\_PATH • LIO, 4-92 to 4-93  
 LIO\$K\_DATA\_WIDTH • LIO, 4-94  
 LIO\$K\_DA\_CHAN • LIO, 4-89 to 4-90  
 LIO\$K\_DBL\_BUF • LIO, 4-95  
 LIO\$K\_DEADDR\_EVT • LIO, 2-124, 4-127  
 LIO\$K\_DEVICE • LIO, 4-141  
 LIO\$K\_DEVICE\_ACK\_NAK\_BUFF • LIO, 4-96  
 LIO\$K\_DEVICE\_EF • LIO, 4-97 to 4-98  
 LIO\$K\_DEV\_CLR\_EVT • LIO, 2-124, 4-127  
 LIO\$K\_DEV\_TRIG\_EVT • LIO, 2-124, 4-127  
 LIO\$K\_DIAG\_CHAN • LIO, 4-99 to 4-100  
 LIO\$K\_DIRECTION • LIO, 4-101 to 4-102  
 LIO\$K\_DIRPATH • LIO, 4-92  
 LIO\$K\_DISABLE  
     with LIO\$K\_ED\_CTT • LIO, 4-112  
     with LIO\$K\_ED\_ECE • LIO, 4-114

LIO\$K\_DISABLE (Cont.)  
     with LIO\$K\_ED\_SBE • LIO, 4-115  
     with LIO\$K\_STO\_1 • LIO, 4-228  
 LIO\$K\_DISPLAY\_ONLY • LIO, 4-103  
 LIO\$K\_DRX\_AST\_RTN • LIO, 4-104 to 4-105  
 LIO\$K\_DRX\_STAT • LIO, 4-106 to 4-107  
 LIO\$K\_DUPLEX • LIO, 4-108 to 4-109  
 LIO\$K\_ECHO • LIO, 4-110 to 4-111  
 LIO\$K\_EDGE • LIO, 4-153  
 LIO\$K\_EDGE\_DELAY • LIO, 4-153  
 LIO\$K\_ED\_CTT • LIO, 4-112 to 4-113  
 LIO\$K\_ED\_ECE • LIO, 4-114  
 LIO\$K\_ED\_SBE • LIO, 4-115  
 LIO\$K\_ENABLE  
     with LIO\$K\_ED\_CTT • LIO, 4-112  
     with LIO\$K\_ED\_ECE • LIO, 4-114  
     with LIO\$K\_ED\_SBE • LIO, 4-115  
     with LIO\$K\_STO\_1 • LIO, 4-228  
 LIO\$K\_EOI • LIO, 4-116 to 4-117  
 LIO\$K\_ERROR\_ENABLE • LIO, 4-120  
 LIO\$K\_ERR\_HANDLE • LIO, 4-118 to 4-119  
 LIO\$K\_EVEN  
     with LIO\$K\_PARITY • LIO, 4-193  
 LIO\$K\_EVENT\_ABS • LIO, 4-146  
 LIO\$K\_EVENT\_AST • LIO, 4-121 to 4-124  
 LIO\$K\_EVENT\_EF • LIO, 4-125 to 4-126  
 LIO\$K\_EVENT\_ENA • LIO, 4-127 to 4-130  
 LIO\$K\_EVENT\_REL • LIO, 4-147  
 LIO\$K\_EVENT\_WAIT • LIO, 4-131 to 4-132  
 LIO\$K\_EXTERNAL • LIO, 4-255, 4-256, 4-260  
 LIO\$K\_EXT\_BURST • LIO, 4-254, 4-257, 4-258  
 LIO\$K\_EXT\_LNR\_EVT • LIO, 2-124, 4-128  
 LIO\$K\_EXT\_POINT • LIO, 4-254, 4-257, 4-259  
 LIO\$K\_EXT\_START • LIO, 4-261  
 LIO\$K\_EXT\_START\_CLK\_SWEEP • LIO, 4-261  
 LIO\$K\_EXT\_START\_EXT\_POINT • LIO, 4-261  
 LIO\$K\_EXT\_START\_EXT\_SWEEP • LIO, 4-261  
 LIO\$K\_EXT\_SWEEP • LIO, 4-254, 4-257, 4-259  
 LIO\$K\_EXT\_TKR\_EVT • LIO, 2-124, 4-128  
 LIO\$K\_FATAL • LIO, 4-118  
 LIO\$K\_FILE\_EXTENT • LIO, 4-133 to 4-134  
 LIO\$K\_FILE\_POS • LIO, 4-135  
 LIO\$K\_FILE\_REMAIN • LIO, 4-136 to 4-137  
 LIO\$K\_FILE\_SIZE • LIO, 4-138  
 LIO\$K\_FLOW\_CONTROL • LIO, 4-139 to 4-140  
 LIO\$K\_FLOW\_MASTER • LIO, 4-141 to 4-142  
 LIO\$K\_FNCT0 • LIO, 4-215  
 LIO\$K\_FORWARD • LIO, 4-143 to 4-144

LIO\$K\_FUNCTION • LIO, 4-145 to 4-147  
 LIO\$K\_FUNCTION\_BITS • LIO, 4-148 to 4-152  
 LIO\$K\_GATE • LIO, 4-153 to 4-155  
 LIO\$K\_HANDSHAKE • LIO, 4-156 to 4-157  
 LIO\$K\_HANGUP • LIO, 4-158  
 LIO\$K\_HOST • LIO, 4-141  
 LIO\$K\_IEEE\_ADDR • LIO, 4-159 to 4-160  
 LIO\$K\_IFC\_EVT • LIO, 2-124, 4-128  
 LIO\$K\_IMMEDIATE • LIO, 4-260  
 LIO\$K\_IMM\_BURST • LIO, 4-253, 4-257, 4-258  
 LIO\$K\_IMM\_START\_CLK\_POINT • LIO, 4-260  
 LIO\$K\_IMM\_START\_CLK\_SWEEP • LIO, 4-260  
 LIO\$K\_IMM\_START\_EXT\_POINT • LIO, 4-260  
 LIO\$K\_INIT\_AD\_CHAN • LIO, 4-161  
 LIO\$K\_INPUT\_TERMINATOR • LIO, 4-162  
 LIO\$K\_INTERRUPT\_LEVEL • LIO, 4-163  
 LIO\$K\_LEAVE\_IN\_STATE • LIO, 4-164 to 4-165  
 LIO\$K\_LEVEL • LIO, 4-153  
 LIO\$K\_LNR\_ADDR\_EVT • LIO, 2-124, 4-128  
 LIO\$K\_LOCK\_BUFFER • LIO, 4-166 to 4-167  
 LIO\$K\_LOOP\_BACK • LIO, 4-168  
 LIO\$K\_MAX\_CHANNELS • LIO, 4-169  
 LIO\$K\_MESSAGE • LIO, 4-118  
 LIO\$K\_MODEM • LIO, 4-170 to 4-171  
 LIO\$K\_MODEM\_STATUS • LIO, 4-172 to 4-173  
 LIO\$K\_MULTIPLE\_X\_AXES • LIO, 4-174  
 LIO\$K\_NAME • LIO, 4-180 to 4-181  
 LIO\$K\_NEGATIVE • LIO, 4-202  
 LIO\$K\_NONE  
     with LIO\$K\_PARITY • LIO, 4-193  
 LIO\$K\_NO\_FNCT0 • LIO, 4-215  
 LIO\$K\_N\_AD\_CHAN • LIO, 4-176  
 LIO\$K\_N\_BUFFS • LIO, 4-177 to 4-178  
 LIO\$K\_N\_DA\_CHAN • LIO, 4-179  
 LIO\$K\_ODD  
     with LIO\$K\_PARITY • LIO, 4-193  
 LIO\$K\_OFF  
     with LIO\$K\_AD\_DIFFERENTIAL • LIO, 4-15  
     with LIO\$K\_DIAG\_CHAN • LIO, 4-99  
     with LIO\$K\_ECHO • LIO, 4-110  
     with LIO\$K\_EOI • LIO, 4-116  
     with LIO\$K\_GATE • LIO, 4-153  
     with LIO\$K\_HANDSHAKE • LIO, 4-156  
     with LIO\$K\_IEEE\_ADDR • LIO, 4-159  
     with LIO\$K\_LEAVE\_IN\_STATE • LIO, 4-164  
     with LIO\$K\_MODEM • LIO, 4-170  
     with LIO\$K\_MULTIPLE\_X\_AXES • LIO, 4-174

LIO\$K\_OFF (Cont.)  
     with LIO\$K\_PROTOCOL • LIO, 4-206  
     with LIO\$K\_TERM\_SRQ • LIO, 4-243  
     with LIO\$K\_TIMEOUT\_ENABLE • LIO, 4-247  
     with LIO\$K\_TYPE\_AHEAD • LIO, 4-264  
 LIO\$K\_ON  
     with LIO\$K\_AD\_DIFFERENTIAL • LIO, 4-15  
     with LIO\$K\_DIAG\_CHAN • LIO, 4-99  
     with LIO\$K\_ECHO • LIO, 4-110  
     with LIO\$K\_EOI • LIO, 4-116  
     with LIO\$K\_HANDSHAKE • LIO, 4-156  
     with LIO\$K\_IEEE\_ADDR • LIO, 4-159  
     with LIO\$K\_LEAVE\_IN\_STATE • LIO, 4-164  
     with LIO\$K\_MODEM • LIO, 4-170  
     with LIO\$K\_MULTIPLE\_X\_AXES • LIO, 4-174  
     with LIO\$K\_PROTOCOL • LIO, 4-206  
     with LIO\$K\_TERM\_SRQ • LIO, 4-243  
     with LIO\$K\_TIMEOUT\_ENABLE • LIO, 4-247  
     with LIO\$K\_TYPE\_AHEAD • LIO, 4-264  
 LIO\$K\_OPEN\_FILE • LIO, 4-182  
 LIO\$K\_OUTPUT\_PREFIX • LIO, 4-183  
 LIO\$K\_OUTPUT\_TERMINATOR • LIO, 4-184  
 LIO\$K\_PAGE\_ALIGN • LIO, 4-185  
 LIO\$K\_PARITY • LIO, 4-193 to 4-194  
 LIO\$K\_PAR\_POLL • LIO, 4-186 to 4-187  
 LIO\$K\_PAR\_POLL\_CONFIG • LIO, 4-188 to  
     4-190  
 LIO\$K\_PAR\_POLL\_CONFIG\_EVT • LIO, 2-125,  
     4-128  
 LIO\$K\_PAR\_POLL\_STATUS • LIO, 4-191 to  
     4-192  
 LIO\$K\_PAR\_POLL\_UNCONFIG\_EVT • LIO, 2-125,  
     4-128  
 LIO\$K\_PASS\_CTRL • LIO, 4-195  
 LIO\$K\_PCR • LIO, 4-196  
 LIO\$K\_PLOT\_SIZE • LIO, 4-198  
 LIO\$K\_PLOT\_TYPE • LIO, 4-199 to 4-200  
 LIO\$K\_POLARITY • LIO, 4-202 to 4-203  
 LIO\$K\_POSITION • LIO, 4-204 to 4-205  
 LIO\$K\_POSITIVE • LIO, 4-202  
 LIO\$K\_PO\_CHAN • LIO, 4-201  
 LIO\$K\_PROTOCOL • LIO, 4-206 to 4-208  
 LIO\$K\_PURGE • LIO, 4-209  
 LIO\$K\_READ • LIO, 4-141  
 LIO\$K\_READ\_ONLY • LIO, 4-210  
 LIO\$K\_READ\_PROMPT • LIO, 4-211  
 LIO\$K\_READ\_STAT • LIO, 4-212 to 4-213  
 LIO\$K\_REC\_CTRL\_EVT • LIO, 2-125, 4-129



LIO\$K\_REM\_LOCAL\_EVT • *LIO*, 2-125, 4-129  
 LIO\$K\_REP\_COUNT • *LIO*, 4-145  
 LIO\$K\_RESET\_AXF • *LIO*, 4-214  
 LIO\$K\_RESET\_DRX • *LIO*, 4-215 to 4-216  
 LIO\$K\_SAME • *LIO*, 4-256  
 LIO\$K\_SCHMITT\_TRIGGER • *LIO*, 4-217 to 4-218  
 LIO\$K\_SCOPE • *LIO*, 4-199  
 LIO\$K\_SER\_POLL • *LIO*, 4-219 to 4-220  
 LIO\$K\_SER\_POLL\_CONFIG • *LIO*, 4-221 to 4-222  
 LIO\$K\_SGL\_BUF • *LIO*, 4-223 to 4-224  
 LIO\$K\_SGL\_COUNT • *LIO*, 4-145  
 LIO\$K\_SKIP\_COUNT • *LIO*, 4-225  
 LIO\$K\_SRQ • *LIO*, 4-226 to 4-227  
 LIO\$K\_SRQ\_EVT • *LIO*, 2-125, 4-129  
 LIO\$K\_ST0\_1 • *LIO*, 4-228 to 4-229  
 LIO\$K\_START • *LIO*, 4-230 to 4-232  
 LIO\$K\_STATUS • *LIO*, 4-118  
 LIO\$K\_STAT\_BITS • *LIO*, 4-233  
 LIO\$K\_STE • *LIO*, 4-234  
 LIO\$K\_STOP • *LIO*, 4-235 to 4-236  
 LIO\$K\_STRIPCHART • *LIO*, 4-199  
 LIO\$K\_SWEEP\_CLOCK • *LIO*, 4-256  
 LIO\$K\_SWEEP\_RATE • *LIO*, 4-237 to 4-238  
 LIO\$K\_SYNCH • *LIO*, 4-239 to 4-240  
 LIO\$K\_SYNCH sample program • *LIO*, 6-16  
 LIO\$K\_TERM\_CHAR • *LIO*, 4-241  
 LIO\$K\_TERM\_SRQ • *LIO*, 4-243 to 4-244  
 LIO\$K\_TIMEOUT • *LIO*, 4-245 to 4-246  
 LIO\$K\_TIMEOUT\_ENABLE • *LIO*, 4-247  
 LIO\$K\_TITLE • *LIO*, 4-248 to 4-249  
 LIO\$K\_TITLE\_n • *LIO*, 4-250 to 4-251  
 LIO\$K\_TKR\_ADDR\_EVT • *LIO*, 2-125, 4-129  
 LIO\$K\_TRANSFER • *LIO*, 4-252  
 LIO\$K\_TRIG • *LIO*, 4-253 to 4-263  
 LIO\$K\_TTL • *LIO*, 4-217  
 LIO\$K\_TYPE\_AHEAD • *LIO*, 4-264 to 4-265  
 LIO\$K\_UNLOCK\_BUFFER • *LIO*, 4-266  
 LIO\$K\_UNSOLICITED • *LIO*, 4-267  
 LIO\$K\_UPDATE • *LIO*, 4-268  
 LIO\$K\_USER\_ACK\_AST • *LIO*, 4-269  
 LIO\$K\_USER\_ACK\_STRING • *LIO*, 4-270  
 LIO\$K\_USER\_NAK\_AST • *LIO*, 4-271  
 LIO\$K\_USER\_NAK\_STRING • *LIO*, 4-272  
 LIO\$K\_USER\_READ\_PROTOCOL\_AST • *LIO*, 4-273 to 4-274

LIO\$K\_USER\_WRITE\_NAK\_HANDLING • *LIO*, 4-275 to 4-276  
 LIO\$K\_VLT\_DDR • *LIO*, 4-277  
 LIO\$K\_VOLTAGE • *LIO*, 4-278  
 LIO\$K\_XON • *LIO*, 4-283  
 LIO\$K\_X\_LABEL • *LIO*, 4-280  
 LIO\$K\_X\_RANGE • *LIO*, 4-281  
 LIO\$K\_Y\_LABEL • *LIO*, 4-284  
 LIO\$K\_Y\_MAX • *LIO*, 4-285  
 LIO\$K\_Y\_MAX parameter • *LIO*, 4-285  
 LIO\$K\_Y\_MIN • *LIO*, 4-286  
 LIO\$M\_CD  
     with LIO\$K\_MODEM\_STATUS • *LIO*, 4-172  
 LIO\$M\_CTS  
     with LIO\$K\_MODEM\_STATUS • *LIO*, 4-172  
 LIO\$M\_DSR  
     with LIO\$M\_DSR • *LIO*, 4-172  
 LIO\$M\_DTR  
     with LIO\$K\_MODEM\_STATUS • *LIO*, 4-172  
 LIO\$M\_RI  
     with LIO\$K\_MODEM\_STATUS • *LIO*, 4-172  
 LIO\$M\_RTS  
     with LIO\$K\_MODEM\_STATUS • *LIO*, 4-172  
 LIO\$READ • *LIO*, 3-24 to 3-28  
     device-specific argument values • *LIO*, 3-26  
 LIO\$SET\_I • *LIO*, 3-29 to 3-30  
 LIO\$SET\_R • *LIO*, 3-31 to 3-32  
 LIO\$SET\_S • *LIO*, 3-33 to 3-34  
 LIO\$SHOW • *LIO*, 3-35 to 3-36  
 LIO\$WRITE • *LIO*, 3-37 to 3-40  
     device-specific argument values • *LIO*, 3-39  
 LIO\$\_ACCVIO error message • *LIO*, 5-6  
 LIO\$\_ADDR\_NOT\_SET error message • *LIO*, 5-6  
 LIO\$\_ALREADY\_ATTACHED error message • *LIO*, 5-6  
 LIO\$\_ARGREQ error message • *LIO*, 5-6  
 LIO\$\_ATTACH\_FAILED error message • *LIO*, 5-7  
 LIO\$\_BUFFSIZE error message • *LIO*, 5-7  
 LIO\$\_BUFF\_OVERLAP error message • *LIO*, 5-7  
 LIO\$\_BUFORDER error message • *LIO*, 5-8  
 LIO\$\_BUS\_ERR error message • *LIO*, 5-8  
 LIO\$\_CIC error message • *LIO*, 5-8  
 LIO\$\_CLKOVERUN error message • *LIO*, 5-8  
 LIO\$\_CTGCDMA error message • *LIO*, 5-9  
 LIO\$\_DETACH\_FAILED error message • *LIO*, 5-9  
 LIO\$\_DEVACTIVE error message • *LIO*, 5-9  
 LIO\$\_DEVSPREQ error message • *LIO*, 5-9

LIO\$\_DEV\_ERR error message • *LIO*, 5-9  
 LIO\$\_EMPTYQ error message • *LIO*, 5-10  
 LIO\$\_FIL\_OPEN error message • *LIO*, 5-10  
 LIO\$\_FLAGREQD error message • *LIO*, 5-10  
 LIO\$\_GBLACCESS error message • *LIO*, 5-11  
 LIO\$\_ILLBUFF error message • *LIO*, 5-11  
 LIO\$\_ILLCHAN error message • *LIO*, 5-11  
 LIO\$\_ILLDEVSPEC error message • *LIO*, 5-12  
 LIO\$\_ILLFUNC error message • *LIO*, 5-12  
 LIO\$\_ILLGAIN error message • *LIO*, 5-12  
 LIO\$\_ILLID error message • *LIO*, 5-12  
 LIO\$\_ILLSETUP error message • *LIO*, 5-13  
 LIO\$\_ILLTRIG error message • *LIO*, 5-13  
 LIO\$\_ILLVAL error message • *LIO*, 5-13  
 LIO\$\_INSBUFHDR error message • *LIO*, 5-13  
 LIO\$\_INSFWS error message • *LIO*, 5-13  
 LIO\$\_INTERR error message • *LIO*, 5-14  
 LIO\$\_INV\_ADDR error message • *LIO*, 5-14  
 LIO\$\_IOERROR error message • *LIO*, 5-14  
 LIO\$\_MALFAIL error message • *LIO*, 5-14  
 LIO\$\_NAMTOOLONG error message • *LIO*, 5-14  
 LIO\$\_NIMP error message • *LIO*, 5-15  
 LIO\$\_NOASYNCH error message • *LIO*, 5-15  
 LIO\$\_NOCT1 error message • *LIO*, 5-15  
 LIO\$\_NODP error message • *LIO*, 5-15  
 LIO\$\_NODRIVER error message • *LIO*, 5-15  
 LIO\$\_NOENTRY error message • *LIO*, 5-16  
 LIO\$\_NOEVENT error message • *LIO*, 5-16  
 LIO\$\_NOINPUT error message • *LIO*, 5-16  
 LIO\$\_NOINTERP error message • *LIO*, 5-17  
 LIO\$\_NOLB error message • *LIO*, 5-17  
 LIO\$\_NOLOCAL error message • *LIO*, 5-17  
 LIO\$\_NOMAP error message • *LIO*, 5-18  
 LIO\$\_NOMIX error message • *LIO*, 5-18  
 LIO\$\_NOOUTPUT error message • *LIO*, 5-18  
 LIO\$\_NOQIO error message • *LIO*, 5-19  
 LIO\$\_NORESET error message • *LIO*, 5-19  
 LIO\$\_NOROOM error message • *LIO*, 5-19  
 LIO\$\_NOSHARE error message • *LIO*, 5-19  
 LIO\$\_NOSLOT error message • *LIO*, 5-19  
 LIO\$\_NOSYNCH error message • *LIO*, 5-20  
 LIO\$\_NOTOPEN error message • *LIO*, 5-20  
 LIO\$\_NOTREADY error message • *LIO*, 5-20  
 LIO\$\_NOTSETCDMA error message • *LIO*, 5-21  
 LIO\$\_NOT\_CIC error message • *LIO*, 5-20  
 LIO\$\_NOT\_SETUP error message • *LIO*, 5-21  
 LIO\$\_NO\_TRANS error message • *LIO*, 5-20

LIO\$\_ONFREEQ error message • *LIO*, 5-21  
 LIO\$\_ONQ error message • *LIO*, 5-21  
 LIO\$\_OVERRUN error message • *LIO*, 5-22  
 LIO\$\_PAGEALIGN error message • *LIO*, 5-22  
 LIO\$\_POLL\_STAT error message • *LIO*, 5-22  
 LIO\$\_QIOCHAN error message • *LIO*, 5-22  
 LIO\$\_QNEMP error message • *LIO*, 5-23  
 LIO\$\_REMOTE\_DEV error message • *LIO*, 5-23  
 LIO\$\_REQ64K error message • *LIO*, 5-23  
 LIO\$\_RUNNING error message • *LIO*, 5-23  
 LIO\$\_SS\_INTERR error message • *LIO*, 5-24  
 LIO\$\_SUCCESS error message • *LIO*, 5-24  
 LIO\$\_TERM-EOI error message • *LIO*, 5-24  
 LIO\$\_TERM\_CHAR error message • *LIO*, 5-24  
 LIO\$\_TERM\_SRQ error message • *LIO*, 5-25  
 LIO\$\_TOOFEWARGS error message • *LIO*, 5-25  
 LIO\$\_TOOFEWVALS error message • *LIO*, 5-25  
 LIO\$\_TOOMANYPROCS error message • *LIO*,  
     5-25  
 LIO\$\_TOOMANYVALS error message • *LIO*, 5-26  
 LIO\$\_UNKDEV error message • *LIO*, 5-26  
 LIO\$\_UNKPARAM error message • *LIO*, 5-26  
 LIO\$\_VALTOOBIG error message • *LIO*, 5-26  
 LIO\$\_VALTOOSMALL error message • *LIO*, 5-26  
 LIO\$\_WORDALIGN error message • *LIO*, 5-27  
 LIO example programs • *INSTALL*, 4-8  
 LIO routines  
     format of • *LIO*, 3-1  
     summary of • *LIO*, 3-2  
 LIO\_AAFBIG.C sample program • *LIO*, 6-4  
 LIO\_AAF\_CALIB.C sample program • *LIO*, 6-4  
 LIO\_AAF\_RW\_ACS.C sample program • *LIO*, 6-5  
 LIO\_AAF\_SEL\_OUT.C sample program • *LIO*, 6-6  
 LIO\_AAF\_SINGLE.C sample program • *LIO*, 6-6  
 LIO\_ADFBIG.C sample program • *LIO*, 6-7  
 LIO\_ADF\_CALIB.C sample program • *LIO*, 6-7  
 LIO\_ADF\_DAC\_CALIB.C sample program • *LIO*,  
     6-8  
 LIO\_ADF\_DOUBLE\_AST.C sample program • *LIO*,  
     6-9  
 LIO\_ADF\_DOUBLE\_SAST.C sample program •  
     *LIO*, 6-9  
 LIO\_ADF\_LOOPBACK.C sample program • *LIO*,  
     6-10  
 LIO\_ADF\_TEST\_SEQ.C sample program • *LIO*,  
     6-11

LIO\_ADQ\_ASYNC.HFOR sample program • *LIO*, 6-11  
 LIO\_ADQ\_SYNC.HFOR sample program • *LIO*, 6-11  
 LIO\_ADV\_AST.BAS sample program • *LIO*, 6-12  
 LIO\_ASYNC\_CLK\_TRIG.FOR sample program • *LIO*, 6-12  
 LIO\_AXV\_CTI.FOR sample program • *LIO*, 6-12  
 LIO\_AXV\_DIRECTION.FOR sample program • *LIO*, 6-13  
 LIO\_AXV\_MAPPED.BAS sample program • *LIO*, 6-13  
 LIO\_AXV\_QIO.FOR sample program • *LIO*, 6-13  
 LIO\_AXV\_RTLPLOT.FOR sample program • *LIO*, 6-13  
 LIO\_BUF\_FWD.FOR sample program • *LIO*, 6-14  
 LIO\_BUF\_INX.FOR sample program • *LIO*, 6-14  
 LIO\_CONT\_DMA.FOR sample program • *LIO*, 6-14  
 LIO\_DRJ\_SETUP.FOR sample program • *LIO*, 6-14  
 LIO\_DRQ3B\_LOOP.FOR sample program • *LIO*, 6-15  
 LIO\_DRV11J\_LOOP.FOR sample program • *LIO*, 6-15  
 LIO\_DRV\_LOOP.PAS sample program • *LIO*, 6-15  
 LIO\_FILE\_POS.FOR sample program • *LIO*, 6-15  
 LIO\_FILTER\_EVENT.FOR sample program • *LIO*, 6-15  
 LIO\_HX\_EXAMPLE.C sample program • *LIO*, 6-16  
 LIO\_IEEE\_LOOP.FOR sample program • *LIO*, 6-16  
 LIO\_IEX\_ASYNC.C sample program • *LIO*, 6-16  
 LIO\_IEX\_SYNC.C sample program • *LIO*, 6-16  
 LIO\_IEZ\_SYNC.C sample program • *LIO*, 6-17  
 LIO\_KWV\_AST.FOR sample program • *LIO*, 6-17  
 LIO\_MQ\_DISPLAY.FOR sample program • *LIO*, 6-17  
 LIO\_MQ\_READONLY.FOR sample program • *LIO*, 6-17  
 LIO\_MQ\_XFER.FOR sample program • *LIO*, 6-18  
 LIO\_PRESTON\_AST\_PLOT.C sample program • *LIO*, 6-18  
 LIO\_PRESTON\_READ.C sample program • *LIO*, 6-18  
 LIO\_RTC01\_COUNTER.FOR sample program • *LIO*, 6-18  
 LIO\_RTC01\_SET.FOR sample program • *LIO*, 6-19  
 LIO\_SERIAL.C sample program • *LIO*, 6-19  
 LIO\_SGLBUF\_DMA.FOR sample program • *LIO*, 6-19  
 LIO\_SYNC\_CLK\_TRIG.FOR sample program • *LIO*, 6-19  
 LIO\_TIME\_EVENT.FOR sample program • *LIO*, 6-20  
 LIO\_UQ\_LOOP.C sample program • *LIO*, 6-20  
 Listing DECnet nodes • *GETSTART*, 2-31  
 LN03 PLUS printer  
     plotting capabilities • *LGP*, 1-14  
 LN03R printer  
     plotting capabilities • *LGP*, 1-14  
 Loading VSL  
     license • *INSTALL*, 5-5  
     tape cartridge • *INSTALL*, 4-5  
 Local area VAXcluster • *INSTALL*, 1-4  
 Logarithmic axis system • *LGP*, 4-68  
 Logarithmic scaling • *LGP*, 4-68  
 Logical names  
     assigning • *LGP*, 1-9  
     assigning for foreign device support • *LGP*, 1-12  
 LOGIN.COM • *INSTALL*, 5-2  
 LOGIN.COM file  
     editing • *INSTALL*, 5-3  
 LOI\$\_TERM\_ERR error message • *LIO*, 5-24  
 LPG\_MULTIPLOT.FOR sample program • *LGP*, 6-4  
 LSP\$APPLY\_SPECTRAL\_WINDOWS\_TABLE  
     routine • *LSP*, 6-5  
 LSP\$BUILD\_WINDOW\_TABLE routine • *LSP*, 6-8  
 LSP\$CORRELATION routine • *LSP*, 6-11  
 LSP\$FFT\_COMPLEX routine • *LSP*, 6-14  
 LSP\$FFT\_COMPLEX\_2D routine • *LSP*, 6-17  
 LSP\$FFT\_REAL routine • *LSP*, 6-20  
 LSP\$FILTER\_NONREC routine • *LSP*, 6-23  
 LSP\$FILTER\_POLY routine • *LSP*, 6-26  
 LSP\$FILTER\_POLY\_1ST\_DERIV routine • *LSP*, 6-29  
 LSP\$FILTER\_POLY\_2ND\_DERIV routine • *LSP*, 6-32  
 LSP\$FILTER\_POLY\_3RD\_DERIV routine • *LSP*, 6-35

LSP\$FORMAT\_TRANSLATE\_ADC routine • LSP, 6-38  
LSP\$FORMAT\_TRANSLATE\_DAC routine • LSP, 6-41  
LSP\$HIST\_F routine • LSP, 6-45  
LSP\$HIST\_I routine • LSP, 6-49  
LSP\$PHASE\_ANGLE routine • LSP, 6-53  
LSP\$PHASE\_ANGLE\_2D routine • LSP, 6-56  
LSP\$POWER\_SPECTRUM routine • LSP, 6-59  
LSP\$SPECTRAL\_WINDOWS routine • LSP, 6-62  
LSP\$THERMOCOUPLE\_X routine • LSP, 6-65  
LSP sample programs • LSP, 8-1  
LVP16  
    LGP\_CHANGE\_LOGICALS.FOR sample program • LGP, 6-2  
LVP16 plotter • LGP, 4-57  
    plotting capabilities • LGP, 1-14

---

## M

Mail Utility • INSTALL, 5-3  
Main Menu • IDAT, 2-2  
    EXIT option • IDAT, 1-16  
Maintenance Utilities  
    using the Backup Utility • GETSTART, 2-43  
    using the Restore Utility • GETSTART, 2-45  
Making a pass through IDAT • IDAT, 1-6  
Manager Utility  
    management tasks • GETSTART, 2-6  
    overview • GETSTART, 2-2  
    running MANAGER • GETSTART, 2-4  
    using the function keys • GETSTART, 2-4  
Mapping colors to pen numbers • LGP, 4-57  
MAXBUF parameter • INSTALL, 5-4  
Maximum axis lengths • LGP, 1-7  
Memory-mapped I/O • LIO, 1-7  
Memory queue device • LIO, 2-150 to 2-159  
    AST routines • LIO, 4-22  
    asynchronous I/O • LIO, 4-24  
    attaching • LIO, 2-151  
    buffer forwarding • LIO, 4-143  
    buffer size • LIO, 4-37  
    buffer source • LIO, 4-39  
    buffer transfer • LIO, 4-252  
    device event flag • LIO, 4-97  
    global section name • LIO, 4-180  
    interprocess display-only • LIO, 4-103

Memory queue device (Cont.)  
    number of buffers • LIO, 4-177  
    page-aligning buffers • LIO, 4-185  
    parameters valid for • LIO, 2-151  
    read-only device • LIO, 4-210  
    read-only global section • LIO, 4-210  
    setting up • LIO, 2-151  
    synchronous I/O • LIO, 4-239  
    transferring data buffers • LIO, 4-252

Menus  
    conventions for use • IDAT, 1-8  
    Data Analysis • IDAT, 2-6  
    generic screen layout • IDAT, 1-9  
    Input Source • IDAT, 2-3  
    Main • IDAT, 2-2  
    Output Destination • IDAT, 2-7

Metafile  
    CGM • LGP, 2-10  
    GKS • LGP, 2-10  
    plotting a previously stored • LGP, 4-78

Micro488A  
    See IOtech Micro488A  
Modifying a user account • GETSTART, 2-13  
MODPARAMS.DAT • INSTALL, 5-4  
Mounting a device • GETSTART, 2-32  
Multicolor plotting • LGP, 1-15  
Multiple Input Channel Selection screen • IDAT, 2-28  
Multiple plots  
    basic information • LGP, 3-1 to 3-3  
    creating • LGP, 3-1 to 3-8  
Multiplexers  
    IAV11-C • LIO, 2-91  
    IAV11-CA • LIO, 2-91

---

## N

Nonrecursive filtering • LSP, 6-23  
    bandpass • LSP, 3-3  
    bandstop • LSP, 3-3  
    highpass • LSP, 3-3  
    lowpass • LSP, 3-3  
    mathematical equation • LSP, 3-4  
    sample program • LSP, 3-6  
Number  
    workstation • LGP, 3-1  
Nyquist frequency • LSP, 3-3

---

## O

---

- Obtaining device IDs • *LIO*, 3-3
- Online programs
  - See Sample programs
- Online sample programs
  - See Sample programs
- Optional software • *INSTALL*, 4-10
- Output
  - character • *LGP*, 1-19
- Output Channel Selection screen • *IDAT*, 2-29
- Output Destination Menu • *IDAT*, 2-7
- Output frequencies
  - generating using the IDV11-D • *LIO*, 2-113
- Overview
  - of laboratory graphics • *LGP*, 1-1

---

## P

---

- Packaged systems • *INSTALL*, 3-1
- Page-aligning buffers • *LIO*, 1-24
- PAK
  - for new VAXlab systems • *INSTALL*, 2-2
  - for VAXlab systems • *INSTALL*, 3-4
  - for VSL upgrade • *INSTALL*, 4-2
  - installing • *INSTALL*, 2-2, 3-4, 4-2
  - registering • *INSTALL*, 2-2, 3-4, 4-2
- Parallel I/O devices
  - DRB32 • *LIO*, 2-67 to 2-74
  - DRB32W • *LIO*, 2-74 to 2-77
  - DRQ3B • *LIO*, 2-78 to 2-82
  - DRV11-J • *LIO*, 2-83 to 2-86
  - DRV11-WA • *LIO*, 2-86 to 2-89
- Parallel polling
  - configuring for • *LIO*, 4-188
  - enabling • *LIO*, 4-186
  - status register • *LIO*, 4-191
- Parameters
  - list of • *LIO*, 4-2 to 4-11
- Parameter settings
  - checking • *INSTALL*, 4-3, 5-4
- PASCAL program development • *GETSTART*, 3-57
  - checking routine call status • *GETSTART*, 3-64
  - creating environment files • *GETSTART*, 3-58
- PASCAL program development (Cont.)
  - declaring and dimensioning arrays • *GETSTART*, 3-61
  - declaring data types and variables • *GETSTART*, 3-59
  - declaring external routines • *GETSTART*, 3-62
  - defaulting routine call arguments • *GETSTART*, 3-62
  - including symbolic definition files • *GETSTART*, 3-57
- Password
  - changing • *INSTALL*, 5-2
- Paths
  - installation • *INSTALL*, 1-1
- PCR (Programmable Clock Register) • *LIO*, 4-196
- PEAK
  - See Peak Processing Package
- Peak Processing Package (PEAK) • *INSTALL*, 4-8, 4-11
- Periodogram
  - power spectrum • *LSP*, 4-2
- [PF3]** key • *IDAT*, 1-8, 1-11
- Phase angle and amplitude spectra • *LSP*, 6-53, 6-56
- Plotting
  - a data set • *LGP*, 4-59
  - additional data sets • *LGP*, 4-89
  - a metafile • *LGP*, 4-78
  - a standard deviation marker • *LGP*, 4-130
  - a three-dimensional array • *LGP*, 4-80, 4-121, 4-134
  - a two-dimensional array • *LGP*, 4-59, 4-115
  - coordinate points • *LGP*, 4-43
  - create menu screen • *LGP*, 4-32
  - data points • *LGP*, 4-95
  - device-dependent capabilities • *LGP*, 1-14
  - graph titles • *IDAT*, 2-15
  - histograms • *LGP*, 4-50
  - inputting a value • *LGP*, 4-46
  - labeling axes • *IDAT*, 2-15, 2-16
  - logarithmic scaling • *LGP*, 4-68
  - multicolor • *LGP*, 1-15
  - return coordinate value • *LGP*, 4-36
  - returning value of text string • *LGP*, 4-39
  - selecting A/D channel for single channel plot • *IDAT*, 2-33
  - symbols and shapes • *LGP*, 4-95
  - x-axis coordinates • *IDAT*, 2-39

## Plotting (Cont.)

- y-axis coordinates • *IDAT*, 2-40
- Plotting attribute list • *LGP*, 2-1 to 2-10
  - default values • *LGP*, 2-2 to 2-10
  - examining • *LGP*, 4-143
  - LGP\$TABLE\_MODIFY* • *LGP*, 4-142
  - modifying • *LGP*, 2-12, 4-141
  - ranges • *LGP*, 2-2 to 2-10
  - reading values • *LGP*, 2-11
  - resetting • *LGP*, 4-145
  - resetting default values • *LGP*, 2-13
  - symbolic status definition files • *LGP*, 1-13, 2-1
  - values • *LGP*, 2-2 to 2-10
- Plotting attributes
  - See Plotting attribute list
- Plotting data iteratively • *LGP*, 4-84
- Plotting device • *LIO*, 2-160 to 2-164
  - attaching • *LIO*, 2-162
  - channels to plot • *LIO*, 4-201
  - current channel title • *LIO*, 4-248
  - current channel x-axis label • *LIO*, 4-280
  - current channel y-axis label • *LIO*, 4-284
  - graph title • *LIO*, 4-248, 4-250
  - maximum number of channels • *LIO*, 4-169
  - maximum y value • *LIO*, 4-285
  - minimum y value • *LIO*, 4-286
  - number of channels in buffer • *LIO*, 4-177
  - parameters • *LIO*, 2-160
  - parameters valid for • *LIO*, 2-160
  - plotting style • *LIO*, 4-199
  - plotting window position • *LIO*, 4-204
  - plotting window size • *LIO*, 4-198
  - setting up • *LIO*, 2-160, 2-162
  - skipping points • *LIO*, 4-225
  - specifying current channel • *LIO*, 4-86
  - starting continuous plotting • *LIO*, 4-230
  - x-axis format • *LIO*, 4-174
  - x-axis range • *LIO*, 4-281

## Plotting devices

- supported • *LGP*, 1-6 to 1-8
- Plotting device support • *LGP*, 1-6 to 1-8
- Plotting routine hierarchy • *LGP*, 1-4

## Plotting routines

- LGP\$3D\_SIMPLE* • *LGP*, 4-134
- LGP\$CHANGE\_PLOTTING\_LOGICALS* • *LGP*, 4-5

## Plotting routines (Cont.)

- LGP\$CONTOUR* • *LGP*, 4-8
- LGP\$CONTOURM* • *LGP*, 4-24
- LGP\$CONTOUR\_SHADE* • *LGP*, 4-16
- LGP\$ERASE* • *LGP*, 4-29
- LGP\$GET\_CHOICE* • *LGP*, 4-32
- LGP\$GET\_LOCATOR* • *LGP*, 4-36
- LGP\$GET\_STRING* • *LGP*, 4-39
- LGP\$GET\_STROKE* • *LGP*, 4-43
- LGP\$GET\_VALUE* • *LGP*, 4-46
- LGP\$HIST* • *LGP*, 4-50
- LGP\$INFO* • *LGP*, 4-55
- LGP\$MAP\_PEN* • *LGP*, 4-57
- LGP\$PLOT* • *LGP*, 4-59
- LGP\$PLOT\_C* • *LGP*, 4-84
- LGP\$PLOT\_M* • *LGP*, 4-89
- LGP\$PLOT\_3D* • *LGP*, 4-80
- LGP\$PLOT\_LOG* • *LGP*, 4-68
- LGP\$PLOT\_METAFILE* • *LGP*, 4-78
- LGP\$POINT* • *LGP*, 4-95
- LGP\$PRINT\_SCREEN* • *LGP*, 4-100
- LGP\$PUT\_TEXT* • *LGP*, 4-102
- LGP\$SCALE* • *LGP*, 4-108
- LGP\$SCALE\_LOG* • *LGP*, 4-111
- LGP\$SET\_3D\_GRAPH* • *LGP*, 4-121
- LGP\$SET\_GRAPH* • *LGP*, 4-115
- LGP\$SPLINE\_QHC* • *LGP*, 4-126
- LGP\$STNDEV* • *LGP*, 4-130
- LGP\$TABLE\_MODIFY* • *LGP*, 4-141
- LGP\$TABLE\_READ\_VALUE* • *LGP*, 4-143
- LGP\$TABLE\_RESET* • *LGP*, 4-145
- LGP\$TERMINATE\_PLOT* • *LGP*, 4-146
  - summary of • *LGP*, 4-1
- Point Size Specification screen • *IDAT*, 2-30
- Polled I/O • *LIO*, 1-7
- Polynomial filtering
  - definition • *LSP*, 3-1
  - for smoothing • *LSP*, 6-26
    - with first-derivative output • *LSP*, 6-29
    - with second-derivative output • *LSP*, 6-32
    - with third-derivative output • *LSP*, 6-35
- Port Specification screen • *IDAT*, 2-31
- Postinstallation
  - procedures • *INSTALL*, 5-1 to 5-7
  - tasks • *INSTALL*, 5-1 to 5-7
- Power spectrum • *IDAT*, 3-27; *LSP*, 6-59
  - periodogram technique • *LSP*, 4-2
- Preinstallation information • *INSTALL*, 1-1 to 1-4

## Preinstalled software

- VAXlab system • *INSTALL*, 2-1
- Prerequisites • *INSTALL*, 1-2 to 1-3
- Preston • *LIO*, 2-61 to 2-67
  - A/D channels • *IDAT*, 2-10; *LIO*, 4-13, 4-176
  - adding an A/D channel • *LIO*, 4-19
  - AST routines • *LIO*, 4-22
  - asynchronous input • *LIO*, 4-24
  - attaching • *LIO*, 2-62
  - bit precision • *IDAT*, 2-17
  - buffer forwarding • *LIO*, 4-143
  - burst rate clock • *IDAT*, 3-26
  - burst rate divisor • *LIO*, 4-41
  - channel burst rate • *LIO*, 4-43
  - clock rate and divider • *LIO*, 4-55
  - continuous DMA • *LIO*, 4-70
  - device event flag • *LIO*, 4-97
  - FIFO buffers • *LIO*, 1-16
  - initialize channel list • *LIO*, 4-161
  - internal clock base frequency • *LIO*, 4-51
  - internal clock divider • *LIO*, 4-53
  - internal sampling rate clock • *IDAT*, 3-26
  - number of samples • *IDAT*, 2-10
  - parameters valid for • *LIO*, 2-63
  - Preston buffer size • *LIO*, 4-37
  - setting up • *LIO*, 2-63
  - single-buffer DMA • *LIO*, 4-223
  - starting continuous DMA • *LIO*, 4-230
  - stopping continuous DMA • *LIO*, 4-235
  - synchronous input • *LIO*, 4-239
  - timeout • *LIO*, 4-245
  - trigger modes • *IDAT*, 2-32, 3-25; *LIO*, 4-253
  - updating set-up information • *LIO*, 4-268
- Preston Trigger Mode Selection screen • *IDAT*, 2-32
- Print queues
  - deleting • *GETSTART*, 2-17
  - restarting • *GETSTART*, 2-16
  - setting up • *GETSTART*, 2-14
  - showing status • *GETSTART*, 2-24
  - stopping • *GETSTART*, 2-17
- Problems
  - reporting • *INSTALL*, 5-7
- Processors
  - not supported for VSL • *INSTALL*, 1-3
  - supported for VSL 1.4 • *INSTALL*, 1-3

## Producing

- See Creating
- Product authorization key
  - See PAK
- Program development
  - compiling program source code • *GETSTART*, 3-2
  - creating program source code • *GETSTART*, 3-1
  - debugging programs • *GETSTART*, 3-3
  - executing programs • *GETSTART*, 3-3
  - linking object files • *GETSTART*, 3-2
  - overview • *GETSTART*, 3-1
  - using VAX Ada • *GETSTART*, 3-4
  - using VAX BASIC • *GETSTART*, 3-21
  - using VAX C • *GETSTART*, 3-33
  - using VAX FORTRAN • *GETSTART*, 3-45
  - using VAX PASCAL • *GETSTART*, 3-57
- Programming
  - with LGP routines • *LGP*, 1-20
- Programs
  - See Sample programs
- Protocol
  - user-defined • *LIO*, 4-12
- Pseudodevices • *LIO*, 2-146 to 2-164
  - disk file • *LIO*, 2-146 to 2-150
  - memory queue • *LIO*, 2-150 to 2-159
  - real-time plotting • *LIO*, 2-160 to 2-164
- Pulse duration
  - measuring using the IDV11-D • *LIO*, 2-108
- Pulse trains
  - generating using the IDV11-D • *LIO*, 2-112

---

## Q

- QIOs • *LIO*, 1-6
- Queueing buffers • *LIO*, 3-15
- Queue management tasks
  - deleting a batch queue • *GETSTART*, 2-22
  - deleting a print queue • *GETSTART*, 2-17
  - restarting a batch queue • *GETSTART*, 2-21
  - restarting a print queue • *GETSTART*, 2-16
  - setting up a batch queue • *GETSTART*, 2-19
  - setting up a print queue • *GETSTART*, 2-14
  - showing queue status • *GETSTART*, 2-24
  - stopping a batch queue • *GETSTART*, 2-22
  - stopping a print queue • *GETSTART*, 2-17

Queue manager • *INSTALL*, 5-3

#### Queues

device • *LIO*, 1-3

user • *LIO*, 1-3

#### Quotas

user accounts • *INSTALL*, 5-5

---

## R

---

Reading a buffer from a device • *LIO*, 3-24

Real-time clock module • *IDAT*, 1-2

#### Real-time clocks

See Clock

#### Real-time plotting device

See Plotting device

REALTIME\_SPTS parameter • *INSTALL*, 5-4

Rebooting • *INSTALL*, 5-6

Release notes • *INSTALL*, 1-1

accessing • *INSTALL*, 5-2

copying • *INSTALL*, 4-6

displaying • *INSTALL*, 4-6

printing • *INSTALL*, 4-6

Removing a node from DECnet • *GETSTART*, 2-29

Reporting problems • *INSTALL*, 5-7

#### Requirements

installation • *INSTALL*, 1-2

Restarting a stalled batch queue • *GETSTART*, 2-21

Restarting a stalled print queue • *GETSTART*, 2-16

Restore Utility • *GETSTART*, 2-45

Returning device IDs • *LIO*, 3-3

Returning parameter values • *LIO*, 3-35

RING signal • *LIO*, 4-173

#### Routine calls

checking status • *LGP*, 5-2

summary of • *LGP*, 4-1

#### Routines

summary of • *LGP*, 4-1

#### RS/1 files

file names • *IDAT*, 2-24

#### RTC01

See Simpact RTC01

RTS/CTS • *LIO*, 4-139

RTS signal • *LIO*, 4-173

Running IDAT • *IDAT*, 1-6

Running the Manager Utility • *GETSTART*, 2-4

Run-time library • *LGP*, 5-1

---

## S

---

#### Sample dialogue

VSL installation • *INSTALL*, A-1

#### Sample programs

creating multiple plots • *LGP*, 3-4

LGP routine call programming • *LGP*, 1-21

listing • *LIO*, 6-3 to 6-20

overview • *LGP*, 6-1

table of • *LGP*, 6-2 to 6-6

using LSP routines • *LSP*, 8-1

#### Sample session

data file • *IDAT*, 4-2

input data source • *IDAT*, 4-2

power spectrum • *IDAT*, 4-6

producing a multiple channel plot • *IDAT*, 4-4

producing a single channel plot • *IDAT*, 4-7

running IDAT • *IDAT*, 4-3

TESTDATA.DAT • *IDAT*, 4-2

using a disk file as input • *IDAT*, 4-3

#### Sampling rate

establishing for Preston • *LIO*, 4-41

Scientific Subroutines Package (SSP) • *INSTALL*, 4-8, 4-11

Screen forms interface • *IDAT*, 1-7

#### Screens

A/D Samples and Channel Gains • *IDAT*, 2-12

A/D Samples and Channels • *IDAT*, 2-10

Autoscaling Option • *IDAT*, 2-16

Axes Labels • *IDAT*, 2-15

Bit Precision Specification • *IDAT*, 2-17

Channel Selection • *IDAT*, 2-18

Clock Function Selection • *IDAT*, 2-19

Clock Rate Selection • *IDAT*, 2-20

Clock Source Selection • *IDAT*, 2-21

Clock Trigger Selection • *IDAT*, 2-22

Data Length Specification • *IDAT*, 2-23

File Name Specification • *IDAT*, 2-24

Handshake Enable/Disable • *IDAT*, 2-25

Input Channel Selection • *IDAT*, 2-27

Multiple Input Channel Selection • *IDAT*, 2-28

Output Channel Selection • *IDAT*, 2-29

Point Size Specification • *IDAT*, 2-30

Port Specification • *IDAT*, 2-31

Preston Trigger Mode Selection • *IDAT*, 2-32



## Screens (Cont.)

- Single Input Channel Selection • *IDAT*, 2-33
- Sweep Clock Rate Selection • *IDAT*, 2-37
- Trigger Mode Selection • *IDAT*, 2-38
- X-Axis Coordinates Selection • *IDAT*, 2-39
- Y-Axis Coordinates Selection • *IDAT*, 2-40
- Selecting analysis operations • *IDAT*, 2-6
- Selecting input devices • *IDAT*, 2-3
- Selecting options from menus • *IDAT*, 1-8
- Selecting output destinations • *IDAT*, 2-7
- Serial line device • *LIO*, 2-140 to 2-146
  - ACK/NAK buffer • *LIO*, 4-96
  - ACK AST routine • *LIO*, 4-269
  - ACK string • *LIO*, 4-270
  - AST routines • *LIO*, 4-22, 4-81
  - asynchronous I/O • *LIO*, 4-24
  - attaching • *LIO*, 2-140
  - baud rate • *LIO*, 4-29 to 4-31
  - break (spacing) condition • *LIO*, 4-36
  - buffer forwarding • *LIO*, 4-143
  - buffer terminator • *LIO*, 4-162
  - canceling pending I/O requests • *LIO*, 4-235
  - characters in type-ahead buffer • *LIO*, 4-267
  - control character handling • *LIO*, 4-83
  - data bits per character • *LIO*, 4-33
  - device event flag • *LIO*, 4-97
  - duplex mode • *LIO*, 4-108
  - echoing • *LIO*, 4-110
  - flow control • *LIO*, 4-139
  - full-duplex mode • *LIO*, 4-108
  - half-duplex mode • *LIO*, 4-108
  - input terminator • *LIO*, 4-162
  - modem disconnect • *LIO*, 4-158
  - modem status • *LIO*, 4-172
  - modem use • *LIO*, 4-170
  - NAK AST routine • *LIO*, 4-271
  - NAK string • *LIO*, 4-272
  - output prefix • *LIO*, 4-183
  - output terminator • *LIO*, 4-184
  - parameters valid for • *LIO*, 2-140
  - parity checking • *LIO*, 4-193
  - parity error handling • *LIO*, 4-120
  - protocol AST routine • *LIO*, 4-273
  - purging type-ahead buffer • *LIO*, 4-209
  - read prompt • *LIO*, 4-211
  - repriming the serial line • *LIO*, 4-283
  - setting up • *LIO*, 2-140
  - synchronous I/O • *LIO*, 4-239

## Serial line device (Cont.)

- timeout • *LIO*, 4-245
- timeout enable • *LIO*, 4-247
- type-ahead buffer • *LIO*, 4-264
- user-defined protocol • *LIO*, 4-12, 4-206, 4-275
- XOFF/XON flow control • *LIO*, 4-141
- Serial polling • *LIO*, 4-219
  - configuring for • *LIO*, 4-221
- Setting channels • *LIO*, 4-50
- Setting up a batch queue • *GETSTART*, 2-19
- Setting up a graph • *LGP*, 4-115
- Setting up a print queue • *GETSTART*, 2-14
- Setting up I/O devices
  - A/D channel gains • *LIO*, 4-17
  - A/D channels • *LIO*, 4-13
  - AAF01 • *LIO*, 2-14
  - AAV11-D • *LIO*, 2-23
  - ACK/NAK buffer • *LIO*, 4-96
  - ADF01 • *LIO*, 2-29
  - ADQ32 • *LIO*, 2-40
  - ADQ32 diagnostic inputs • *LIO*, 4-99
  - ADV11-D • *LIO*, 2-45
  - AST routines • *LIO*, 4-22, 4-104
  - asynchronous I/O • *LIO*, 4-24
  - AXV11-C • *LIO*, 2-50
  - baud rate • *LIO*, 4-29
  - break (spacing) condition • *LIO*, 4-36
  - buffer size • *LIO*, 4-37
  - buffer source • *LIO*, 4-39
  - burst rate divisor • *LIO*, 4-41
  - canceling outstanding I/O • *LIO*, 4-45
  - channel burst rate • *LIO*, 4-43
  - character echoing • *LIO*, 4-110
  - clearing large buffer overflow • *LIO*, 4-61
  - clearing sequence timer enable bit • *LIO*, 4-234
  - clock rate and divider • *LIO*, 4-55
  - clock source and divider • *LIO*, 4-58
  - Command Output (COUT) bit • *LIO*, 4-63
  - connect-to-interrupt handler overhead • *LIO*, 4-78
  - connect-to-interrupt I/O • *LIO*, 4-75
  - continuous DMA • *LIO*, 4-70
  - D/A channels • *LIO*, 4-89
  - data bits per character • *LIO*, 4-33
  - deactivating controller function • *LIO*, 4-85
  - device event flag • *LIO*, 4-97

## Setting up I/O devices (Cont.)

- differential input • *LIO*, 4–15
- disabling character echoing • *LIO*, 4–110
- disk file • *LIO*, 2–147
- DRB32 • *LIO*, 2–68
- DRB32 parallel data path • *LIO*, 4–91
- DRB32 parallel data path width • *LIO*, 4–94
- DRB32W • *LIO*, 2–75
- DRQ11-C • *LIO*, 2–55
- DRQ3B • *LIO*, 2–79
- DRV11-J • *LIO*, 2–84
- DRV11-WA • *LIO*, 2–87
- enabling character echoing • *LIO*, 4–110
- error handling • *LIO*, 5–4
- frequency output reference signal • *LIO*, 4–46
- I/O direction • *LIO*, 4–101
- IAV11-A • *LIO*, 2–92
- IAV11-B • *LIO*, 2–96
- IDV11-A • *LIO*, 2–99
- IDV11-B • *LIO*, 2–102
- IDV11-D • *LIO*, 2–105, 4–48
- IEEE-488 active controller function • *LIO*, 4–79
- IEEE-488 commands • *LIO*, 4–64
  - auxiliary • *LIO*, 4–26
- IEQ11 • *LIO*, 2–120
- IEZ11 • *LIO*, 2–120
- IOtech Micro488A • *LIO*, 2–120
- KWV11-C • *LIO*, 2–3
- loading Control Table Address (CTA) register • *LIO*, 4–74
- memory queue • *LIO*, 2–151
- memory queue display-only process • *LIO*, 4–103
- moving output voltage to DDR • *LIO*, 4–32
- moving voltage to DAC Data Register • *LIO*, 4–277
- outputting a voltage value • *LIO*, 4–21
- Preston • *LIO*, 2–63
- Preston base frequency • *LIO*, 4–51
- Preston divider • *LIO*, 4–53
- Programmable Clock Register • *LIO*, 4–196
- reading Control Word Registers • *LIO*, 4–87
- real-time plotting • *LIO*, 2–160
- sequence timer • *LIO*, 4–228
- serial line • *LIO*, 2–140
- serial line character echoing • *LIO*, 4–110
- serial line duplex mode • *LIO*, 4–108
- setting A/D or D/A channel • *LIO*, 4–50

## Setting up I/O devices (Cont.)

- Simpac RTC01 • *LIO*, 2–3
- single-ended input • *LIO*, 4–15
- sizing the plotting window • *LIO*, 4–198
- specifying device trigger mode • *LIO*, 4–253
- specifying error handling method • *LIO*, 4–118
- stopping continuous DMA • *LIO*, 4–45
  - using LIO\$SET\_I • *LIO*, 3–29
  - using LIO\$SET\_R • *LIO*, 3–31
  - using LIO\$SET\_S • *LIO*, 3–33
- writing Control Word Registers • *LIO*, 4–87
- x-axis range • *LIO*, 4–281
- Showing device status • *GETSTART*, 2–41
- Showing queue status • *GETSTART*, 2–24
- Shutting down • *INSTALL*, 5–6
- Signal-processing routines
  - LSP\$APPLY\_SPECTRAL\_WINDOWS\_TABLE • *LSP*, 6–5
  - LSP\$BUILD\_WINDOW\_TABLE • *LSP*, 6–8
  - LSP\$CORRELATION • *LSP*, 6–11
  - LSP\$FFT\_COMPLEX • *LSP*, 6–14
  - LSP\$FFT\_COMPLEX\_2D • *LSP*, 6–17
  - LSP\$FFT\_REAL • *LSP*, 6–20
  - LSP\$FILTER\_NONREC • *LSP*, 6–23
  - LSP\$FILTER\_POLY • *LSP*, 6–26
    - LSP\$FILTER\_POLY\_1ST\_DERIV • *LSP*, 6–29
    - LSP\$FILTER\_POLY\_2ND\_DERIV • *LSP*, 6–32
    - LSP\$FILTER\_POLY\_3RD\_DERIV • *LSP*, 6–35
  - LSP\$FORMAT\_TRANSLATE\_ADC • *LSP*, 6–38
  - LSP\$FORMAT\_TRANSLATE\_DAC • *LSP*, 6–41
  - LSP\$HIST\_F • *LSP*, 6–45
  - LSP\$HIST\_I • *LSP*, 6–49
  - LSP\$PHASE\_ANGLE • *LSP*, 6–53
  - LSP\$PHASE\_ANGLE\_2D • *LSP*, 6–56
  - LSP\$POWER\_SPECTRUM • *LSP*, 6–59
  - LSP\$SPECTRAL\_WINDOWS • *LSP*, 6–62
  - LSP\$THERMOCOUPLE\_X • *LSP*, 6–65
- Simpac RTC01 • *LIO*, 2–1 to 2–11
  - AST routines • *LIO*, 4–22
  - asynchronous I/O • *LIO*, 4–24, 4–55
  - attaching • *LIO*, 2–2
  - buffer forwarding • *LIO*, 4–143
  - clock function • *LIO*, 4–145
  - clock source and divider • *LIO*, 4–58
  - device event flag • *LIO*, 4–97
  - event ASTs • *LIO*, 4–121
  - external event flags • *LIO*, 4–125
  - FIFO buffers • *LIO*, 1–16

## Simpact RTC01 (Cont.)

- interrupt level
    - setting • *LIO*, 4-163
  - parameters valid for • *LIO*, 2-3
  - reading the count register • *LIO*, 4-72
  - Schmitt trigger operation • *LIO*, 4-217
  - setting up • *LIO*, 2-3
  - starting the clock • *LIO*, 4-230
  - stopping the clock • *LIO*, 4-235
  - synchronous I/O • *LIO*, 4-239
  - timeout • *LIO*, 4-245
  - trigger modes • *LIO*, 4-253
  - Single-buffer DMA • *LIO*, 1-19 to 1-20, 4-223
  - Single Input Channel Selection screen • *IDAT*, 2-33
  - Software pseudodevices • *LIO*, 2-146 to 2-164
  - Spacing condition • *LIO*, 4-36
  - Spectral window
    - symbolic status definition files • *LSP*, 4-14
  - Spectral window filtering
    - applying coefficient table • *LSP*, 6-5
    - building coefficient table • *LSP*, 6-8
    - LSP*\$SPECTRAL\_WINDOWS routine • *LSP*, 6-62
  - LSP window algorithms • *LSP*, 4-4
  - LSP window routines • *LSP*, 4-4
  - periodogram technique • *LSP*, 4-2
  - sample program • *LSP*, 4-9
  - spectral window reference list • *LSP*, 4-14
  - window types illustration • *LSP*, 4-6
- Spectral Window routine • *LSP*, 6-62
- Spectral windows
  - symbolic status definition files • *LSP*, 4-14
- SSP
- See Scientific Subroutines Package
- Startup command files
  - editing • *INSTALL*, 5-2
  - SYLOGIN.COM* • *INSTALL*, 5-3
  - SYSTARTUP\_V5.COM* • *INSTALL*, 5-3
- Status
  - checking • *LGP*, 5-2
- Stopping a batch queue • *GETSTART*, 2-22
- Stopping a print queue • *GETSTART*, 2-17
- Storing data in a disk file • *IDAT*, 1-7
- Structure
  - of document • *LGP*, ix; *INSTALL*, vii
- Structure of document • *LIO*, xix
- Supported devices • *LGP*, 1-6 to 1-8

- Sweep clock rate • *IDAT*, 2-37
- Sweep Clock Rate Selection screen • *IDAT*, 2-37
- SYLOGIN.COM* • *INSTALL*, 5-3
- Symbolic status definition files
  - error code • *LGP*, 1-13
  - plotting attribute list • *LGP*, 1-13, 2-1
- Synchronous I/O • *LIO*, 1-2
  - application uses • *LIO*, 1-3
  - LIO*\$READ routine • *LIO*, 1-2
  - LIO*\$WRITE routine • *LIO*, 1-2
  - using disk files • *LIO*, 2-148
  - using serial line devices • *LIO*, 2-143
  - using the DRB32 • *LIO*, 2-70
  - using the DRB32W • *LIO*, 2-76
  - using the DRQ11-C • *LIO*, 2-56
  - using the DRQ3B • *LIO*, 2-80
  - using the DRV11-WA • *LIO*, 2-88
- Synchronous input
  - using the ADF01 • *LIO*, 2-31
  - using the ADQ32 • *LIO*, 2-42
  - using the AXV11-C • *LIO*, 2-51
  - using the IAV11-A • *LIO*, 2-92
  - using the IDV11-A • *LIO*, 2-100
  - using the Preston • *LIO*, 2-65
- Synchronous output
  - using the AAF01 • *LIO*, 2-15
  - using the AAV11-D • *LIO*, 2-24
  - using the IAV11-B • *LIO*, 2-97
- Synchronous Output
  - using the IDV11-B • *LIO*, 2-103
- SYS*\$ERROR • *LGP*, 5-1
- SYS*\$HELP • *INSTALL*, 4-6, 4-11, 5-2
- SYS*\$OUTPUT • *LGP*, 5-1
- SYS*\$STARTUP:SYLOGIN.COM • *INSTALL*, 5-3
- SYS*\$SYSDEVICE • *INSTALL*, 4-3
- SYS*\$SYSROOT:[UNSUPPORTED.SSP] • *INSTALL*, 4-11
- SYS*\$SYSTEM:MODPARAMS.DAT • *INSTALL*, 5-4
- SYS*\$SYSTEM:SHUTDOWN.COM • *INSTALL*, 5-7
- SYS*\$SYSTEM:SYSGEN • *INSTALL*, 4-3
- SYS*\$UPDATE:AUTOGEN • *INSTALL*, 5-4
- SYS*\$UPDATE:VMSINSTAL.COM • *INSTALL*, 4-4
- SYS*\$UPDATE:VMSLICENSE.COM • *INSTALL*, 2-2, 3-4, 4-2
- SYSGEN • *INSTALL*, 4-3
- SYSTARTUP\_V5.COM* • *INSTALL*, 5-3

## SYSTEM account

- changing password • *INSTALL*, 5-2
- unauthorized access • *INSTALL*, 5-2

## System configuration command file

- modifying • *INSTALL*, 5-6
- SYCONFIG.COM • *INSTALL*, 5-6

## System disk

- backing up • *INSTALL*, 4-2, 4-5
- danger of erasing • *INSTALL*, 3-1

## System Generation Utility • *INSTALL*, 4-3

## System management

- DECnet management tasks • *GETSTART*, 2-25
- device management tasks • *GETSTART*, 2-32
- maintenance utilities • *GETSTART*, 2-43
- queue management tasks • *GETSTART*, 2-14
- system planning • *GETSTART*, 2-1
- using the Manager Utility • *GETSTART*, 2-2
- VMS management tasks • *GETSTART*, 2-8

## System Management

- tasks • *GETSTART*, 2-6

## System parameters • *INSTALL*, 5-4

- checking • *INSTALL*, 4-3, 5-4
- MAXBUF • *INSTALL*, 5-4
- modifying • *INSTALL*, 5-4
- REALTIME\_SPTS • *INSTALL*, 5-4
- TTY\_ALTYPAMD • *INSTALL*, 5-4
- TTY\_TYPAHDSZ • *INSTALL*, 5-4

## System quotas

- setting • *INSTALL*, 5-5

## Systems

- not supported for VSL • *INSTALL*, 1-3
- packaged • *INSTALL*, 3-1
- supported for VSL 1.4 • *INSTALL*, 1-3

## System tape

- contents of • *INSTALL*, 3-1

## System tape cartridge

- loading • *INSTALL*, 3-2

---

## T

### Template format • *LGP*, 4-4

### Terminal screen

- directing output to • *LGP*, 1-19

### Terminal types

- supported • *INSTALL*, 4-8

### Termination characters • *LIO*, 2-139

### TESTDATA.DAT

### TESTDATA.DAT (Cont.)

- input data source • *IDAT*, 4-2

### Thermocouple conversion • *LSP*, 5-1

- LSP\$THERMOCOUPLE\_X • *LSP*, 5-1
- temperature and voltage ranges • *LSP*, 5-2

### Thermocouple conversion routines • *LSP*, 5-1

### Times

- installation • *INSTALL*, 1-4

### Timing external events

- using the KVV11-C • *LIO*, 2-4
- using the Simpact RTC01 • *LIO*, 2-4

### Transferring data

- using the memory queue • *LIO*, 2-155

### Triggering data transfers

- using the KVV11-C • *LIO*, 2-7

### Trigger Mode Selection screen • *IDAT*, 2-38

### Trigger slivering • *LIO*, 2-10

### TTY\_ALTYPAMD parameter • *INSTALL*, 5-4

### TTY\_TYPAHDSZ parameter • *INSTALL*, 5-4

### Turning DECnet on or off • *GETSTART*, 2-30

---

## U

### Unsupported software • *INSTALL*, 4-10

- key • *IDAT*, 1-8

### User queue • *LIO*, 1-3

- Using the  key • *IDAT*, 1-8

- Using the  key • *IDAT*, 1-8, 1-11

- Using the  key • *IDAT*, 1-11

- Using the  key • *IDAT*, 1-8

---

## V

### Value

- inputting • *LGP*, 4-46

### VAXcluster • *INSTALL*, 1-4

### VAX GKS • *GETSTART*, 1-5

### VAXlab

- hardware overview • *GETSTART*, 1-2

- software overview • *GETSTART*, 1-5

- system overview • *GETSTART*, 1-1

### VAXlab/2000 • *INSTALL*, 3-1

### VAXlab/3400 • *INSTALL*, 3-2

### VAXlab/3500 • *INSTALL*, 3-2

### VAXlab/GPX • *INSTALL*, 3-1

### VAXlab/MFG • *INSTALL*, 3-1

### VAXlab/STD • *INSTALL*, 3-1

VAXlab/VSL system tape  
  contents of • *INSTALL*, 3-1  
  installing • *INSTALL*, 3-3  
  loading • *INSTALL*, 3-2

VAXlab signal-processing  
  analog-to-digital data translation • *LSP*, 1-1  
  calculating phase angles • *LSP*, 1-2  
  calculating the correlation function • *LSP*, 1-2  
  converting thermocouple voltages to  
    temperatures • *LSP*, 1-2  
  determining power spectra • *LSP*, 1-2  
  digital filtering • *LSP*, 1-2  
  digital-to-analog data translation • *LSP*, 1-1  
  Gibbs Phenomenon • *LSP*, 3-6  
  interval histogram analysis • *LSP*, 1-2  
  number representations • *LSP*, 1-3  
    binary • *LSP*, 1-3  
    offset binary • *LSP*, 1-4  
    two's complement • *LSP*, 1-4  
  Nyquist frequency • *LSP*, 3-3  
  performing Fourier transform • *LSP*, 1-1  
  spectral window filtering • *LSP*, 1-2

VAXlab Software Library  
  See VSL  
  components • *GETSTART*, 1-5  
  overview • *GETSTART*, 1-1

VAXlab system  
  powering up • *INSTALL*, 2-1 to 2-2  
  preinstalled software • *INSTALL*, 2-1

VMS Authorize Utility • *INSTALL*, 5-5  
VMSINSTAL.COM • *INSTALL*, 4-4  
VMSLICENSE.COM • *INSTALL*, 2-2, 3-4, 4-2  
VMS management tasks • *GETSTART*, 2-8  
  adding a user account • *GETSTART*, 2-8  
  changing account passwords • *GETSTART*,  
    2-14  
  deleting a user account • *GETSTART*, 2-11  
  displaying a list of user accounts • *GETSTART*,  
    2-10  
  modifying a user account • *GETSTART*, 2-13

VMS Run-Time Library and System Services •  
  *LGP*, 5-1

Voltage value  
  outputting • *LIO*, 4-21

VSL  
  components of • *INSTALL*, 4-1  
  installing • *INSTALL*, 4-1 to 4-13

VSL\$EXAMPLES • *IDAT*, 4-2  
VSL\$STARTUP.COM • *INSTALL*, 5-3  
VSL installation  
  sample dialogue • *INSTALL*, A-1  
VSL Release Notes  
  See Release notes

---

## W

---

WISS  
  using with *LGP* • *LGP*, 1-19  
Word-aligning buffers • *LIO*, 1-19  
Workstation Independent Segment Storage  
  See WISS  
Workstation number • *LGP*, 3-1  
Workstation types • *LGP*, 1-7  
Writing an output buffer to a device • *LIO*, 3-37  
Writing text to a plot • *LGP*, 4-102

---

## X

---

X-Axis Coordinates screen • *IDAT*, 2-39  
XOFF/XON • *LIO*, 4-139, 4-141

---

## Y

---

Y-Axis Coordinates screen • *IDAT*, 2-40



# Reader's Comments

VAXlab Master Index  
AV-KN98C-TE

Your comments and suggestions will help us improve the quality of our future documentation. Please note that this form is for comments on documentation only.

I rate this manual's:	Excellent	Good	Fair	Poor
Accuracy (product works as described)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (enough information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clarity (easy to understand)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (structure of subject matter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Figures (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Examples (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Index (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Page layout (easy to find information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

What I like best about this manual: \_\_\_\_\_

What I like least about this manual: \_\_\_\_\_

My additional comments or suggestions for improving this manual:

I found the following errors in this manual:

Page	Description
_____	_____
_____	_____
_____	_____

Please indicate the type of user/reader that you most nearly represent:

- |   |   |
|---|---|
| <input type="checkbox"/> Administrative Support | <input type="checkbox"/> Scientist/Engineer           |
| <input type="checkbox"/> Computer Operator      | <input type="checkbox"/> Software Support             |
| <input type="checkbox"/> Educator/Trainer       | <input type="checkbox"/> System Manager               |
| <input type="checkbox"/> Programmer/Analyst     | <input type="checkbox"/> Other (please specify) _____ |
| <input type="checkbox"/> Sales                  |   |

Name/Title \_\_\_\_\_ Dept. \_\_\_\_\_

Company \_\_\_\_\_ Date \_\_\_\_\_

Mailing Address \_\_\_\_\_

Phone \_\_\_\_\_

**digital**™

Please  
Affix Stamp  
Here

**DIGITAL EQUIPMENT CORPORATION**  
**Corporate User Publications**  
P.O. BOX 1001  
MARLBOROUGH, MA 01752-9840

Fold Here

Cut Along Dotted Line