

HEATH COMPANY · BENTON HARBOR, MICHIGAN

HEATH COMPANY PHONE DIRECTORY

The following telephone numbers are direct lines to the departments listed:

Kit orders and delivery information (616) 982-3411 Credit (616) 982-3561 Replacement Parts (616) 982-3571				
Technical Assistance Phone Numbers				

8:00 A.M. to 12 P.M. and 1:00 P.M. to 4:30 P.M., ES	T, Weekdays Only
R / C, Audio, and Electronic Organs	(616) 982-3310
Amateur Radio	(616) 982-3296
Test Equipment, Weather Instruments and	
Home Clocks	(616) 982-3315
Television	(616) 982-3307
Aircraft, Marine, Security, Scanners, Automotive,	
Appliances and General Products	(616) 982-3496
Computer Hardware	(616) 982-3309
Computer Software	(616) 982-3860
Heath Craft Wood Works	(616) 982-3423

YOUR HEATHKIT 90-DAY LIMITED WARRANTY

Consumer Protection Plan for Heathkit Consumer Products

Welcome to the Heath family. We believe you will enjoy assembling your kit and will be pleased with its performance. Please read this Consumer Protection Plan carefully. It is a "LIMITED WARRANTY" as defined in the U.S. Consumer Product Warranty and Federal Trade Commission Improvement Act. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Heath's Responsibility

PARTS -Replacements for factory defective parts will be supplied free for 90 days from date of purchase. Replacement parts are warranted for the remaining portion of the original warranty period. You can obtain warranty parts direct from Heath Company by writing or telephoning us at (616) 982-3571. And we will pay shipping charges to get those parts to you . . . anywhere in the world.

SERVICE LABOR - For a period of 90 days from the date of purchase, any malfunction caused by defective parts or error in design will be corrected at no charge to you. You must deliver the unit at your expense to the Heath factory, any Heathkit Electronic Center (units of Veritechnology Electronics Corporation), or any of our authorized overseas distributors.

XXXXXXXXXXXX

TECHNICAL CONSULTATION - You will receive free consuitation on any problem you might encounter in the assembly or use of your Heathkit product. Just drop us a line or give us a call. Sorry, we cannot accept collect calls.

NOT COVERED — The correction of assembly errors, adjustments, calibration, and damage due to misuse, abuse, or negligence are not covered by the warranty. Use of corrosive solder and/or the unauthorized modification of the product or of any furnished component will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, loss of use, customer assembly, set-up time, or unauthorized service.

This warranty covers only Heath products and is not extended to other equipment or components that a customer uses in conjunction with our products

SUCH REPAIR AND REPLACEMENT SHALL BE THE SOLE REMEDY OF THE CUSTOMER AND THERE SHALL BE NO LIABILITY ON THE PART OF HEATH FOR ANY SPECIAL INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO ANY LOSS OF BUSINESS OR PROFITS, WHETHER OR NOT FORSEEABLE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Owner's Responsibility

EFFECTIVE WARRANTY DATE — Warranty begins on the date of first consumer purchase. You must supply a copy of your proof of purchase when you request warranty service or parts.

ASSEMBLY — Before seeking warranty service, you should complete the assembly by carefully following the manual instructions. Heathkit service agencies cannot complete assembly and adjustments that are customer's responsibility.

ACCESSORY EQUIPMENT - Performance malfunctions involving other non-Heath accessory equipment, (antennas, audio components, computer peripherals and software, etc.) are not covered by this warranty and are the owner's responsibility.

SHIPPING UNITS - Follow the packing instructions published in the assembly manuals. Damage due to inadequate packing cannot be repaired under warranty.

If you are not satisfied with our service (warranty or otherwise) or our products, write directly to our Director of Customer Service. Heath Company, Benton Harbor MI 49022. He will make certain your problems receive immediate, personal attention.

Heathkit[®] Manual

for the

MEMORY I/O ACCESSORY

Model ETA-3400

ASSEMBLY

595-2170-03

HEATH COMPANY BENTON HARBOR, MICHIGAN 49022 Copyright © 1979 Heath Company All Rights Reserved Printed in the United States of America •

TABLE OF CONTENTS

Introduction 3	Troubleshooting Chart 49
Assembly Notes 4	Specifications 51
Parts List	Semiconductor Identification Charts 52
Step-by-Step Assembly	ROM Program 57
Circuit Board Assembly 10 Cabinet Assembly and Wiring 26	Circuit Board X-Ray View
Initial Tests 36	(Illustration Booklet, Page 7)
Resistance Measurements 36 Voltage Measurements 38	Schematic Fold-In
Final Assembly and Operational Tests 40	Warranty Inside front cover
Operation	Customer Service Inside rear cover
In Case of Difficulty 48	

INTRODUCTION


The ETA-3400 Memory I/O Accessory expands the capability of the ET-3400 Microprocessor Trainer by adding Tiny BASIC and a terminal monitor (both in ROM), expansion RAM, and audio cassette program storage. The standard Accessory comes with 1,024 bytes of user RAM memory, which can be expanded to a total of 4,096 bytes.

A serial I/O port provides communication to a standard terminal such as the Heath H9 Video Terminal or H36 hard copy terminal. Baud rates are selectable from 110 through 9600. Both EIA RS-232 and 20 mA current loop interfaces are provided. Machine language object code may be easily stored using a cassette recorder such as the Heath ECP-3801, with or without a terminal. The audio cassette storage feature plus additional user memory both enhance the ET-3400 Trainer, and do not require a terminal. With a terminal, you can also store BASIC programs on cassette tapes.

ASSEMBLY NOTES

TOOLS

You will need these tools to assemble your kit.



ASSEMBLY

- 1. Follow the instructions carefully. Read the entire step before you perform each operation.
- 2. The illustrations in the Manual are called Pictorials and Details. Pictorials show the overall operation for a group of assembly steps; Details generally illustrate a single step. When you are directed to refer to a certain Pictorial "for the following steps," continue using that Pictorial until you are referred to another Pictorial for another group of steps.
- 3. Most kits use a separate "Illustration Booklet" that contains illustrations (Pictorials, Details, etc.) that are too large for the Assembly Manual. Keep the "Illustration Booklet" with the Assembly Manual. The illustrations in it are arranged in Pictorial number sequence.
- 4. Position all parts as shown in the Pictorials.
- 5. Solder a part or a group of parts only when you are instructed to do so.

- 6. Each circuit part in an electronic kit has its own component number (R2, C4, etc.). Use these numbers when you want to identify the same part in the various sections of the Manual. These numbers, which are especially useful if a part has to be replaced, appear:
 - In the Parts List,
 - At the beginning of each step where a component is installed,
 - In some illustrations,
 - In the Schematic,
 - In the section at the rear of the Manual.
- 7. When you are instructed to cut something to a particular length, use the scales (rulers) provided at the bottom of the Manual pages.

SAFETY WARNING: Avoid eye injury when you cut off excess lead lengths. Hold the leads so they cannot fly toward your eyes.

SOLDERING

Soldering is one of the most important operations you will perform while assembling your kit. A good solder connection will form an electrical connection between two parts, such as a component lead and a circuit board foil. A bad solder connection could prevent an otherwise well-assembled kit from operating properly.


It is easy to make a good solder connection if you follow a few simple rules:

- Use the right type of soldering iron. A 25 to 40-watt pencil soldering iron with a 1/8" or 3/16" chisel or pyramid tip works best.
- 2. Keep the soldering iron tip clean. Wipe it often on a wet sponge or cloth; then apply solder to the tip to give the entire tip a wet look. This process is called tinning, and it will protect the tip and enable you to make good connections. When solder tends to "ball" or does not stick to the tip, the tip needs to be cleaned and retinned.

NOTE: Always use rosin core, radio-type solder (60:40 or 50:50 tin-lead content) for all of the soldering in this kit. This is the type we have supplied with the parts. The Warranty will be void and we will not service any kit in which acid core solder or paste has been used.

PARTS

Resistors will be called out by their resistance value in Ω (ohms), k Ω (kilohms), or M Ω (megohms). Certain types of resistors will have the value printed on the body, while others will be identified by a color code. The colors of the bands and the value will be given in the steps, therefore the following color code is given for information only.



1 . 1 .

1/4-WATT

OR

OR


Capacitors will be called out by their capacitance value in μ F (microfarads) or pF (picofarads) and type: ceramic, Mylar*, electrolytic, etc. Some capacitors may have their value printed in the following manner:

EXAMPLES:

 $151K = 15 \times 10 = 150 \text{ pF}$ $759 = 75 \times 0.1 = 7.5 \text{ pF}$

NOTE: The letter "R" may be used at times to signify a decimal point: as in: 2R2 = 2.2 (pF or μ F).

MULTIPLIE	R	TOLERANCE OF CAPACITOR			
FOR THE NUMBER:	MULTIPLY BY:	10 pF OR LESS	LETTER	OVER 10 pF	
0	1	±0.1 pF	В		
1	10	±0.25 pF	С		
2	100	±0.5 pF	D		
3	1000	±1.0 pF	F	±1%	
4	10,000	±2.0 pF	G	±2%	
5	100,000		н	±3%	
			J	±5%	
8	0.01		к	±10%	
9	0.1		м	±20%	



*DuPont Registered Trademark

PARTS LIST

Check each part against the following list. Any part that is packed in an individual envelope with the part number on it should be placed back in the envelope after you identify it until it is called for in a step. Do not discard any packing materials until all parts are accounted for.

The key numbers correspond to the numbers on the "Parts Pictorial" on Page 1 in the separate "Illustration Booklet." To order a replacement part: Always include the PART NUMBER. Use the Parts Order Form furnished with the kit. If one is not available, see "Replacement Parts" inside the rear cover of the Manual. Your Warranty is located inside the front cover. For prices, refer to the separate "Heath Parts Price List."

	HEATH Part No.	QTY	. DESCRIPTION	CIRCUIT Comp. No.	KE <u>No.</u>	Y HEATH Part No.	QT)	7. DESCRIPTION	CIRCUIT Comp. No.
RE	SISTORS				СА	PACITOR	S		
NOT	TES:				Ele	ectrolytic (Capa	citors	
	otherw cates a cates 5 2. The re envelo	rise no a 10% 5% to esistor pe. C	are 1/4-watt, 5% toleran oted. A fourth color band of tolerance; a fourth band o lerance. To may be packed in more open all the resistor envelo you check them against the	silver indi- f gold indi- e than one pes in this	81 B1 B2 B3 B3	25-221 25-276 25-924 25-241 25-272	1 2 6 2 1	2.2 μ F tantalum 4.7 μ F tantalum 2.2 μ F electrolytic 1200 μ F 6000 μ F	C102 C108, C110 C105, C106, C111, C112, C114, C115 C107, C109 C113
A1 A1 A1 A1 A1	6-470-12 6-101-12 6-151-12 6-471-12 6-102-12	1 1 2 9	47 Ω (yellow-violet-black) 100 Ω (brown-black-brown) 150 Ω (brown-green-brown) 470 Ω (yellow-violet-brown) 1000 Ω (brown-black-red)	R122 R101 R113 R121, R129 R105, R108,	Oth 84 84 85	21-71 21-78 21-182 21-46	t ors 2 1	.001 μF ceramic .047 μF (473) ceramic .005 μF ceramic	C2, C3 C101 C103
				R109, R111, R114, R115, R123, R130, R131	B5 B6	21-95 27-127	4 1	.1 μF ceramic .047 μF Mylar	C103 C104, C116, C117, C118 C1
A1	6-222 -12	15	2200 Ω (red-red-red)	R118, R119, R124, R126, R132, R134		DES	-		
A1 A1	6-332-12 6-472-12	1 5	3300 Ω (orange-orange-red) 4700 Ω (yellow-violet-red)	R116, R120, R125, R127,	C1 C1 C1	56-56 57-42 57-65	3 2 4	1N4149 diode 3A1 diode 1N4002 diode	D107, D108, D109 D105, D106 D101, D102, D103, D104
A1 A1	6-103-12 6-104-12	4 3	10 k\Omega (brown-black-orange) 100 kΩ (brown-black-yellow)	R128 R102, R104, R110, R117 R103, R107,					5100, 5104

R112

KEY	HEATH	QTY. DESCRIPTION	CIRCUIT
No.	Part No.		Comp. No.

TRANSISTORS — INTEGRATED CIRCUITS (IC's)

NOTE: Transistors (and integrated circuits) are marked for identification in one of the the following four ways:

- 1. Part number.
- 2. Type number.
- 3. Part number and type number.
- 4. Part number with a type number other than the one shown.

IMPORTANT: If any components are missing from the sealed IC package, return the unopened package for replacement. Claims for missing IC's will not be honored.

If you locate damaged or defective IC's, order individual replacements. Be sure to follow the standard instructions on the "Parts Order Form" and on the inside rear cover of the Manual. Save defective or damaged components for return instructions.

CAUTION: The integrated circuits packed in conductive foam can be damaged by static voltage. Since these parts are quite expensive, do not remove them from their packages until you are instructed to do so.

D1	417-874	1	2N3906 transistor	Q101
D1	417-875	4	2N3904 transistor	Q102 through
				Q105
D2	442-54	1	μA7805 IC	U110
D2	442-633	1	78M12CKC IC	U102
D2	442-664	1	79M12CKC IC	U101
D3	442-616	1	LM3302N, LM2901N,	U109
			or µA775 IC	
D3	443-1 8	1	7404N IC	U104
D3	443-46	1	7402N IC	U107
D3	444-28	1	74S188N IC	U108
D3	443-764	2	2114 IC	U117, U118
D3	443-843	1	MC6820 IC	U103
D4	444-24	1	"TINY BASIC" ROM IC	U106
D4	444-51	1	"Terminal Monitor"	U105
			ROM IC	

CONNECTORS — SOCKETS

E1	432-8 65	1	3-hole socket	
E2	432-866	3	Spring connector	
E3	432-1062	1	40-pin connector	S101
E4	434- 253	1	40-pin IC socket	
E5	434-298	3	14-pin IC socket	
E6	434-299	1	16-pin IC socket	
E7	434-307	2	24-pin IC socket	

KEY No.	HEATH Part No.	QTY.	DESCRIPTION	CIRCUIT Comp. No.
CO	NNECTOF	IS —	SOCKETS (cont'd)	
E8	43 4-310	8	18-pin IC socket	
E9	432-1028	1	25-hole socket	S102
E10	432-1031	25	Female connector pin	
E11	432-1032	1	25-hole connector shell	
E12	432-1033	25	Male connector pin	
E13	434-107	2	Phono socket	
E14	434-148	1	AC power socket	
E15	438-4	2	Phono plug	

HARDWARE

E16 438-26

NOTE: The hardware may be in more than one packet. Open all the hardware packets according to their size before you check the hardware.

Red phone plug

2

Hardware is shown actual size. To identify a piece of hardware, place it over the illustration.

F1	250-13	2	6-32 × 1" screw
F2	250-89	8	6-32 $ imes$ 3/8" screw
F2	250-381	9	6-32 $ imes$ 3/8" black screw
F3	250-273	2	4-40 $ imes$ 3/8" screw
F4	250-1325	16	6-32 $ imes$ 1/4" black screw
F5	250-1305	1	#6 × 5/8" self-tapping screw
F6	252-2	2	4-40 nut
F7	252-3	4	6-32 nut
F8	252-22	3	Speed Nut*
F9	254-1	2	#6 lockwasher
F10	254-9	2	#4 lockwasher
F11	255-71	2	Long threaded spacer
F12	255-142	8	Short threaded spacer
F13	259-1	2	#6 solder lug
F14	423-11	1	Fuseholder

CIRCUIT BOARD - CABINET - SHIELD

	85-2146-1	Ť	Circuit board
	90-1275-1	1	Cabinet top
	90-1276-1	1	Cabinet bottom
G1	206-1288	1	Shield

WIRE — LINE CORD

89-54	1	Line cord
340-8	6″	Bare wire
344-35	8″	Orange wire
344-59	8″	White wire
347-55	20″	8-wire flat cable
344-33	12″	Large black wire
344-50	8″	Small black wire
343-11	48″	Shielded wire
134-1034	1	40-conductor flat cable

*Registered Trademark, Tinnerman Company,

HEATHKIT


No.			2. DESCRIPTION	CIRCUIT Comp. No.		HEATH Part No.	QTY ——		CIRCUIT Comp. No.	
WING	AISCELLANEOUS					PRINTED MATERIAL				
H1	45-615	4	Toroid coil				IER	IAL		
H2	54-920	-		L1						
H3	54-920 60-619	1	Power transformer	T1	J1	391-34	1	"Heathkit" label		
		1	Rocker switch	SW1		597-260	1	Parts Order Form		
H4	73-3	1	Rubber grommet				1	Assembly Manual (See Page	1	
H5	73-92	1	Foam gasket					for part number).		
H6	75-90	1	Paper insulator				1	Software Reference Manual		
H7	75-754	1	Strain relief					(See Page 1		
	206-1415	1	5" $ imes$ 12" foil shield					for part number).		
H8	261-34	4	Foot							
H9	346-67	2	Shrinkable tubing							
H10	352-13	1	Silicone grease							
H11	354-5	3	Short cable tie							
H12	354-7	2	Long cable tie							
H13	421-42	- 1	3/8-ampere slow-blow fuse	F1						
H14	431-1	1	2-lug terminal strip	FI						
H15	431-83	1	5-lug terminal strip							
	490-185	1								
	, JO-100	•	Desoldering braid							




STEP-BY-STEP ASSEMBLY









 $\label{eq:residual} \begin{array}{l} (\) \ R119: Hold a 2200 \,\Omega \ (red-red) \\ resistor \ as \ shown \ and \ bend \ the \\ leads \ straight \ down \ with \ long- \\ nose \ pliers \ to \ fit \ the \ hole \ spacing \\ on \ the \ circuit \ board. \end{array}$



- () Push the leads through the holes at the indicated location on the circuit board. The end with color bands may be positioned either way.
- () Press the resistor against the circuit board. Then bend the leads outward slightly to hold the resistor in place.












A GOOD SOLDER CONNECTION



time, the solder will flow evenly onto the lead and the foil. The solder will make a good electrical connection between the lead and the foil.

POOR SOLDER CONNECTIONS






When the foil is not heated sufficiently the solder will blob on the circuit board as shown above. To correct, reheat the connection and, if necessary, apply a small amount of additional solder to obtain a good connection.


SOLDER BRIDGES


A solder bridge between two adjacent foils is shown in photograph A. Photograph B shows how the connection should appear. A solder bridge may occur if you accidentally touch an adjacent previously soldered connection, if you use too much solder, or if you "drag" the soldering iron across other foils as you remove it from the connection. A good rule to follow is: always take a good look at the foil area around each lead before you solder it. Then, when you solder the connection, make sure the solder remains in this area and does not bridge to another foil. This is especially important when the foils are small and close together. NOTE: It is alright for solder to bridge two connections on the same foil.

Use only enough solder to make a good connection, and lift the soldering iron straight up from the circuit board. If a solder bridge should develop, turn the circuit board foil-side-down and heat the solder between connections. The excess solder will run onto the tip of the soldering iron, and this will remove the solder bridge. NOTE: The foil side of most circuit boards has a coating on it called "solder resist." This is a protective insulation to help prevent solder bridges.





























10 D L F


in this area of the circuit board. PART NUMBER **IDENTIFICATION** DRAWING CONTINUE 🖓) C101: .047 µF (473) ceramic. NOTE: When you install tantalum capacitors, be sure to position the plus (+) or color dot marked lead in the plus marked hole in the circuit board. CONTINUE 🖓 POSITIVE (+) () C109: 1200 μ F electrolytic. MARK 0 R COLOR () C107: 1200 μ F electrolytic. DOT) Solder the leads to the foil and cut (off the excess lead lengths. () Route a long cable tie through) C102: 2.2 μ F tantalum. ſ the holes in the circuit board, as shown below, and around the () C108: 4.7 μ F tantalum. two 1200 μ F capacitors. Make sure the head of the cable tie is () C105: 2.2 μ F electrolytic. positioned as shown. Then pass the free end of the tie through () C112: 2.2 μ F electrolytic. the head, pull the tie tight, and cut off the excess tie end. () C110: 4.7 μ F tantalum. CABLE TIE () Solder the leads to the foil and cut **PICTORIAL 1-9** off the excess lead lengths. 1200µF

The steps performed in this Pictorial are




) Q105: 2N3904 (#417-875) transis-


tor.




The steps performed in this Pictorial are


HEATHKIT








The steps performed in this Pictorial are



The steps performed in this Pictorial are

CABINET ASSEMBLY AND WIRING



PICTORIAL 2-1

Refer to Pictorial 2-1 for the following steps.

- () Turn the cabinet bottom upside down.
- () Remove the paper backing from the four feet and press them in place on the cabinet bottom 1/4'' from the four corners as shown.


Refer to Pictorial 2-2 (Illustration Booklet, Page 2) for the following steps.

() Position the cabinet bottom on your work area as shown.

NOTE: When the following steps call for hardware, use black screws **only** where specified.

(INCHES)


(CM)



- () Refer to Detail 2-2A and loosely mount a short threaded spacer at A using a 6-32 \times 1/4" black screw.
- () In the same manner, loosely mount seven short threaded spacers at B, C, D, E, F, G, and H.


Refer to Detail 2-2B for the next three steps.

- () Scrape the paint from around holes J and K on the inside of the cabinet bottom.
- () Mount a #6 solder lug at J using a $6-32 \times 3/8''$ screw and a 6-32 nut. Be sure to position the solder lug as shown in the Pictorial.
- () In the same manner, mount a #6 solder lug at K.



NOTE: To prepare a wire, as in the following step, cut it to the indicated length and remove 1/4" of insulation from each end. If not already done, tightly twist each wire end and apply a small amount of solder to hold the fine strands together.

- () If it has not already been done, cut back 2-1/2" of the outer insulation on the three-wire end of the line cord. Cut an additional 1" from the ends of the black and the green line cord wires. Prepare the wire ends.
- () Pass the 3" end of the line cord through hole L; then refer to Detail 2-2C and attach the strain relief and line cord to the cabinet bottom.



Detail 2-2C


Refer to Pictorial 2-3 (Illustration Booklet, Page 3) for the following steps.

() Prepare a 2" large black wire.

Remove an additional 1/4" of insulation (1/2" total) from one end of the 2" black wire.


Refer to Detail 2-3A for the next two steps.

- Connect the 1/2" end of the 2" black wire to screw terminal 3 of the AC power socket M as shown in the inset drawing. Tighten the screw securely.
- () Guide the 2" black wire and AC power socket into hole M. Be sure the screw terminal is facing down as shown; then push the socket until it snaps into place.



Detail 2-3A


() SW1: Refer to Detail 2-3B and position the rocker switch so the ON lettering appears as shown. Guide the switch into hole SW1; then push the switch until it snaps into place.



Detail 2-3B

NOTES:

- In the following steps, (NS) means not to solder a connection because other wires or leads will be connected later. "S-" with a number, such as (S-3), means to solder the connection. The number following the "S" tells how many wires are at the connection. After you solder a wire to lead, cut off any excess lengths.
- 2. Make "mechanically secure" connections as shown in the inset drawing on Pictorial 2-3.
- () Connect the end of the black wire coming from AC socket M terminal 3 to solder lug J (S-1). Be sure to make a mechanically secure connection.
- () Connect the end of the green line cord lead to solder lug K. Make a mechanically secure connection (S-1).
- () Refer to Detail 2-3C and mount a 5-lug terminal strip at TS1 using a $6-32 \times 3/8''$ screw, a 6-32 nut, and a #6 lockwasher. Be sure to position the terminal strip as shown in the Pictorial.




Refer to Detail 2-3D for the following two steps.

() Mount the fuseholder at F1 using the hardware supplied in the fuseholder package. Be sure the end lug on the fuseholder is facing the bottom of the cabinet as shown.


NOTE: A 3/8"-ampere slow-blow fuse was supplied with this kit for 120 VAC line voltage. If the line voltage in your area is 240 VAC, you must obtain a 3/16- ampere, 250 VAC slow-blow fuse.


() F1: Remove the fuseholder cap, and install the proper fuse in the fuseholder. Then replace the cap.





() S102: Refer to Detail 2-3E and mount the 25hole socket S102 using two $4-40 \times 3/8''$ screws, two #4 lockwashers, and two 4-40 nuts. Make sure the socket is positioned as shown.






Detail 2-3F

Refer to Detail 2-3F for the following two steps.

- Mount a phono socket at P using the hardware supplied with the socket. Make sure the solder lug is positioned as shown in the Pictorial, then bend it up slightly as shown in the Detail.
- () Mount a phono socket at R using the hardware supplied with the socket. Make sure the solder lug is positioned as shown in the Pictorial, then bend it up slightly as shown in the the Detail.



() Refer to the inset drawing and open the silicone grease pod. Apply a liberal amount of grease to the bare metal side of the μ A7805 integrated circuit (#442-54).

() U110: Mount the integrated circuit at U110 using a $6-32 \times 3/8''$ screw, a #6 lockwasher, and a 6-32 nut. Face the bare metal side of the IC against the mounting surface. Be sure to position the IC as shown in the Pictorial.

Refer to Detail 2-3H for the following three steps.

- () 1. Mount two long threaded spacers at T1 using two 6-32 \times 3/8" black screws.
- () 2. Pass the following transformer leads through a rubber grommet as shown: black-green, black-red, black-yellow, and black.
- () 3. T1: Mount the power transformer on the long threaded spacers at T1 using two 6-32 × 1" screws. Be sure the transformer leads are positioned as shown.

Refer to Pictorial 2-4 (Illustration Booklet, Page 3) for the following steps.

() Prepare three 2-1/2" large black wires.

NOTE: In the following steps, be sure to make mechanically secure connections.


 Connect a 2-1/2" black wire from switch SW1 lug 2 (S-1) to fuseholder F1 lug 2 (S-1).

- () Connect a 2-1/2" black wire from AC power socket M lug 2 (S-1) to the **eyelet** in terminal strip TS1 lug 2 (S-1).
- () Connect a 2-1/2" black wire from socket M lug 1 to the **eyelet** in terminal strip TS1 lug 4 (S-1).
- () Connect the black line cord wire to fuseholder F1 lug 1 (S-1).
- () Connect the white line cord wire to terminal strip TS1 lug 1 (NS).
- () Cut the leads of two .001 µF ceramic capacitors (#21-71) to 1/2". Use these two capacitors in the next two steps.
- () C3: Connect a .001 μ F ceramic capacitor between terminal strip TS1 lugs 2 (NS) and 3 (NS).
- C2: Connect a .001 μF ceramic capacitor between terminal strip TS1 lugs 3 (S-2) and 4 (NS).
- () C1: Cut the leads of a .047 Mylar capacitor to 1/2". Connect the capacitor from switch SW1 lug 1 (NS) to terminal strip TS1 lug 1 (NS).


-) Cut the four leads of the toroid coil to 1-1/2''.
- () L1: Connect the toroid coil leads as follows:
 - 1. One black lead to switch SW1 lug 1 (S-2).
 - 2. The other black lead to terminal strip TS1 lug 4 (NS).
 - 3. One white lead to terminal strip TS1 lug 1 (S-3).
 - 4. The other white lead to terminal strip TS1 lug 2 (NS).

ALTERNATE LINE VOLTAGE WIRING

Two sets of line voltage wiring instructions follow, one for 120 VAC line voltage and the other for 240 VAC line voltage. In the United States 120 VAC is most often used, while in other countries 240 VAC is more common. USE ONLY THE INSTRUCTIONS THAT AGREE WITH THE LINE VOLTAGE IN YOUR AREA.





🔆 HEATHIKIT®



Refer to Pictorial 2-5 (Illustration Booklet, Page 3) for the following steps.

- Locate three Speed Nuts. Note that each Speed Nut is flat on one side. Push the Speed Nuts onto the shield with the flat sides as shown in Detail 2-5A.
- () Before you remove the backing paper from the paper insulator, place it inside the shield as shown in Detail 2-5A and shape it to fit. Then remove the backing paper and stick the insulator down into place.
- () Position the transformer leads and rubber grommet as shown in the Pictorial. Place the rubber grommet in the shield slot; then mount the shield to the cabinet using three $6-32 \times 3/8''$ screws.





Refer to Pictorial 2-6 for the following steps.

NOTE: As you connect each of the remaining power transformer leads to the circuit board in the following steps, solder the lead to the foil and cut off the excess lead length.

() Position the circuit board, component side up, near the power transformer as shown in the Pictorial.


Connect six power transformer leads to the circuit board as follows:

- () Yellow-green lead to the hole marked YEL/GRN.
- () Red-yellow lead to the hole marked RED/YEL.
- () Either red lead to either hole marked RED.
- () Other red lead to remaining hole marked RED.
- () Either green lead to either hole marked GRN.

() Other green lead to remaining hole marked GRN.

Carefully inspect the circuit board for the following conditions.

- () Unsoldered connections.
- () Poor solder connections.
- () Solder bridges between foils.
- () Protruding leads which could touch together.
- () Transistors for the proper type and installation.
- () Electrolytic and tantalum capacitors for the correct position of the plug (+) or color dot marked lead.
- () Diodes for the correct position of the banded end.



PICTORIAL 2-7

Refer to Pictorial 2-7 for the following steps.


- () Position the circuit board mounting holes over the eight short threaded spacers on the cabinet bottom; then mount the circuit board to the spacers with $6-32 \times 3/8"$ screws.
- () Now tighten the screws underneath the chassis that hold the spacers in place.
- () Twist together the orange, black, and white wires of the 3-hole socket as shown; then push the connector onto the integrated circuit leads

at U110. Be sure the white wire on the 3-hole socket is closest to the power transformer.

Page 33

Connect the free ends of the brown through yellow 4-wire cable coming from the circuit board as follows.

- () Red wire to phono socket R lug 1 (S-1).
- () Brown wire to phono socket R lug 2 (S-1).
- () Orange wire to phono socket P lug 1 (S-1).
- () Yellow wire to phono socket P lug 2 (S-1).



Detail 2-8A

Refer to Pictorial 2-8 (Illustration Booklet, Page 4) for the following steps.

() Refer to Detail 2-8A and solder a female connector pin (#432-1031) to each wire on the 4-wire and 6-wire cables.


IMPORTANT: In the following steps, you will install connector pins in the 25-hole socket. Make sure you install all pins in the correct holes. Once the pins are in place, they are very difficult to remove. Holes 1, 13, 14, and 25 are numbered on the back of the socket. () Refer to Detail 2-8B and install the leftover female connector pins in S102 holes 4, 8 through 13, 15, 17, and 20 through 25. Push the pins in until they lock into place. NOTE: No wires will be connected to these pins; they will be used to help hold the plug and socket together.

Refer to Detail 2-8C for the following ten steps.

NOTE: Refer to the inset drawing of Detail 2-8B for the hole numbers of the connector. Each time you install a connector pin, gently pull on the wire to make sure the pin is locked in place.

Install the connector pins on the gray through orange 6-wire cable in socket S102 as follows:

- () 1. Violet wire in hole 7.
- () 2. Green wire in hole 19.
- () 3. Yellow wire in hole 6.



HEATHKIT[®]


() 5. Orange wire in hole 5. NOTE: The gray wire will be installed later.


Install the connector pins on the gray through green 4-wire cable as follows:


- () 6. Gray wire in hole 16. Make sure this is the gray wire on the **4-wire** cable.
- () 7. Violet wire in hole 3.
- () 8. Green wire in hole 2.
- () 9. Blue wire in hole 1.
- ()10. Install the connector pin on the remaining gray wire (from the 6-wire cable) in hole 14.
- () Position the cables and transformer leads as shown in the Pictorial.

() Refer to the inset drawing of the Pictorial and install three short cable ties on the cables at the locations shown.

This completes the "Step-by-Step Assembly" of your Memory I/O Accessory. Check it over carefully at this time to be sure there are no wire clippings or solder splashes lodged in the wiring, and that there are no loose wires or unsoldered connections. Then proceed to "Initial Tests". Save the foil shield for use with your ET/ETW-3400A Microprocessor Trainer Modification Kit.







INITIAL TESTS

NOTE: You will need a volt-ohmmeter to perform the following tests. If such a meter is not available, proceed to "ET-3400 Modifications".


RESISTANCE MEASUREMENTS

() Use an ohmmeter to measure the resistance between each flat plug prong and the round prong on the line cord. In both measurements, you should obtain an infinite indication. Be sure the test probe is not touching the chassis or any connection.

If you do not obtain infinite indications, recheck all wiring and make sure no fine wire strands at any connection are touching another connection. Use an ohmmeter to make the following resistance measurements before you apply power to your Memory I/O Accessory. This will insure that the power supplies will not be damaged due to a wiring error or some incorrectly installed or faulty part. If you do not get the proper indication under "Approximate Meter Reading," check the wiring and installation of the parts listed in the "Possible Cause" column for that step. You may also refer to the "In Case of Difficulty" section of the Manual (Page 52). Be sure you obtain the correct resistance reading before proceeding.

Refer to Pictorial 3-1 for the following steps.

() Place the AC POWER switch in the OFF position.



PICTORIAL 3-1


() Connect the negative ohmmeter lead to the negative lead of the 6000 μ F capacitor (C113). Then touch the positive meter lead to the points indicated in the following chart.

NOTES:

1. Not all ohmmeters are polarized the same. Therefore, if you do not get the correct meter reading the first time, connect the positive meter lead to C113 and touch the negative meter lead to the point indicated in the chart. If this produces the correct indication, cross out the word "positive" in the heading of the first column and write in "negative."

- 2.
- The ohmmeter that was used to make the following measurements was powered by a 1.5-volt battery and set on the $R \times 100$ range.

POSITIVE METER LEAD TO:	APPROXIMATE METER READING	POSSILE CAUSE
() White wire at hole WHT.	420 - 600 Ω	 Solder bridge on circuit board. Capacitor C115, C116, C117, or C118. Wiring error on 3-hole socket at U110. Integrated circuit U110.
() Heat sink of U101.	550 - 630 Ω	 Solder bridge on circuit board. Diode D101, D102, D103, or D104. Integrated circuit U101.
() Negative lead of C112 (2.2 μF	550 - 1200 Ω	 Solder bridge on circuit board. Capacitor C106 or C112. Integrated circuit U101.
() Emitter of Q101.	4000 - 8000 Ω	 Solder bridge on circuit board. Capacitor C105 or C111. Integrated circuit U102. Transistor Q101 or Q102.



VOLTAGE MEASUREMENTS

NOTE: If at any time during the following steps you fail to obtain the desired reading, immediately unplug the line cord from the AC outlet and refer to the "Possible Cause" chart which follows each step. You may also refer to the "In Case of Difficulty" section of the Manual (Page 48). Be sure you obtain the correct voltage reading before you proceed.

- () Make sure the AC POWER switch is in the OFF position.
- () Plug the line cord into the proper AC outlet.

Refer to Pictorial 3-2 for the following steps.

- () Set the voltmeter to measure +5 volts DC.
- () Connect the negative lead of your voltmeter to the negative lead of capacitor C113.
- () Hold the probe (positive lead) of your voltmeter to the white wire at +5 V and push the AC POWER switch to ON. The voltmeter should indicate approximately +5 volts (4.75 to 5.25 volts).

PROBLEM	POSSIBLE CAUSE
Meter does not indicate +5 volts.	 Solder bridge on circuit board. Wiring error on circuit board at diodes D105, D106. Wiring error on 3-hole socket at U110. Diodes D105, D106. Integrated Circuit U110.

🔆 HEATHKIT®

- () Remove the voltmeter probe from the circuit board and reset the voltmeter to measure +12 volts DC.
- () Hold the probe of your voltmeter to the emitter of Q101. The voltmeter should indicate approximately +12 volts (10.8 to 13.2 volts).

PROBLEM	POSSIBLE CAUSE	
Meter does not indicate +12 volts.	 Solder bridge on circuit board. Wiring error on circuit board at diodes D101 through D104. Wiring error on circuit board at U102. Diodes D101 through D104. Integrated circuit U102. Capacitor C107. 	


- () Remove the voltmeter probe from the circuit, and disconnect the negative voltmeter lead from capacitor C113.
- () Connect the probe (positive lead) of your voltmeter to the negative lead of capacitor C113.
- () Hold the negative lead of your voltmeter to the negative lead of capacitor C112 at -12 volts. The voltmeter should indicate approximately 12 volts (10.8 to 13.2 volts).

PROBLEM	POSSIBLE CAUSE
Meter does not indicate -12 volts.	 Solder bridge on circuit board. Wiring error on circuit board at diodes D101 through D104. Wiring error on circuit board at U101. Diodes D101 through D104. Integrated circuit U101. Capacitor C109.

() Push the AC POWER switch to the OFF position, disconnect the voltmeter leads, and unplug the line cord.

This completes the "Initial Tests" of your Memory I/O Accessory. Set the Memory I/O Accessory aside and proceed to the ET-3400 Trainer Modification Kit. Then return to "Final Assembly and Operational Tests" in this Manual.

FINAL ASSEMBLY AND OPERATIONAL TESTS




PICTORIAL 5-1

Refer to Pictorial 5-1 for the following steps.


NOTE: In the following steps, you will be instructed to assemble two shielded wire cables. After you complete the first cable, repeat the steps for the second cable where double check spaces are provided. Some steps have only one check space. Perform these steps only once as instructed.

- () () Refer to Detail 5-1A and prepare a shielded wire and phono plug as shown.
- () Cut two 1" pieces of heat-shrinkable tubing and slide them over end B on one shielded wire.
- () () Remove the red cap on one of the phone plugs and slide it over the shielded wire at end B with the threaded end as shown.




Detail 5-1A






Detail 5-1B

() () Refer to Detail 5-1B and solder the center lead of the shielded wire to the indicated lug of the phone plug. Solder the shield to the indicated location on the phone plug. After the connection cools, replace the red cap on the phone plug.



Detail 5-2A



- () Refer to Detail 5-1C and position the previously installed 1" pieces of heat-shrinkable tubing approximately 1/2" from each plug on the shielded wire. Shrink the tubing in place with a lighter or a match.
- () If an ohmmeter is available, make continuity checks of your cables.
- () Temporarily set the two cables aside.

Refer to Pictorial 5-2 (Illustration Booklet, Page 5) for the following steps.

NOTE: In the following steps, when you install an integrated circuit, refer to Detail 5-2A, remove the IC from its packing material (if necessary), and install the IC as shown.

() Connect one end of the 40-conductor cable to the Memory I/O Accessory.

NOTE: In the following steps, you will install the IC's and make tests to insure that your Memory I/O Accessory is working properly. Make sure you install all of the IC's in the exact sequence listed. If you do not get the indicated response at any time, refer to the "In Case of Difficulty" section in the "Operation Manual." Refer to Pictorial 5-2 and install the IC's as follows:

- () U104: 7404N (#443-18).
- () U107: 7402N (#443-46).
- () U108: 74S188N (#444-28).

NOTE: Some of the integrated circuits that you will install in the following steps are MOS devices that can be damaged by static electricity. Install each of these integrated circuits (identified as "MOS" in the step) without interruption as follows:

- 1. Remove the IC mounted in conductive foam from its envelope.
- 2. Hold the IC in one hand and pull the conductive foam pad from the pins. (Save this foam in case you ever remove the IC.)
- 3. Touch the circuit board while you hold the IC.
- 4. Carefully insert the IC in its socket before you release the the circuit board with your other hand. The IC is now protected by the circuit board socket and foil.
- () U117: (MOS) 2114, 6614P, or S4045 (#443-764).
- () U118: (MOS) 2114, 6614P, or S4045 (#443-764).
- () Temporarily, place the Accessory cabinet top on the cabinet bottom, but do not install any screws. Then set the Microprocessor Trainer on top of the Accessory.
- () Connect the other end of the 40-conductor cable to the Microprocessor Trainer. Make sure the cable is not twisted.
- () Connect the phono plug with the heatshrinkable tubing to the TAPE INPUT phono jack.
- () Connect the remaining phono plug to the TAPE OUTPUT phono jack.

- () Plug the Trainer line cord into the ETA-3400 Accessory AC socket. Then plug the Accessory line cord into a wall outlet.
- () Set the POWER switch on both units to ON.
- () Press the RESET button on the TRAINER. The display should indicate "CPU UP." This shows that the system has successfully communicated with the new RAM (U117 and U118).
- () Unplug the line cord of the ETA-3400 Accessory from the wall outlet.
- () U105, (MOS) terminal monitor ROM (#444-51).
- () Plug in the Accessory line cord.
- () Press the RESET button on the Trainer. Again, the display should be "CPU UP."

NOTE: In the following chart, you will examine the data at each address listed. These are the terminal monitor ROM locations. For each one, press the RESET button, then the EXAM button and the address number. The Trainer should display the address number in the first four digits, and the information under "Data" in the last two digits. The last column in the chart is supplementary information that tells you which address bits are being tested.

() 1400 0F ALL () 1401 CE A1 () 1402 10 A2 () 1404 6F A3 () 1408 86 A4 () 1410 C6 A5 () 1420 26 A6 () 1440 33 A7	Address	Data	Address Bit(s) Tested
() 1480 4C A8 () 1500 27 A9 () 1600 26 A10 () 1800 4A A11	$\begin{array}{c} (\) \ 1401 \\ (\) \ 1402 \\ (\) \ 1404 \\ (\) \ 1408 \\ (\) \ 1410 \\ (\) \ 1420 \\ (\) \ 1420 \\ (\) \ 1440 \\ (\) \ 1480 \\ (\) \ 1500 \end{array}$	CE 10 6F 86 C6 26 33 4C 27 26	A1 A2 A3 A4 A5 A6 A7 A8 A9 A10

Page 43

- () Unplug the Accessory line cord.
- () U106: (MOS) "Tiny Basic" ROM (#444-24).
- () Plug in the Accessory line cord.
- () Press the Trainer RESET button; the display should read "CPU UP."
- () Using the same procedure as before, examine the following Tiny Basic ROM locations.

Address	Data	Address Bit(s) Tested
1C00	7E	All
1C01	1D	A1
1C02	00	A2
1C04	1D	A3
1C08	E1	A4
1C10	15	A5
1C20	EE	A6
1C40	CE	A7
1C80	BD	A8
1D00	CE	A9
1E00	04	A10

- () Unplug the Accessory line cord.
- () U109: LM3302N, LM2901N, or μ A775 (#442-616).
- () U103: (MOS) MC6820 (#443-843).
- If your cassette recorder has a high level line input (AUX or LINE), make sure the jumper on the Accessory circuit board is connected to "500 mV." If your recorder has only a microphone input, make sure the jumper is at "50 mV." These jumpers establish the output record levels.
- () If you are using a TTY or other 20 mA current loop terminal, make sure the circuit board jumpers are installed at "TTY." If you are using

the Heath H9 Video Terminal or other RS-232 terminal, make sure the jumpers are installed at "RS-232."

() Refer to the following table and make sure the jumpers on the accessory circuit board correspond to the baud rate you are using. NOTE: TTY will require 110 baud. 600 baud is recommended for the Heath H9 Video Terminal.

Baud Rate	Jumper(s) Required
110	No jumpers
300	J101, J102, J103
600	J102
1200	J101, J102
2400	J103
4800	J101, J103
9600	J102, J103

- () Refer to "Operation" on Page 45 and connect your terminal to the "D" connector on the rear panel of the Accessory.
- () Plug in the Accessory line cord.
- () On the Trainer press the RESET button, then press the DO button, then "1AF6." The terminal should print "this is a terminal test," followed by a carriage return and line feed. This test will continue until the RESET button is pressed.
- () Press the RESET button.
- () Execute a memory test program, using the "DO" function to execute the diagnostic which begins at 1A34. An increment type diagnostic proceeds with the LWA (last work address) display in the leftmost four LED's and the current test pattern displayed in the right most two LED's. A pattern failure ceases the test and displays the failed address/pattern on the LED's.

The following test will determine if the cassette load and save feature works correctly.

- () Attach the audio interface cables between the Accessory and your audio cassette recorder. Set the playback level and tone controls to center range.
- () Using the "Auto" function on the Trainer, enter the following list of data into memory, starting at 0000.

Address	Data	Address	Data	Address	Data
0000	BD	0010	CE	0020	ØF
0001	\mathbf{FC}	0011	2F	0021	26
0002	BC	0012	øø	0022	EA
0003	B6	0013	ø9	0023	2ǿ
0004	2ø	0014	26	0024	ĎA
0005	07	0015	FD		
0006	D6	0016	16		
0007	F1	0017	5D		
0008	CB	0018	26		
0009	1ǿ	0019	EC		
000A	D7	001A	86		
000B	F1	001B	ø1		
000C	48	001C	DE		
000D	BD	001D	Fø		
000E	FE	001E	8C		
000F	3A	001F	C1		

- () Cassette save program: Press "DO," and "1A8F". The Trainer will display "---Fr," indicating a request for the starting save address.
- () Enter 0000. The display will indicate "- -La," which is a request for the save ending address.
- () Place the recorder in the record mode and wait for the tape leader to pass the recorder head. Now enter 0024, and data will be transferred to the cassette tape.
- () When the recording is complete, the Trainer will display "CPU UP." At that point, stop the recorder and rewind the tape.
- () Unplug the Accessory line cord, then plug it back in. This will prevent the memory from retaining what was recorded.
- () Cassette load program: Press "DO," and 1ABC". Put the recorder in the playback mode. As data is loaded into memory, the decimal point on the left display digit of the Trainer will flash. If the

load is successful, the Trainer will display "CPU UP". If a data error is encountered, the Trainer will display "Error". Repeat the cassette load program if you get an error.

() Push "DO" and 0000. The segments of each LED will sequence on and off beginning with the left LED. This will continue until you press RESET.

NOTE: If you have purchased the optional Memory Chip Set ETA-3400-1, refer to the instructions supplied with the set and install those IC's at this time. Then return to this Manual.

Refer to Pictorial 5-3 (Illustration Booklet, Page 5) for the following steps.

- () Position the 40-conductor cable flat against the top surface of the cabinet bottom.
- () Secure the cabinet top to the cabinet bottom with eight 6-32 \times 1/4" screws.
- () Locate the blue and white label and remove the protective paper backing. Then press the label onto the rear panel of your Memory I/O Accessory as shown. Refer to the numbers on this label in any correspondence you may have with the Heath Company concerning this kit.

Refer to Pictorial 5-4 (Illustration Booklet, Page 6) for the following steps.

NOTE: Disregard the following steps if you have not installed adhesive foam gaskets on the ET-3400 Trainer.

- () Disconnect the 40-conductor cable connector from the ET-3400 Trainer.
- () Turn the Trainer cabinet upside down and remove the protective paper backing from the four foam gaskets.
- () Carefully position the Trainer as shown in the Pictorial. Be sure not to cover the top screws of the Memory I/O Accessory; then press the Trainer onto the cabinet top of the Memory I/O Accessory.
- () Reconnect the 40-conductor cable connector to the Trainer.

This completes the "Final Assembly and Operational Tests." Proceed to "Operation."

OPERATION


SERIAL I/O PORT

The signals that the serial I/O port uses to communicate with the terminal may be one of two types; EIA RS-232C compatible, or 20 mA active current loop. The type you select must match that used by your terminal. The RS-232 levels are normally used by CRT terminals and other high speed devices. The 20 mA loop is used with teletypes or whenever very long lines are used between units.

RS-232 Levels

To use the RS-232 levels, you should have installed the four EIA jumpers and none of the TTY jumpers. (See page 17 of the "Step-by-Step Assembly.") A cable coming from the rear of the Computer connects to your terminal as shown below in Pictorial 5-5.

EIA RS-232 INTERCONNECTIONS




PICTORIAL 5-5

20 mA Active Current Loop

The 20 mA active current loop is used when the serial I/O interface is to supply the current for the loop. This is normally the mode used with a teletypewriter or other passive device. To use this mode, you should have installed circuit board jumpers at the three TTY locations and none at the EIA locations. A cable coming from the rear panel of your Computer connects as shown in Pictorial 5-6.

20mA ACTIVE CURRENT LOOP



Proceed to the "Software Reference Manual".

CIRCUIT DESCRIPTION

As you read this section, refer to the Block Diagram (Page 47), and the schematic (fold-in). The circuit description applies to the ETA-3400 microcomputer accessory.

POWER SUPPLY

Switch SW1 applies power to the primary windings of power transformer T1. The secondary windings of T1 reduce the AC voltage to provide two separate AC supplies. Fuse F1 protects the unit against excessive current.

The AC voltage from one of the center-tapped secondary windings (green leads) is rectified by diodes D105 and D106 and filtered by capacitor C113. This filtered voltage is regulated by integrated circuit U110 and capacitors C114 and C115 to produce a stable +5-volt DC source.

The other center-tapped secondary winding (red leads) is rectified by diodes D101 and D102 and filtered by capacitor C107. This filtered voltage is regulated by integrated circuit U101 and capacitors C108 and C111 to produce a stable \pm 12-volt DC source. Diodes D103 and D104 also rectify the voltage of the transformer secondary (red leads) to produce a negative voltage that is filtered by C109. This negative voltage is then regulated by U102 and capacitors C110 and C112 to produce a stable \pm 12-volt DC source.

ADDRESS DECODER

Integrated circuit U108 is a 32×8 -bit ROM that is programmed to provide the seven outputs that select the various memory expansion functions (Tiny Basic, terminal monitor, and memory). An eighth output (D8, pin 9), "group decode," goes high when any of the expansion functions are addressed. This group decode signal is ANDed with R/W in U107B to produce a signal (RE) that indicates that a memory read is requested from the memory expansion area. When this occurs, the data bus buffer in the ET-3400 must be pointed toward the CPU. The RE signal performs this function.


MEMORY FUNCTIONS

The individual decoder lines from U108 select either of the two ROM's or one of the 1K RAM's. When one of the ROM's is selected, its particular \overline{CS} line goes low, the address location appears on address bus lines A0 through A15, and data is put on the bus (D0 through D7) and routed to the CPU.

The 4K expansion RAM is made up of eight $1K \times 4$ -bit memory IC's. These $1K \times 4$ -bit memories are grouped in pairs to form the four $1K \times 8$ -bit memory blocks. A RAM read cycle is the same as the ROM read cycle explained above. When a RAM write cycle occurs, the appropriate \overline{CS} line goes low, the proper address appears on the address bus, the data is presented on the data bus by the CPU, and the R/W line is pulsed low to latch the data into the RAM location.

DATA I/O

Integrated circuit U103, a PIA (peripheral interface adapter), is used for I/O functions and baud rate selection. This device has two (port A and port B) 8-bit bidirectional data buses and four control lines. Each of the data lines can be programmed to act as an input or output. Bit 0 of port A (pin 2) is the serial output for a terminal. Bit 7 of port A is the serial input from a terminal. Bits 1, 2, and 3 are jumpers that let you select the desired baud rate. Software routines read the state of these bits and structure the serial I/O (bits 0 - 7) of port A accordingly. Port B of the PIA is the cassette I/O. Bit 0 is a FSK (frequency shift keying) output that is an FSK representation of the cassette dump data. The frequencies are "Kansas City Standards'' (1200/2400 Hz). Bit 7 is the input for the cassette load data.



BLOCK DIAGRAM

CASSETTE INPUT

Resistor R101 presents a load to the recorder output. R102, D107, and D108 limit the amplitude of the cassette output to approximately ± 0.6 volts. R109, R105, and C102 bias the input to comparator U109 to 2.5 volts. Resistors R106 and R107 form a positive feedback that provides 150 mV hysteresis to reduce noise susceptibility. The square wave output of U109 is coupled to port B, bit 7 (pin 17) of the PIA (U103).

CASSETTE OUTPUT

Square wave FSK cassette data generated by software is output from port B, bit 0 (pin 10) of the PIA. This output is filtered by the low pass filter made up of R112 and C103. Resistors R110 and R111 form a voltage divider that allows the data to be output to the recorder at a microphone input level (50 mV) or at a higher level input (500 mV) to an auxillary input.

TERMINAL INPUT

The terminal input circuit can be configured for an RS232 or a 20 mA current loop signal. The 20 mA current loop is active and it is not isolated.

When the circuit is configured for the 20 mA current loop, resistors R113 and R114 provide an active 20 mA current source. When the 20 mA input line switches, transistor Q104 produces an inverted signal. This signal is again inverted by Q105 before it is applied to port A, bit 7 of U103.

When the circuit is configured for an RS232 input, transistor Q104 inverts the RS232 voltage swings and generated TTL levels that are acceptable to the PIA input.

TERMINAL OUTPUT

The terminal output circuit can also be configured for an RS232 or a 20 mA current loop output. The current loop is active and it is not isolated.

When the circuit is configured for the 20 mA current loop, software generated serial data is outputted from port A, bit 0 of the PIA. This serial data is inverted by Q102 and coupled to output driver Q101. Output current is limited to 20 mA by R129 and R121.

When the circuit is wired for RS232 operation, the software generated serial data is inverted by Q103 and again by Q102. It is then coupled to output drive Q101. Resistor R129 is the pulldown load resistor.

IN CASE OF DIFFICULTY

WARNING: Dangerous AC voltage is present inside the cabinet (where the fuse is located) when the line cord is plugged in. See Pictorial 6-2.

This section of the Manual is divided into three parts: "Visual Checks," "Troubleshooting Chart," and "Detailed Troubleshooting." Use the "Visual Checks" first to find a difficulty that shows up right after your kit is assembled. You can also use the other two sections right after your kit is assembled, or at some future time — if your Accessory ever stops working.

If the trouble is still not located after you complete the "Visual Checks," check voltage readings against those shown in the "Schematic." NOTE: All voltage readings were taken with a high impedance voltmeter (10 M Ω or greater).

In the extreme case where you are unable to resolve a difficulty, refer to the "Customer Service" information inside the rear cover of your Manual. Your Warranty is located inside the front cover.

VISUAL TESTS


1. Recheck the wiring. Trace each lead in colored pencil on the Pictorial as it is checked. It is frequently helpful to have a friend check your

work. Someone who is not familiar with the unit may notice something you consistently overlook.

2. About 90 percent of the kits that are returned to the Heath Company for repair do not function properly due to poor connections and soldering. Therefore, you can eliminate many troubles by reheating all connections to make sure they are soldered.

CAUTION: Before you solder or reheat any connections, remove the following integrated circuits. Refer back to "Final Assembly and Operational Tests" for replacement and proper handling of these IC's.

- U103 (#443-843) U105 (#444-51) U106 (#444-24) U108 (#444-28) U117 (#443-764) U118 (#443-764)
- 3. Check to be sure that all the integrated circuits are in their proper location and that each IC pin is properly installed in its connector, and not bent or under the IC.



PICTORIAL 6-2

Page 49

- 4. Check the values of the parts. Be sure in each step that the proper part has been wired into the circuit, as shown in the Pictorial diagrams. It would be easy, for example, to install a 470 Ω (yellow-violet-brown) resistor where a 4700 Ω (yellow-violet-red) resistor should have been installed.
- 5. Check for bits of solder, wire ends, or other foreign matter which may be lodged in the wiring.

Precautions

1. Be cautious when you test IC's. Although they have almost unlimited life when used properly, they are much more vulnerable to damage from excessive voltage or current than some other components.

- 2. Be sure you do not short any terminals to ground when making voltage measurements. If the probe slips, for example, and shorts out a bias or supply point, it is very likely to damage one or more IC or diodes.
- 3. Do not remove an IC while the line cord is plugged in.

Substitution

Corresponding display components can be interchanged; U111 through U118 can be interchanged, for example. If a random-access memory location consistently shows incorrect data you can interchange the memory IC with one of the others. If the problem moves to the new location the memory IC is probably bad. If the problem remains at the same location check the associated circuitry for a solder bridge or broken foil. If you cannot see anything physically wrong then you can suspect the memory decoder chip, U108.

Troubleshooting Chart

NOTES:

- 1. The following chart lists parts to check. These parts indicate areas of the circuits where problems could exist. Check the circuitry and look for an assembly error or **solder bridge**. Parts are rugged and reliable. Consider a part to be bad last.
- 2. If you make a repair, make sure you eliminate the cause as well as the effect of the trouble. If,

for example, you find a damaged part, be sure you find out what damaged the part. If the cause is not eliminated, the replacement part may also become damaged when you put the unit back into operation.

3. In several areas of the circuit boards, the foil patterns are quite narrow. When you unsolder a part to check or replace it, avoid excessive heat while you remove the part. A suction-type desoldering tool makes part removal easier.

TROUBLESHOOTING CHART

DIFFICULTY	POSSIBLE CAUSE
Failure to get CPU UP.	 ET-3400 Trainer not functioning. Disconnect ETA-3400 Accessory. Reinstall IC14 and IC15 (443-721) and test Trainer operation. Check connector cable. Accessory not functioning.
No +5V, 12V and -12 supplies.	 Fuse F1. Transformer T1 primary. Line cord wiring.
No +5V supply.	 Short circuit on 5V line. Transformer T1 secondary (green and green-yellow leads). Rectifier diodes (57-42). Regulator U110.
No ±12V supply.	 Short circuit on ±12 V line. Transformer T1 secondary (red and red-yellow leads). Bridge rectifier. (D101, D102, D103, D104). Regulators U101 and U102.
Memory Test Failure.	1. U111, U112, U113, U114, U115, U116, U117, U118 RAM.
Failure to get TINY BASIC or Monitor. (: or MON>)	 Wrong baud rate. Fantom II Monitor ROM (U105). TINY BASIC ROM (U106). Address Decoder (U107 and U108). Peripheral interface adapters (U103). TTY/RS232 I/O circuitry. Video terminal incorrectly wired or not operating.
Cassette I/O.	 Check cassette operation. (Wiring, playback level, tape). U109, D107, D108. Cassette I/O circuitry. Address Decoder (U107 and U108). Peripheral interface adapter (U103). TINY BASIC and/or Fantom II ROM.

Page 51

SPECIFICATIONS

Clock	1MHz crystal controlled.
Terminal MONITOR in ROM	$2k \times 8$ NMOS.
TINY BASIC in ROM	$2k \times 8$ NMOS.
Serial I/O	110, 300, 600, 1200, 4800, 9600 baud. RS232 and 20 mA active current loop.
Audio Cassette Storage	300 to 2400 baud (programmable).
RAM	1 k × 8 RAM expandable to 4 k in 1 k increments with optional Chip Set (ETA-3400-1).
ET-3400 Interface	Buffered data address and control buses connected by 40-pin ribbon cable.
Local Power Supply	+12 volts and –12 volts @ 50 mA. +5 volts @ 1 ampere.
Power Requirements	105-130 volts, 50-60 Hz, 11 watts. 210-260 volts, 50-60 Hz, 11 watts.
Weight	6 lbs (3.36 kg).
Dimensions	11-1/4" wide \times 13" deep \times 3-1/2" high. 28.58 cm \times 33.02 cm \times 8.89 cm.

SEMICONDUCTOR IDENTIFICATION CHARTS

This section is divided into three parts: Component Number Index, Part Number Index, and ROM and PLA Programs. The first section provides a crossreference between semiconductor component numbers and their respective Part Numbers. The component numbers are listed in numerical order. The second section provides a lead configuration detail (basing diagram) for each semiconductor Part Number. The Part Numbers in the second section are also listed in numerical order. The third section provides a program for the specially "programmed" integrated circuit decoder.

Component Number Index

This index shows the Part number of each semiconductor in the Terminal.

DIODES

CIRCUIT	HEATH
COMPONENT	PART
NUMBER	NUMBER
D101-D104	5 7-6 5
D105-D106	57-42
D107-D109	56-56

TRANSISTORS

CIRCUIT	HEATH
COMPONENT	PART
NUMBER	NUMBER
Q101	417-874
Q102-Q105	417-875

INTEGRATED CIRCUITS

CIRCUIT	HEATH
COMPONENT	Part
NUMBER	Number
U101	442-664
U102	442-663
U103	443-843
U104	443-18
U105	444-51
U106	444-24
U107	443-46
U108	444-28
U109	442-616
U110	442-54

Part Number Index

This index shows a load configuration detail (basing diagram) of each semiconductor Part Number.

DIODES

COMPONENT	HEATH PART NUMBER	MAY BE REPLACED WITH	IDENTIFICATION
D105, D106	57-42	3A1	IMPORTANT: THE BANDED END OF DIODES CAN
D101, D102, D103 D104	57-65	1 N4 002	BE MARKED IN A NUMBER OF WAYS.
D107, D108, D109	56-56	1 N 4149	SC SF ST ST ST
			BANDED END

TRANSISTORS

HEATH PART NUMBER	MAY BE REPLACED WITH	TRANSISTOR BASING DIAGRAM
417-874 417-875	2N3906 2N3904	E B C

INTEGRATED CIRCUITS

HEATH NUMBER	MAY BE REPLACED WITH	DESCRIPTION	IDENTIFICATION
442-54	μ Α780 5	5-VOLT REGULATOR U110	IN GND OUT OR OUT OUT
442-616	LM3302N LM2901N μΑ775	VOLTAGE COMPARATOR U109	OUTPUT OUTPUT 3 4 $6ND$ 4 4 3 3 14 13 12 11 10 9 8 3 4 4 3 3 14 13 12 11 10 9 8 14 13 12 11 10 10 10 10 10 10 10
442-663	μA78M12	12-VOLT REGULATOR U102	TO-220 PACKAGE PACKAGE OUTLINE GH PACKAGE CODE U COMMON OUT
442-664	μΑ79M12	-12-VOLT REGULATOR U101	
443-18	7404N	HEX INVERTER U104	$V_{CC} \xrightarrow{6A} \xrightarrow{6Y} \xrightarrow{5A} \xrightarrow{5Y} \xrightarrow{4A} \xrightarrow{4Y}$
443-46	7402	QUAD 2-INPUT POSITIVE NOR GATE U107	V_{CC} $4Y$ $4B$ $4A$ $3Y$ $3B$ $3A$ 14 12 11 10 9 8 14 12 11 10 9 8 14 12 11 10 9 8 7 1 1 12 24 3 4 5 6 7 7 7 7 7 7 7 7 7 7

HEATH PART NUMBER	MAY BE REPLACED WITH	DESCRIPTION	IDENTIFICATION
443-764	NMOS2114	1 k × 8 STATIC RAM U117, U118	$V_{CC} = A_7 + A_8 + A_9 + 1/0_1 + 1/0_2 + 1/0_3 + 1/0_4 = WE$ $18 + 17 + 16 + 15 + 14 + 13 + 12 + 11 + 10$ $1 + 2 + 3 + 4 + 5 + 6 + 7 + 8 + 9$
			$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
443-843	MC6820	PERIPHERAL INTERFACE ADAPTER U103	VSS 1 40 CA1 PA0 2 39 CA2 PA1 3 38 IRQA PA2 4 37 IRQB PA3 5 36 RS0 PA4 6 35 RS1 PA5 7 34 Reset PA6 8 33 D0 PA7 9 32 D1 PB0 10 31 D2 PB1 11 30 D3 PB2 12 29 D4 PB3 13 28 D5 PB4 14 27 D6 PB5 15 26 D7 PB6 16 25 E PB7 17 24 CS1 CB1 18 23 CS2 CB2 19 22 CS0 Vcc 20 21 R/W
444-24	NMOS2316E	TINY BASIC ROM U106	V _{CC} A ₈ A ₉ CS ₃ CS ₁ A ₁₀ CS ₂ D ₇ D ₆ D ₅ D ₄ D ₃ [24] [23] [22] [21] [20] [19] [18] [17] [16] [15] [14] [13]
444-51	NMOS2316E	MONITOR ROM U105	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$

Integrated Circuits (cont'd.)

HEATH PART NUMBER	MAY BE REPLACED WITH	DESCRIPTION	INDENTIFICATION
444-28	TTL 32*8 ROM	ADDRESS DECODER ROM	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$

444-28

U108

ROM Program

This is the software code used in the decoder ROM.

		0.0	•		
	A14	A13	A12	A11	A10
PIN #	14	13	12	11	10
-	0	0	0	0	0
	0	0	0	0	1
	0	0	0	1	0
	0	0	0	1	1
	0	0	1	0	0
	0	0	1	0	1
	0	0	1	1	0
	0	0	1	1	1
	0	1	0	0	0
	0	1	0	0	1
	0	1	0	1	0
	0	1	0	1	1
	0	1	1	0	0
	0	1	1	0	1
	0	1	1	1	0
	0	1	1	1	1
	1	0	0	0	0
	1	0	0	0	1
	1	0	0	1	0
	1	0	0	1	1
	1	0	1	0	0
	1	0	1	0	1
	1	0	1	1	0
	1	0	1	1	1
	1	1	0	0	0
	1	1	0	0	1
	1	1	0	1	0.
	1	1	0	1	1
	1	1	1	0	0
	1	1	1	0	1
	1	1	1	1	0
	1	1	1	1	1

	GROUP DECODE	BASIC	MONITOR	P.I.A.	RAM 3	RAM 2	RAM 1	RAM 0
PIN #	9	7	6	5	4	3	2	1
	0	1	1	1	1	1	1	0
	0	1	1	1	1	1	0	1
	0	1	1	1	1	0	1	1
·	0	1	1	1	0	1	1	1
	0	1	1	0	1	1	1	1
	0	1	0	1	1	1	1	1
	0	1	0	1	1	1	1	1
	0	0	1	1	1	1	1	1
	0	0	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
:	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1
	1	1	1	1	1	1	1	1

FOR PARTS	REQUESTS	ONLY			FOR PARTS	REQUEST	SONLY	
 Be sure to follow instructions carefully. Use a separate letter for all correspondence. 					Be sure to follow instructions carefully.			
 Use a separate let Please allow 10 - 					 Use a separate let Please allow 10 - 			
	RITE IN THIS S			┫╏┣━━				
 INSTRUCTIONS Please print all informa Be sure you list the corr it appears in the parts If you wish to prepay y payment in an envelo minimum, \$3.50 maxin handling. Michigan res If you prefer COD shipped 	ect HEATH pa list. rour order, ma pe. Be sure t num) for insu idents add 49 Total er	art number (il this card o include ⁻ rance, ship 6 tax. inclosed \$_	and your 10% (25¢ oping and		STRUCTIONS Please print all informa Be sure you list the corr it appears in the parts If you wish to prepay y payment in an envelo minimum, \$3.50 maxir handling. Michigan res If you prefer COD shipt	ect HEATH p list. your order, m pe. Be sure num) for insu sidents add 4 Total e	art number of ail this card to include ⁻ urance, ship % tax. nclosed \$	and your 10% (25¢ oping and
this form.					this form.			
NAME				NA	ME			
ADDRESS				ш AD	DRESS	·····		
CITY					Υ			
STATE		ZIP		ST/	ATE		ZIP	
Model # Date Purchased	Location			IT III Mo	p us provide you with b del # e chased	Invoice # Location		
LIST HEATH PART NUMBER	QTY.	PRICE EACH	TOTAL PRICE		LIST HEATH PART NUMBER	QTY.	PRICE EACH	TOTAL PRICE
TOTAL FOR PARTS				І то	TAL FOR PARTS			
HANDLING AND SHIPPIN	IG				NDLING AND SHIPPIN	IG		
MICHIGAN RESIDENTS	NDD 4% TAX				CHIGAN RESIDENTS A			
TOTAL AMOUNT OF OR	DER			то	TAL AMOUNT OF OR	DER		
BENTO MICHIG	COMPANY N HARBOR AN 49022 PARTS REPL				BENTO MICHIG	COMPANY N HARBOR AN 49022 PARTS REPL		••••• <u>•</u> •••
Phone (Replacemer	nt parts only):	616 982-3	571		Phone (Replacemer	nt parts only):	616 982-3	571
THIS FORM IS FO OVERSEAS CUSTOM	R U.S. CUSTOM	ERS ONLY DISTRIBUTOR	۹	· · · 	THIS FORM IS FO OVERSEAS CUSTOME	R U.S. CUSTOM	ERS ONLY	

CUSTOMER SERVICE

REPLACEMENT PARTS

Please provide complete information when you request replacements from either the factory or Heath Electronic Centers. Be certain to include the **HEATH** part number exactly as it appears in the parts list.

ORDERING FROM THE FACTORY

Print all of the information requested on the parts order form furnished with this product and mail it to Heath. For telephone orders (parts only) dial 616 982-3571. If you are unable to locate an order form, write us a letter or card including:

- Heath part number.
- Model number.
- Date of purchase.
- Location purchased or invoice number.
- Nature of the defect.
- Your payment or authorization for COD shipment of parts not covered by warranty.

Mail letters to: Heath Company Benton Harbor MI 49022 Attn: Parts Replacement

Retain original parts until you receive replacements. Parts that should be returned to the factory will be listed on your packing slip.

OBTAINING REPLACEMENTS FROM HEATH ELECTRONIC CENTERS

For your convenience, "over the counter" replacement parts are available from the Heath Electronic Centers listed in your catalog. Be sure to bring in the original part and purchase invoice when you request a warranty replacement from a Heath Electronic Center.

TECHNICAL CONSULTATION

Need help with your kit? — Self-Service? — Construction? — Operation? — Call or write for assistance. you'll find our Technical Consultants eager to help with just about any technical problem except "customizing" for unique applications.

The effectiveness of our consultation service depends on the information you furnish. Be sure to tell us:

- The Model number and Series number from the blue and white label.
- The date of purchase.
- An exact description of the difficulty.
- Everything you have done in attempting to correct the problem.

Also include switch positions, connections to other units, operating procedures, voltage readings, and any other information you think might be helpful.

Please do not send parts for testing, unless this is specifically requested by our Consultants.

Hints: Telephone traffic is lightest at midweek — please be sure your Manual and notes are on hand when you call.

Heathkit Electronic Center facilities are also available for telephone or "walk-in" personal assistance.

REPAIR SERVICE

Service facilities are available, if they are needed, to repair your completed kit. (Kits that have been modified, soldered with paste flux or acid core solder, cannot be accepted for repair.)

If it is convenient, personally deliver your kit to a Heathkit Electronic Center. For warranty parts replacement, supply a copy of the invoice or sales slip.

If you prefer to ship your kit to the factory, attach a letter containing the following information directly to the unit:

- Your name and address.
- Date of purchase and invoice number.
- Copies of all correspondence relevant to the service of the kit.
- A brief description of the difficulty.
- Authorization to return your kit COD for the service and shipping charges. (This will reduce the possibility of delay.)

Check the equipment to see that all screws and parts are secured. (Do not include any wooden cabinets or color television picture tubes, as these are easily damaged in shipment. Do not include the kit Manual.) Place the equipment in a strong carton with at least THREE INCHES of *resilient* packing material (shredded paper, excelsior, etc.) on all sides. Use additional packing material where there are protrusions (control sticks, large knobs, etc.). If the unit weighs over 15 lbs., place this carton in another one with 3/4" of packing material between the two.

Seal the carton with reinforced gummed tape, tie it with a strong cord, and mark it "Fragile" on at least two sides. Remember, the carrier will not accept liability for shipping damage if the unit is insufficiently packed. Ship by prepaid express, United Parcel Service, or insured Parcel Post to:

Heath Company Service Department Benton Harbor, Michigan 49022



COLUMN TRANS TOLEDAY


NR ROAD (I.

1971 Calendaria

碗.


1.28 1.163


HEATH COMPANY . BENTON HARBOR, MICHIGAN THE WORLD'S FINEST ELECTRONIC EQUIPMENT IN KIT FORM




TION BOOKLET

Part of 595-2170-03







Detail 1-13A




Detail 1-14A



Detail 1-15A












-3






PICTORIAL 2






~ ~





PICTORIAL 5-2




PICTORIAL 5-3

PICTORIAL &






CTORIAL 5-4



CIRCUIT BOARD X-I



OARD X-RAY VIEW